

TWINGO

1 Engine and peripherals

16A STARTING-CHARGING

New Twingo

Fault finding – List and location of components	16A - 2
Fault finding – Role of components	16A - 3
Fault finding – Operating diagram	16A - 4
Fault finding – Features	16A - 5
Fault finding – Customer complaints	16A - 6
Fault finding – Fault finding charts	16A - 7
Fault finding – Tests	16A - 16

V2

Edition Anglaise


"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."


All rights reserved by Renault s.a.s.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault s.a.s.


© Renault s.a.s. 2008



1 Starter motor



3 Passenger compartment unit UCH



2 Alternator

● Battery

The principal purpose of the battery is to provide the powerful current briefly required by the starter motor to start the engine. For optimum starting, the current supplied by the battery must be sent to the starter motor with minimum loss. To achieve this, the electrical connections (wires, terminals, connectors, etc.) must be in good condition. When the engine is not running, the battery must feed the accessories that operate constantly, even with the ignition switched off, such as the alarm, radio codes, computers, etc.

● Alternator

The alternator only operates when the engine is running. Its function is to recharge the battery, and at the same time to supply the electrical power required to operate all the electrical accessories on the vehicle. The alternator fitted to the New Twingo is a controlled alternator. The UCH controls the regulation by means of a serial connection (BSS).


● UCH

The UCH is linked to the alternator by a serial connection (BSS connection). The UCH and the alternator communicate via this connection. The UCH intelligently manages the alternator regulation voltage according to the engine phase, battery charge and temperature.

● Starter

This turns the engine over to make it start, and requires a very powerful electric current, which the battery must be able to supply.

STARTING - CHARGING FLOWCHART:



- 1 Battery (107)
- 2 Starter (163)
- 3 Alternator (103)
- 4 UCH (645)

- A Supply and voltage measurement
- B BSS connection (serial connection for communication between the alternator and the UCH)
- C Starter control line

The function of the charging circuit is to:

- Ensure electrical energy is supplied to the vehicle whilst respecting the dynamic performance constraints of the engine and transmission assembly: the alternator resisting torques and the torque gradients measured must be managed.
- To control alternator loading and load shedding during engine management authorisation or variation of the electrical load.
- To ensure the quality of the on board network voltage in terms of the voltage level and variation (voltage gradient management).
- To optimise the battery charge by applying a voltage to its terminals correlating to its initial charge status (in sleep mode) and to its internal temperature.
- To inform the engine management about the mechanical power taken from the accessories pulley the alternator charge rate and the rotor excitation current value.
- To run fault finding on the charging circuit: “Battery” warning light display.

The function of the starting circuit is to:

- Start the vehicle during a starting request with the ignition key if necessary.

STARTING

THE STARTER DOES NOT WORK

ALP1

THE STARTER TURNS BUT DOES NOT
ENGAGE

ALP2

STARTER NOISY


ALP3

LOW STARTER SPEED

ALP4

ALP1	The starter does not work
-------------	----------------------------------

NOTES	Test the condition of the battery (see 80A, Battery). Test the condition of the power fuse (see TEST 2). Check that fuse F9 on component 1016 is in good condition. Check that the engine is not jammed.
--------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



ALP1 CONTINUED 1

A

With the ignition switched off, measure the voltage between the battery earth and the starter control terminal.

Voltage value?

< 1 V

Between 1 V
and 10 V

≥ 10 V

While activating the starter, measure the voltage between the battery earth and the starter control terminal.

Voltage value?

≥ 10 V

< 10 V

Replace the starter
(see **MR 411, 16A,
Starting - Charging,
Starter: Removal -
Refitting**).

C

Disconnect the starter control terminal wire and measure the voltage on the wire of connection 1A again.

Voltage value?

≥ 10 V

< 10 V

Replace the starter
(see **MR 411, 16A,
Starting - Charging,
Starter: Removal -
Refitting**).

Disconnect relay 232 on component 597 and measure the voltage on connection 1A.

Voltage value?

< 10 V

≥ 10 V

C

Insulation fault on connection 1A between components 232 and 163. If there is a repair method (see **Technical Note 6015A, Repairing electrical wiring, Wiring: Precautions for repair**) repair the wiring, otherwise replace it.

**ALP1
 CONTINUED 2**



Measure the voltage on connection BPDA between the earth taken on one of the starter mounting points and its B+ terminal while activating the starter.

Voltage value?

> 10 V

Between 0 V and 10 V

Measure the drop in voltage on connection BPDA between the battery + terminal and the starter B+ terminal while activating the starter.

Voltage value?

≥ 1 V

Replace the wire connecting the battery + terminal to the starter.

< 1 V

Measure the drop in voltage between the battery - terminal and the earth on one of the starter mounting points while activating the starter.

Voltage value?

≥ 1 V


Replace the earth wire(s) connecting the engine to the battery.

< 1 V

Replace the starter (see **MR 411, 16A, Starting - Charging, Starter: Removal - Refitting**).

ALP1 CONTINUED 3

C



**ALP1
CONTINUED 4****D**

YES

Check for **12 V** on relay 232 between connection **1A** of component **232** and a chassis **earth** when starting is requested. Is there **12 V**?

NO

Replace the starter relay (see **MR 411 Mechanical, 81C, FUSES, Engine compartment fuse and relay box: List and location of components**).

YES

Continuity and/or insulation fault on connection **1A** between components **232** and **163**. If there is a repair method (see **Technical Note 6015A, Repairing electrical wiring, Wiring: Precautions for repair**) repair the wiring, otherwise replace it.

ALP2	The starter turns but does not engage
-------------	----------------------------------------------

NOTES	Special notes: Disconnect the battery earth before handling.
--------------	------------------------------------------------------------------------

Remove the starter (see **MR 411 Mechanical, 16A, Starter: Removal - Refitting**).

Check that the ring gear of the flywheel is in good condition.

Are the ring gear teeth damaged?

YES

NO

Replace the flywheel (see **MR 411, Mechanical, 10A, Flywheel: Removal - Refitting**).

Check the condition of the starter (broken teeth or worn gears).

Is the starter in good condition?

YES


NO


Refit the starter (see **MR 411 Mechanical, 16A, Starter: Removal - Refitting**).

Replace the starter (see **MR 411 Mechanical, 16A, Starter: Removal - Refitting**).

ALP3	The starter is noisy when starting
-------------	-------------------------------------------

NOTES	Test the condition of the battery (see MR 413, 80A, Battery). Check that the noise is actually coming from the starter.
--------------	------------------------------------------------------------------------------------------------------------------------------------



**ALP3
CONTINUED**

ALP4

The starter rotates slowly from the outset.
The rotation speed of the starter decreases rapidly.
The starter causes the warning lights on the instrument panel to become very dim

Applicability: All types**NOTES**

Test the wiring (TEST3).
Test the status of the battery (see **80A, Battery**).

If the fault is still present, replace the starter (see **MR 411, 16A, Starting - Charging, Starter: Removal - Refitting**).

NOTES

Perform this test only after running complete fault finding on the UCH using the diagnostic tool (see **87B, UCH**).
Because the UCH houses the CHARGING CIRCUIT function (sub-function: alternator) and checks the alternator via a serial connection (BSS).

CHARGING

ALTERNATOR SUPPLY TEST

TEST1

TEST1

Alternator supply test

NOTES

Test the condition of the battery (see **80A, Battery**).

Measure the voltage at the battery terminals with the engine warm and running at idle speed for 2 minutes and with all consumers switched off.

Voltage value?

< 14.8V

> 14.8V

Replace the alternator (see **MR 411, 16A, Starting - Charging, Alternator: Removal - Refitting**).
Visually inspect the consequences (battery condition, corrosion, etc.).

With the engine at idle speed, connect a current clamp to the alternator B+ wire, connection BPDA, with all consumers switched off.

Current < 5 A

Current between 5 A
and 35 A

Current > 35A

Replace the alternator
(see **MR 411, 16A, Starting - Charging, Alternator: Removal - Refitting**).

Keep the engine speed at
3000 rpm and still with no
consumers switched on.


Check that there are no
electrical components
consuming an abnormal
amount of current.
Disconnect the fuses one by
one to identify the consumer.

Value of measured current?
(i 1)

To be examined


A

TEST1 CONTINUED 1




TEST2	Test the condition of the power fuse and the cause of its fault
--------------	------------------------------------------------------------------------

NOTES	Check that the engine is not locked
--------------	-------------------------------------



**TEST2
 CONTINUED 1**



TEST3

Wiring test

Check the condition of the battery terminals. Check that there is no corrosion on the battery terminals. Check that the terminals are correctly tightened and secure (see **MR 411 Mechanical, 80A, Battery, Battery: Removal - Refitting**).

Are the terminals and posts in good condition and not corroded?

NO

Clean the terminals and posts or replace them, if necessary.

YES

Check that there are no electrolyte leaks from the battery (cracks or breakage).
Check that the mechanical mounting of the battery is sound (see **MR 411, Mechanical, 80A, Battery, Battery: Removal - Refitting**).

Is the battery in good condition?

NO

Change the battery and clean the surrounding area on the vehicle if necessary.
(see **MR 411, Mechanical, 80A, Battery, Battery: Removal - Refitting**).

YES

Inhibit the engine injection (see **13B or 17B, Interpretation of commands**).
With the starter activated, measure the voltage on connection BPDA between the + terminal of the battery, component 107, and the B+ of the starter, component 163.

Is the voltage > 1 V?

YES

Repair the damaged wires and terminals. If the connection is faulty and if there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace the wiring

NO



TEST3 CONTINUED

A
NO

With the engine running and the main beam headlights lit and the heated rear screen on, measure the voltage between the B+ of the battery, component 107, and the B+ of the alternator, component 103.

Is the voltage > 0.7 V?

YES

Check that all the wires connecting the battery, the alternator and the starter are secure and in good condition, and that all their terminals are correctly tightened and secure.

Repair the damaged wires and terminals. If the connection is faulty and if there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace the wiring

NO

With the engine running and the main beam headlights lit and the heated rear screen on, measure the voltage between the negative terminal of the battery, component 107, and the alternator frame, component 103.

Is the voltage > 0.7 V?

YES

Check the earths of the engine, the alternator, the chassis, the gearbox, the battery, or the starter (check the tightness and condition of the terminals and the condition of the wires) (see **Technical Note for the relevant vehicle**).

Repair the damaged wires and terminals. If the connection is faulty and if there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace the wiring

NO

The electrical circuit is in good order.