

TWINGO

8 Electrical equipment

87F PARKING DISTANCE CONTROL

Vdiag No.: 04 08

Fault finding - Introduction	87F - 2
Fault finding - List and location of components	87F - 7
Fault finding - Operating diagram	87F - 8
Fault finding - Function	87F - 9
Fault finding - Role of components	87F - 10
Fault finding - Replacement of components	87F - 11
Fault finding - Configurations and programming	87F - 12
Fault finding - Fault summary table	87F - 13
Fault finding - Interpretation of faults	87F - 14
Fault finding - Conformity check	87F - 26
Fault finding - Status summary table	87F - 28
Fault finding - Interpretation of statuses	87F - 29
Fault finding - Parameter summary table	87F - 34
Fault finding - Interpretation of parameters	87F - 35
Fault finding - Customer complaints	87F - 37
Fault finding - Fault Finding Chart	87F - 38

V2

Edition Anglaise

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All rights reserved by Renault s.a.s.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault s.a.s.

© Renault s.a.s.

1. SCOPE OF THIS DOCUMENT

This document presents the fault finding procedure applicable to all computers with the following specifications:

Vehicle(s): New Twingo
Function concerned: Parking distance control

Computer name: Parking proximity sensor
Vdiag No.: 04 08

2. PREREQUISITES FOR FAULT FINDING

Documentation type

Fault finding procedures (this manual):

- Assisted fault finding (integrated into the **diagnostic tool**), Dialogys.

Wiring Diagrams:

- Visu-Schéma (CD-ROM), paper.

Type of diagnostic tools

- **CLIP + multiplex line sensor**

Special tooling required

Special tooling required	
	Multimeter
Elé. 1681	Universal bornier

3. RECAP

To run fault finding on the vehicle computers, switch on the ignition.

Depending on the type of vehicle equipment, proceed as follows:

For vehicles with radio frequency remote control/key,
 switch on the ignition with the key.

To cut off the + after ignition feed, proceed as follows:

For vehicles with key/radio frequency remote control, use the key to switch off the ignition.

Faults

Faults are declared as either present or stored (depending on whether they appeared in a certain context and have disappeared since, or whether they remain present but have not been diagnosed within the current context).

The **present** or **stored** status of faults should be taken into consideration when the **diagnostic tool** is used following the + after ignition supply being switched on (without operating the system components).

For a **present fault**, apply the procedure described in the **Interpretation of faults** section.

For a **stored fault**, note the faults displayed and apply the instructions in the **Notes** section.

If the fault is **confirmed** when the instructions in the Notes section are applied, the fault is present. Deal with the fault

If the fault is **not confirmed**, check:

- the electrical lines which correspond to the fault,
- the connectors for these lines (for oxidation, bent pins, etc.),
- the resistance of the component detected as faulty,
- the condition of the wires (melted or split insulation, wear).

Conformity check

The aim of the conformity check is to check data that does not produce a fault on the **diagnostic tool** because the data is inconsistent. Therefore, this stage is used to:

- carry out fault finding on faults that do not have a fault display, and which may correspond to a customer complaint.
- check that the system is operating correctly and that there is no risk of a fault recurring after repairs.

This section gives the fault finding procedures for statuses and parameters and the conditions for checking them.


If a status is not behaving normally or a parameter is outside the permitted tolerance values, consult the corresponding fault finding page.

Customer complaints - Fault finding chart

If the test with the **diagnostic tool** is OK but the customer complaint is still present, the fault should be processed by **customer complaints**.

A synopsis of the general procedure to follow is provided on the following page in the form of a flow chart.

4. FAULT FINDING PROCEDURE



4. FAULT FINDING PROCEDURE (continued)**Wiring check****Fault finding problems**

Disconnecting the connectors and/or manipulating the wiring harness may temporarily remove the cause of a fault. Electrical measurements of voltage, resistance and insulation are generally correct, especially if the fault is not present when the analysis is made (stored fault).

Visual inspection

Look for damage under the bonnet and in the passenger compartment. Carefully check the fuses, insulators and wiring harness routing. Look for signs of oxidation.

Tactile inspection

While manipulating the wiring harness, use the **diagnostic tool** to note any change in fault status from stored to present.

Make sure that the connectors are properly locked.

Apply light pressure to the connectors.

Twist the wiring harness.

If there is a change in status, try to locate the source of the fault.

Inspection of each component

Disconnect the connectors and check the appearance of the clips and tabs, as well as the crimping (no crimping on the insulating section).

Make sure that the clips and tabs are properly locked in the sockets.

Check that no clips or tabs have been dislodged during connection.

Check the clip contact pressure using an appropriate model of tab.

Resistance check

Check the continuity of entire lines, then section by section.

Look for a short circuit to earth, to **+ 12 V** or to another wire.

If a fault is detected, repair or replace the wiring harness.

5. FAULT FINDING LOG**IMPORTANT****IMPORTANT**

Any fault on a complex system requires thorough fault finding with the appropriate tools. The FAULT FINDING LOG, which should be completed during the procedure, enables you to keep track of the procedure which is carried out. It is an essential document when consulting the manufacturer.

IT IS THEREFORE MANDATORY TO FILL OUT A FAULT FINDING LOG EACH TIME FAULT FINDING IS CARRIED OUT.

You will always be asked for this log:


- when requesting technical assistance from Techline,
- for approval requests when replacing parts for which approval is mandatory,
- to be attached to monitored parts for which reimbursement is requested. The log is needed for warranty reimbursement, and enables better analysis of the parts removed.

6. SAFETY ADVICE


Safety rules must be observed during any work on a component to prevent any damage or injury:

- check the battery voltage to avoid incorrect operation of computer functions,
- use the appropriate tools,

- ENGINE WIRING
- FRONT OF ENGINE & ADDITIONAL HEADLIGHTS WIRING
- DOOR WIRING
- INTERIOR LIGHTS WIRING
- PASSENGER COMPARTMENT WIRING
- REAR BUMPER WIRING
- TAILGATE WIRING



- 1 Parking distance control computer
- 2 Parking distance control switch
- 3 Buzzer
- 4 Rear right-hand exterior sensor
- 5 Rear right-hand interior sensor
- 6 Rear left-hand exterior sensor
- 7 Rear left-hand interior sensor



26969

- 1: + after ignition feed
- 2: switch
- 3: switch warning light
- 4: trailer attachment
- 5: reversing signal
- 6: K line

DEACTIVATING THE SYSTEM

- The parking proximity sensor system can be deactivated in two ways:
- **Temporary deactivation: briefly pressing (1 second)** the parking distance control switch on the instrument panel deactivates the system (the red warning light on the switch comes on). The function can be switched on again by pressing **briefly** for a second time (the red indicator light on the switch goes out) or by switching the ignition off and back on.
- **Permanent deactivation:** The parking distance control system can be deactivated **for a longer period** by **pressing and holding** (for approximately **3 seconds**) the parking distance control switch on the instrument panel (the red warning light on the switch comes on). The function can be switched on again only by **pressing and holding** the switch again (the red warning light on the switch goes out).

Note:

The **diagnostic tool** statuses can be used to determine the function status (ready, detecting, suspended or deactivated) by using status **ET003 Parking distance control function** (see **Conformity check** or **the relevant status interpretation**).

Fault finding:

In the event of a system fault, the driver will be alerted by a 5-second continuous warning sound with a different pitch to the detection signal.

Description of operation

The system consists of four sensors built into the rear bumper, a computer and a buzzer. The system assists the driver during parking manoeuvres by warning of any obstacles to the rear of the vehicle.

The sensors and the computer calculate the distance between the vehicle and any obstacles.

The ultrasonic sensors are able to detect different obstacles such as:

- A wall.
- A post.
- A fence.
- A square section tube.
- Runner.

The sensors operate over a distance range from between **26 to 30 cm minimum and 150 cm maximum**. If an obstacle is less than **25 cm** away, the signal received (after coming into contact with the obstacle) will be disrupted by the signal emitted by the sensor, therefore, it is possible that measurements made at this distance will be incorrect

The driver is informed of the distances by a **buzzer**.

The system only works when the vehicle **is in reverse gear**. Activation is indicated by a **brief 0.5 second activation sound**.

The buzzer is activated when the vehicle is **150 cm** from the obstacle. As the distance diminishes, the frequency of the buzzer increases. When the distance reaches **20 - 30 cm**, the buzzer becomes continuous.

- The system can only be **activated with + after ignition feed and reverse gear engaged**.

REPLACING THE PARKING PROXIMITY SENSOR COMPUTER

BEFORE REPLACING ANY COMPUTER IT IS ESSENTIAL THAT YOU CONTACT TECHLINE.

When replacing the computer, apply the following procedure:

- switch off the ignition,
- replace the computer,
- configure the vehicle identification using command **CF005 Vehicle identification** (refer to **Configurations and Programming**),
- if there is a caravan attachment, check that there is no inconsistent warning sound. If there is, adjust the detection distance with configuration **VP003 "Caravan towbar distance"**.
- enter the vehicle identification number with the **diagnostic tool** using command **VP001 "Enter VIN"**,
- check that the system is operating correctly and make sure that there are no faults.

CONFIGURATION AFTER REPLACING THE COMPUTER

After replacing the computer, configure the parking distance control computer with the vehicle type using configuration **CF005 Vehicle identification** (repair mode menu, **diagnostic tool** configuration function).

The configuration adapts the sensors' detection field to the type of body.

Activation of the parking proximity sensor is indicated by a **brief 0.5 second activation sound** (vehicle in reverse gear).

After having configured the computer, check that the configuration has taken effect by reading the configuration **LC005 Vehicle identification**.

SETTING OPTIONS

The volume and the tone of the buzzer can be changed if the customer desires.

Configuration **CF001 "Buzzer volume"** is used to adjust the **volume** of the buzzer.

There are five selections:

- ZERO,
- LOW,
- MEDIUM,
- HIGH.
- MAXIMUM

Note:

The system must not be in "Detection" mode during this configuration as the buzzer will remain active until the next time the **+ after ignition feed** is cut off.

Configuration function **CF006 Pitch adjustment** is used to adjust the **pitch** of the buzzer.

There are three choices:

- 800 Hz,
- 1000 Hz,
- 2000 Hz (high pitch).

Note:

The system must not be in "Detection" mode during the configuration as the buzzer will remain active until the next time the **+ after ignition feed** is cut off.

After configuring the computer, check that these configurations have been registered correctly using configuration readings **LC001 "Buzzer volume"** and **LC006 "Tone adjustment"**.

Fault finding - Fault summary table

Summary of components on which fault finding can be performed by the parking distance control computer (the associated DTC column corresponds to the Design Office codes)

Tool fault	Associated DTC	Diagnostic tool title
DF002	9001	Left-hand outer sensor
DF003	9002	Left-hand inner sensor
DF004	9004	Right-hand outer sensor
DF005	9003	Right-hand inner sensor
DF006	9006	Buzzer
DF007	9007	Sensor feed voltage
DF008	9005	Computer fault
DF012	9010	Parking proximity sensor switch indicator light

DF002 PRESENT OR STORED	<u>LEFT-HAND OUTER SENSOR</u> CC.1 : Short circuit to + 12 V CO.0 : Open circuit or short circuit to earth 1.DEF: Internal electronic fault
--	--

NOTES	<p>Conditions for applying the fault finding procedure to stored faults: The fault is declared present following selection of reverse gear if the parking proximity sensor function is ACTIVE (READY): the parking proximity sensor warning light is not lit, see the interpretation of status ET003 Parking proximity sensor function.</p> <p>Special notes: This fault is indicated by the buzzer (a 5 second warning sound) and the system shuts down.</p>
--------------	--

CC.1 CO.0	NOTES	None
----------------------	--------------	------

Remove the rear bumper and disconnect the **3-track** connector on the left-hand outer sensor. Check for possible damage to the wiring harness, check the condition and connection of the **parking distance control computer** and **left-hand outer sensor** connectors (bent, oxidised or broken tabs). If the connection is faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

Switch off the ignition and disconnect the computer's **16-track connector**. Measure the internal resistances of computer component code **12022** between the following connections:

- Connection code **151C**,
- Connection code **151U**.

The resistance must be **215 kΩ ± 10 kΩ**.

- Connection code **151C**,
- Connection code **151V**.

The resistance must be **100 kΩ ± 5 kΩ**.

If the readings do not correspond to the above values or if there is a short circuit in the specified connections, contact Techline.

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

**DF002
CONTINUED**

Measure the resistance of component **1218** between the following connections:

- Connection code **151C**,
- Connection code **151U**.

If the resistance value is not infinite, replace the left-hand outer sensor.

- Connection code **151C**,
- Connection code **151V**.

If the resistance is not **40 kΩ ± 5 kΩ** (wait a few seconds for the reading to stabilise), replace the left-hand outer sensor.

If the fault is still present, contact the Techline.

With the ignition off, disconnect the parking distance control computer connector and check **the insulation, continuity and the absence of interference resistance** on the following connections:

- Connection code **151U**.
- Connection code **151C**.
- Connection code **151V**.

Between components **1222 and 1218**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, replace the left-hand outer detection sensor.

If the fault is still present, contact the Techline.

1.DEF

NOTES

None

Replace the left-hand outer sensor.

If the fault is still present, contact the Techline.

AFTER REPAIR

Clear the stored faults.
Follow the instructions to confirm repair.
Deal with any other faults.

DF003 PRESENT OR STORED	<u>LEFT-HAND INNER SENSOR</u> CC.1 : Short circuit to + 12 V CO.0 : Open circuit or short circuit to earth 1.DEF: Internal electronic fault
--	--

NOTES	<p>Conditions for applying the fault finding procedure to stored faults: The fault is declared present following selection of reverse gear if the parking proximity sensor function is ACTIVE (READY): the parking proximity sensor warning light is not lit, see the interpretation of status ET003 Parking proximity sensor function.</p> <p>Special notes: This fault is indicated by the buzzer (a 5 second warning sound) and the system shuts down.</p>
--------------	--

CC.1 CO.0	NOTES	None
----------------------	--------------	------

Remove the rear bumper and disconnect the **3-track** connector on the left-hand inner detection sensor. Check for possible damage to the wiring harness, check the condition and connection of the **parking distance control computer** and **left hand inner sensor** connectors (bent, oxidised or broken tabs). If the connection is faulty (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, or replace it.

Switch off the ignition and disconnect the computer's **16-track connector**.

Measure the internal resistances of the computer between the following connections:

- Connection code **151M**,
- Connection code **151U**.

The resistance must be **215 kΩ ± 10 kΩ**.

- Connection code **151M**,
- Connection code **151V**.

The resistance must be **100 kΩ ± 5 kΩ**.

If the readings do not correspond to the above values or if there is a short circuit in the specified connections, contact Techline.

Measure the resistance of component **1221** between the following connections:

- Connection code **151M**,
- Connection code **151U**.

If the resistance value is not infinite, replace the left-hand inner sensor.

- Connection code **151M**,
- Connection code **151V**.

If the resistance is not **40 kΩ ± 5 kΩ** (wait a few seconds for the reading to stabilise), replace the left-hand inner sensor.

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

DF003 CONTINUED	
----------------------------	--

With the ignition off, disconnect the parking distance control computer connector and check **the insulation, continuity and the absence of interference resistance** on the following connections:

- Connection code **151U**,
- Connection code **151M**.
- Connection code **151V**.

Between components **1222 and 1221**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, replace the left-hand inner detection sensor.

If the fault is still present, contact the Techline.

1.DEF	NOTES	None
--------------	--------------	------

Replace the left-hand inner sensor.

If the fault is still present, contact the Techline.

AFTER REPAIR	<p>Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.</p>
---------------------	--

DF004 PRESENT OR STORED	<u>RIGHT-HAND OUTER SENSOR</u> CC.1 : Short circuit to + 12 V CO.0 : Open circuit or short circuit to earth 1.DEF: Internal electronic fault
--	---

NOTES	<p>Conditions for applying the fault finding procedure to stored faults: The fault is declared present following selection of reverse gear if the parking proximity sensor function is ACTIVE (READY): the parking proximity sensor warning light is not lit, see the interpretation of status ET003 Parking proximity sensor function.</p> <p>Special notes: This fault is indicated by the buzzer (a 5 second warning sound) and the system shuts down.</p>
--------------	--

CC.1 CO.0	NOTES	None
----------------------	--------------	------

Remove the rear bumper and disconnect the **3-track** connector on the right-hand outer detection sensor. Check for possible damage to the wiring harness, check the condition and connection of the **parking distance control computer** and **right-hand outer sensor** connectors (bent, oxidised or broken tabs). If the connection is faulty (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, or replace it.

Switch off the ignition and disconnect the computer's **16-track connector**.

Measure the internal resistances of the computer between the following connections:

Connection code **151H**,

- Connection code **151U**.

The resistance should be **215 kΩ ± 10 kΩ**.

- Connection code **151H**,

- Connection code **151V**.

The resistance should be **100 kΩ ± 5 kΩ**.

If the readings do not correspond to the above values or if there is a short circuit in the specified connections, contact Techline.

Measure the resistance of component **1219** between the following connections:

- Connection code **151H**,

- Connection code **151U**.

If the resistance value is not infinite, replace the right-hand outer sensor.

- Connection code **151H**,

- Connection code **151V**.

If the resistance is not **40 kΩ ± 5 kΩ** (wait a few seconds for the reading to stabilise), replace the right-hand outer sensor.

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

DF004 CONTINUED	
----------------------------	--

With the ignition off, disconnect the parking distance control computer connector and check **the insulation, continuity and the absence of interference resistance** on the following connections:

Connection code **151U**,

Connection code **151H**.

Connection code **151V**.

Between components **1222 and 1219**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, replace the right-hand outer detection sensor.

<i>1.DEF</i>	<i>NOTES</i>	
		None

Replace the right-hand outer sensor.

If the fault is still present, contact the Techline.

AFTER REPAIR	<p>Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.</p>
---------------------	--

DF005 PRESENT OR STORED	<u>RIGHT-HAND INNER SENSOR</u> CC.1 : Short circuit to + 12 V CO.0 : Open circuit or short circuit to earth 1.DEF: Internal electronic fault
--	---

NOTES	<p>Conditions for applying the fault finding procedure to stored faults: The fault is declared present following selection of reverse gear if the parking proximity sensor function is ACTIVE (READY): the parking proximity sensor warning light is not lit, see the interpretation of status ET003 Parking proximity sensor function.</p> <p>Special notes: This fault is indicated by the buzzer (a 5 second warning sound) and the system shuts down.</p>
--------------	--

CC.1 CO.0	NOTES	None
----------------------	--------------	------

Remove the rear bumper and disconnect the **3-track** connector on the right-hand inner detection sensor. Check for possible damage to the wiring harness, check the condition and connection of the **parking distance control computer** and the **right hand inner sensor** connectors (bent, oxidised or broken tabs). If the connection is faulty (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, or replace it.

Switch off the ignition and disconnect the computer's **16-track connector**.

Measure the internal resistances of the computer between the following connections:

Connection code **151Q**,

- Connection code **151U**.

The resistance should be **215 kΩ ± 10 kΩ**.

- Connection code **151Q**,

- Connection code **151V**.

The resistance should be **100 kΩ ± 5 kΩ**.

If the readings do not correspond to the above values or if there is a short circuit in the specified connections, contact Techline.

Measure the resistance of component **1220** between the following connections:

- Connection code **151Q**,

- Connection code **151U**.

If the resistance value is not infinite, replace the right-hand inner sensor.

- Connection code **151Q**,

- Connection code **151V**.

If the resistance value is not **40 kΩ ± 5 kΩ** (wait a few seconds for the reading to stabilise), replace the right-hand inner sensor.

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

**DF005
CONTINUED**

With the ignition off, disconnect the parking distance control computer connector and check **the insulation, continuity and the absence of interference resistance** on the following connections:

Connection code **151U**,

Connection code **151Q**.

Connection code **151V**.

Between components **1222 and 1220**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, replace the right-hand inner detection sensor.

1.DEF

NOTES

None

Replace the right-hand inner sensor.

If the fault is still present, contact the Techline.

AFTER REPAIR

Clear the stored faults.
Follow the instructions to confirm repair.
Deal with any other faults.

DF006 PRESENT OR STORED	<p><u>BUZZER</u></p> <p>CC.1 : Short circuit to + 12 V CO.0 : Open circuit or short circuit to earth</p>
--	---

NOTES	<p>Conditions for applying the fault finding procedure to stored faults: The fault is declared present following selection of reverse gear if the parking proximity sensor function is ACTIVE (READY): the parking proximity sensor warning light is not lit, see the interpretation of status ET003 Parking proximity sensor function.</p> <p>Special notes: The fault is indicated by the absence of the 1-second beep normally emitted by the buzzer when reverse gear is selected.</p>
--------------	---

	<p>Check for possible damage to the wiring harness, check the condition and connection of the parking distance control computer and the buzzer connectors (bent, oxidised or broken tabs). If the connection is faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
	<p>Switch off the ignition and disconnect the 16 track connector from computer component code 1222. Measure the internal resistance of the computer between the following connections:</p> <ul style="list-style-type: none"> ●Connection code 151R. ●Connection code 151S <p>Between components 1222 and 1223. If the measured value is not 314 Ω ± 10 Ω or if there is a short circuit on the specified connections, contact Techline.</p>
	<p>Switch off the ignition, and disconnect the parking distance control computer to check the insulation, continuity and the absence of interference resistance on the following connections:</p> <ul style="list-style-type: none"> ●Connection code 151R, ●Connection code 151S. <p>Between components 1222 and 1223.</p> <p>If the connection or connections are faulty and if there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring or replace it.</p>
	<p>Measure the resistance value of component 1223 between the following connections: Measure the resistance between the following connections:</p> <ul style="list-style-type: none"> ●Connection code 151R, ●Connection code 151S. <p>Replace the buzzer if its resistance value is not approximately 48 Ω ± 5 Ω.</p>
	<p>If the fault is still present, replace the buzzer.</p>

AFTER REPAIR	<p>Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.</p>
---------------------	--

DF007 PRESENT OR STORED	<u>SENSOR SUPPLY VOLTAGE</u> CC.0: Short circuit to earth
--	--

NOTES	Conditions for applying the fault finding procedure to stored faults: The fault reappears present or stored after its has been cleared, the ignition is switched on and off again and reverse gear is selected.
	Special notes: The sensors are directly supplied with + 12 V by the computer.

<p>With the parking proximity sensor computer 16-track connector connected and with the ignition on, measure the sensor power supply coming from the computer. The voltage should be equal to the battery voltage (± 0.5 V) when measuring between connections 151U (+ 12 V) and 151V (earth). If there is no + 12 V supply between connections 151U and 151V, remove the rear bumper to access the sensors.</p>
<p>Switch off the ignition, and disconnect the parking proximity sensor computer to check the insulation and continuity and the absence of interference resistance on the following connections:</p>
<ul style="list-style-type: none"> ●Connection code 151U, ●Connection code 151V. <p>Between components 1222 and 1218, 1219, 1220, 1221.</p>
<p>If the connection or connections are faulty and if there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring or replace it.</p>
<p>If the sensor power supply is correct (no short circuit), reconnect the computer connector and four sensor connectors. Turn on the ignition and disconnect the sensors, one at a time, to see if any of the sensors causes the power supply to drop. Replace the defective sensor.</p>
<p>If the sensor supply lines are not correct, check the presence and condition of fuse F6 (15A); replace it if necessary. Check for the + 12 V supply on connection AP3 between components of component 1222 and 1016. Check for earth on connection MG between components 1222 and earth MG.</p>
<p>If the fault is still present, contact the Techline.</p>

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

DF008 PRESENT OR STORED	<u>COMPUTER FAULT</u> 1.DEF: Internal electronic fault
--	---

NOTES	Conditions for applying the fault finding procedure to stored faults: The fault reappears present or stored after its has been cleared, the ignition is switched on and off again and reverse gear is selected.
	Special notes: If the fault is present and is represented by 1.DEF or 2.DEF , the system operates in defect mode (substitute values are used).

1.DEF	NOTES	None
--------------	--------------	------

<p>After following the instructions, if the fault recurs, switch off the ignition and disconnect the supply fuse from the parking distance control computer F6 (15A). Reconnect the fuse, switch the ignition back on, and perform a fault reading.</p>
<p>If the fault recurs, check the connections and condition of the parking proximity sensor computer connector (no damage to the connections). If the connection is faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>With the ignition switched off, disconnect the parking proximity sensor computer connector to check the conformity of the feeds and to check the insulation, continuity and the absence of interference resistance on the following connections: Connection code AP3, Between components 1222 and 1016.</p> <p>Connection code MG. Between component 1222 and the rear left-hand earth.</p> <p>If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>If the fault is still present, contact the Techline.</p>

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

DF012 PRESENT OR STORED	<u>PARKING DISTANCE CONTROL SWITCH INDICATOR LIGHT</u> CC.0 : short circuit to earth or open circuit CC.1 : open circuit or short circuit to +12 volts
--	--

NOTES	Conditions for applying the fault finding procedure to stored faults: A fault is declared present after reverse gear is engaged and the parking distance control deactivation switch is pressed.
--------------	--

	Check for fuse F42 (10A) , check its condition and replace it if necessary.
	Remove the parking distance control switch and check the connection and condition of its connector. Repair if necessary.
	Check for earth on connection MAN of the connector of component 1440 . If the connection is faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it. With the ignition off , disconnect the parking proximity sensor computer to check the insulation, continuity and the absence of interference resistance on the following connection: <ul style="list-style-type: none"> ●Connection code 151E between components 1222 and 1440. If the connection is faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.
	Check the presence and condition of fuse F6 (15A) ; replace it if necessary. Check the + 12 V supply on connection LPDAP3 between components 1440 and 1016 . Check for earth on the connection MG between components 1222 and the earth MG .
	If the fault is still present, replace the parking distance control switch.

AFTER REPAIR	Clear the stored faults. Follow the instructions to confirm repair. Deal with any other faults.
---------------------	---

NOTES

Only perform this conformity check after a **complete check** with the **diagnostic tool**.
Conditions for applying the fault finding procedure: ignition on.

MAIN SCREEN

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
1	Parking distance control system status	ET003: Parking distance control function	READY (system operating and ready to detect)	For further information or, if there is a fault, consult the interpretation of status ET003 .
			DETECTING (if the system is detecting)	
			SUSPENDED (if the system is temporarily switched off)	
			OFF (if the system is completely switched off)	
2	Parking proximity sensor deactivation switch.	ET004: Parking distance control switch	PRESS DETECTED when the switch is pressed, RELEASED when released.	In the event of a fault, consult the interpretation of status ET004 .
3	Feeds	PR006: Sensor feed voltage	10.5 V < X <14.4 V	In the event of a fault, apply the fault finding procedure for DF007 Sensor supply voltage .
		PR020: Computer feed voltage	10.5 V < X <14.4 V	In the event of a fault with this parameter, consult the interpretation of fault DF008 "Computer fault" If the fault is still present, run fault finding on the charging circuit .
4	Reverse gear selection	ET001: Reverse gear engaged	YES or NO	If there is a fault, refer to the interpretation of status ET001 .

NOTES

Only perform this conformity check after a thorough check with the **diagnostic tool**.
Conditions for applying the fault finding procedure: ignition on.

MAIN SCREEN (CONTINUED)

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
5	Buzzer control	ET002: Buzzer control	ACTIVE when the buzzer sounds. INACTIVE if not.	In the event of a fault, consult the interpretation of status ET002 .
6	Proximity sensors	PR001: Left-hand outer sensor distance	26 cm < X < 150 cm depending on the distance from the obstacle ("out of range" value: 0 cm).	In the event of a fault, refer to the interpretation of the parameter PR001 .
		PR002: Left-hand inner sensor distance	26 cm < X < 150 cm depending on the distance from the obstacle ("out of range" value: 0 cm).	If there is a fault, refer to the interpretation of parameter PR002 .
		PR003: Right-hand outer sensor distance	26 cm < X < 150 cm depending on the distance from the obstacle ("out of range" value: 0 cm).	In the event of a fault, consult the interpretation of parameter PR003 .
		PR004: Right-hand inner sensor distance	26 cm < X < 150 cm depending on the distance from the obstacle ("out of range" value: 0 cm).	If there is a fault, refer to the interpretation of parameter PR004 .
		PR005: Shortest distance calculated	26 cm < X < 150 cm depending on the distance from the obstacle (value out of range or less than 30 cm: 0 cm).	If there is a fault, refer to the interpretation of parameter PR005 .
7	Caravan towbar	PR026: Distance from the caravan attachment	26 cm < X < 35 cm This distance allows the threshold point (0 cm) from the rear of the vehicle to be redetermined according to the length of the caravan towbar	In the event of a permanent or erratic warning signal, check that no components are disrupting the measurement (sticker, mud, snow on the rear bumper, etc.) then increase the distance of the caravan towbar cm by cm , using configuration VP003 "Caravan towbar distance" .

PARKING DISTANCE CONTROL

Fault finding - Status summary table

Tool status	Diagnostic tool title
ET001	Reverse gear engaged
ET002	Buzzer control
ET003	Parking distance control function
ET004	Parking distance control switch

ET001	<u>REVERSE GEAR ENGAGED</u>
--------------	-----------------------------

NOTES	<p>Special note: Only carry out the checks if the YES and NO statuses are not consistent with the position of the gear lever.</p>
--------------	--

<p>Check that the reversing lights are working properly: they should come on when reverse gear is engaged and go out when shifting out of reverse</p>
<p>Check for the presence and condition of fuse F6 (15A); replace it if necessary. Check for the + 12 V supply on connection AP3 between components 155 and 1016.</p>
<p>If the reversing lights fail to function as specified: With the ignition switched off, disconnect the parking distance control computer connector to check the insulation (against + 12 V), the continuity and the absence of interference resistance on the following connection:</p> <p>Connection code H66P between components 1222 and 172. Connection code H66P between components 1222 and 173.</p> <p>If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>Check that the reverse gear switch is operating correctly.</p>
<p>If the fault is still present, replace the reverse gear switch.</p>
<p>If the lights come on and the connections are correct, contact the Techline.</p>
<p>If the fault is still present, contact Techline.</p>

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

ET002	<u>BUZZER CONTROL</u>
--------------	-----------------------

NOTES	There must be no present or stored faults.
--------------	--

ET002 remains INACTIVE	<p>Check that the parking distance control system is activated using status ET003 “Parking distance control” function (parking distance control switch indicator light off) and check that status ET001 “Reverse gear engaged” shows “YES”. If the status displays “suspended” or “deactivated”, restart the system by pressing for 1 or 3 seconds, consult the interpretation of status ET003 “Parking distance control function”.</p> <p>Check, when the vehicle is close to an obstacle (between 26 and 150 cm), that the distance evaluated corresponds to the distance displayed by the diagnostic tool (PR001 to PR004). If the distance is inconsistent or if the distance parameters remain at 0 cm, consult the interpretation of faults DF002 “Left-hand outer sensor”, DF003 “Left-hand inner sensor”, DF004 “Right-hand outer sensor”, DF005 “Right-hand inner sensor”.</p>
---------------------------	---

ET002 ON but buzzer does not sound	<p>Check that status ET001 “Reverse gear engaged” is “YES”. Check that the buzzer volume is not at a zero setting (LC001: ZERO).</p> <p>If the configured volume is ZERO, reconfigure the computer using command CF001 Buzzer volume. Select the volume setting preferred by the customer (ZERO, MINIMUM, VERY LOW, LOW, MEDIUM, HIGH, MAXIMUM).</p> <p>Switch off the ignition, and disconnect the parking distance control computer to check the insulation and continuity and the absence of interference resistance on the following connections:</p> <p>Connection code 151R, Connection code 151S. Between components 1222 and 1016.</p> <p>If the connection or connections are faulty and if there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring or replace it.</p> <p>Check the condition of the buzzer and that it is operating correctly. Measure the resistance between the buzzer's two tracks. Replace the buzzer if its resistance is not approximately 48 Ω.</p> <p>If the fault is still present, replace the buzzer.</p>
--	---

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

ET003	<u>PARKING PROXIMITY SENSOR FUNCTION</u>
--------------	--

NOTES	<p>Special notes: If the parking proximity sensor system is suspended or deactivated, the parking proximity sensor switch indicator light comes on.</p>
--------------	--

This status indicates whether the parking distance control system is on or off:

ET003: READY	→	This means that, when reversing, the parking distance control detects obstacles and the buzzer sounds (the parking distance control switch indicator light goes out).
ET003: DETECTING	→	This information is displayed when reverse gear is engaged. This status indicates that the parking distance control system has detected an obstacle.
ET003: SUSPENDED	→	This means the parking distance control system is switched off (no detection possible). The suspension is temporary because the parking distance control system will come back on after the ignition is switched off and on. Briefly pressing the parking distance control switch enables the system to be suspended or reactivated manually.
ET003: DEACTIVATED	→	This means the parking distance control system is switched off (no detection possible). This suspension is permanent (switching the + after ignition off and on again will not reactivate the system). Pressing and holding (3 seconds) the parking distance control switch enables the system to be deactivated or reactivated.

Check the condition of the fuses **F6 (15A)**, **F42 (10A)**, and replace them if necessary.

If the status does not function as described, check the **+ 12 V** supply on connection **LPD** between components **1440** and **1016**. Check for **earth** on connection **MAN** of the connector of component **1440**.
If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

Check for a **+ 12 V** supply on connection **AP3**. Check for an **earth** on connection **MG** of the connector of component **1222**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.



AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

ET003 CONTINUED	
----------------------------------	--

(A)



With the ignition off, disconnect the parking proximity sensor switch to check the **insulation** (against the **earth** and **+ 12 V**), **continuity and the absence of interference resistance** on the following connection:

- Connection code **151W**,
 Between components **1222** and **1440**.

If the connection is faulty (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, or replace it.

If the connection just checked is correct (no open circuit or short circuit) and there is an **earth** on connection **MAN** of the switch but the fault is still present, check the switch operation with an ohmmeter.

Switch not pressed: **insulation** between connections **151W** and **MAN**.

After pressing the switch: **continuity** between connections **151W** and **MAN**.

Replace the parking proximity sensor switch if it fails to function as specified.

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

ET004	<u>PARKING DISTANCE CONTROL SWITCH</u>
--------------	--

NOTES	<p>Special notes: Only apply the interpretation of this status if the position of the parking distance control switch is not consistent with the information supplied by status (“Brief press” or “Released”). There must be no present or stored faults.</p>
--------------	--

<p>Check the condition of fuses F6 (15A), F42 (10A) and replace them if necessary.</p>
<p>Check that there is a + 12 V supply on connection LPD between components 1140 and 1016. Check that there is an earth on connection MAN of the connector of component 1440. If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>Check for a + 12 V supply on connection AP3. Check for earth on connection MG of the connector of component 1222. If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>With the ignition off, disconnect the parking distance control button connector to check the insulation (against earth and + 12 V), continuity and the absence of interference resistance on the following connection:</p> <p>Connection code 151W between components 1222 and 1440.</p> <p>If the connection is faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>If the connection just checked is OK (no open or short circuit), and there is an earth on track A2 of the switch but the fault is still present, check the switch operation with an ohmmeter. Switch not pressed: insulation between connections 151W and MAN. After pressing the switch: continuity between connections 151W and MAN. Replace the parking proximity sensor switch if it fails to function as specified.</p>

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

Tool parameter	Diagnostic tool title
PR001	Left-hand outer sensor distance
PR002	Left-hand inner sensor distance
PR003	Right-hand outer sensor distance
PR004	Right-hand inner sensor distance
PR005	Shortest distance calculated

PR001 PR002 PR003 PR004	<u>LEFT-HAND OUTER SENSOR DISTANCE</u> <u>LEFT-HAND INNER SENSOR DISTANCE</u> <u>RIGHT-HAND OUTER SENSOR DISTANCE</u> <u>RIGHT-HAND INNER SENSOR DISTANCE</u>
--	--

NOTES	<p>Special notes: Before searching for a fault with these parameters, make sure no fault is present or stored. If there is a fault, apply the interpretation for the fault detected by the diagnostic tool.</p> <p>Note: The ultrasonic sensors are very fragile. Therefore, when removing the rear bumper, be careful not to scratch them. If the distance displayed equals 0 cm, there are two possible reasons:</p> <ol style="list-style-type: none"> 1 no obstacle has been detected (therefore this is the default value) 2 The sensor is malfunctioning, check that there are none of the following faults: DF002 "LEFT-HAND OUTER SENSOR", DF003 "LEFT-HAND INNER SENSOR", DF004 "RIGHT-HAND OUTER SENSOR", DF005 "RIGHT-HAND INNER SENSOR" and apply the relevant fault finding procedure
--------------	--

When the vehicle is close to an obstacle (between **26** and **150 cm**), check that the distance evaluated corresponds to the distance displayed by the **diagnostic tool (PR001 to PR004)**.

If the distance is inconsistent when there is an obstacle present, check that there is nothing interfering with the measurement (sticker, mud, snow on the rear bumper, etc.).

If the distances displayed by the sensors are inconsistent, check the condition of the sensor(s), check the condition of the button using status **ET003 "Parking distance control function"** and **ET004 "Parking distance control switch"**. There must be no scratches on the detection component (outer metal section) of the sensors. Replace the defective sensor.

If the fault is still present, apply the fault finding procedure to the sensor whose distance parameter is incorrect (even if the **diagnostic tool** does not report a fault).

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

PR005	<u>SHORTEST DISTANCE CALCULATED</u>
--------------	-------------------------------------

NOTES	<p>Special notes: Before searching for a fault with this parameter, make sure that no fault is present or stored. If there is a fault, apply the interpretation for the fault detected by the diagnostic tool.</p>
	<p>Note: The ultrasonic sensors are very fragile. Therefore, when removing the rear bumper, be careful not to scratch them. This parameter is an average calculated by the computer when an obstacle is placed between two sensors. When below 30 cm, the estimated distance is displayed as 0 cm (critical detection zone with constant warning sound).</p>

With the vehicle close to an obstacle (between **0** and **150 cm**), check whether the calculated distance is consistent. If the distance is inconsistent when there is an obstacle present, check that there is nothing interfering with the measurement (sticker, mud, snow on the rear bumper, etc.).

If the distance calculated is still inconsistent or if it is continuously displayed as 255 cm, check the condition of the sensors; the detection part (metallic outer part) must not have any scratches.
Replace the defective sensor.

If the fault is still present, apply the fault finding procedure to the sensor with the inconsistent distance parameter (even if the **diagnostic tool** does not detect a fault), consult interpretation of faults, **DF002 "Left-hand outer sensor"**, **DF003 "Left-hand inner sensor"**, **DF004 "Right-hand outer sensor"**, **DF005 "Right-hand inner sensor"**.

AFTER REPAIR	Repeat the conformity check from the start.
---------------------	---

NOTES

Only consult this customer complaint after a complete check with the diagnostic tool.

NO DIALOGUE WITH THE COMPUTER

ALP1

NO BUZZER

ALP2

**WARNING SOUND EMITTED CONTINUOUSLY
(NO OBSTACLE DETECTED)**

ALP3

**BUZZER SOUNDS CONTINUOUSLY
(WITH CARAVAN ATTACHMENT)**

ALP4

ALP1	No dialogue with the computer
-------------	--------------------------------------


NOTES	None
--------------	------

<p>Try the diagnostic tool on another vehicle.</p>
<p>Check:</p> <ul style="list-style-type: none"> – The connection between the diagnostic tool and the diagnostic socket (lead in good condition). – The injection, engine and passenger compartment fuses.
<p>Check the condition of fuses F6 (15A) and F11 (20A) and replace them if necessary.</p>
<p>Check that there is a + 12 V battery feed on connection BP19 of the diagnostic socket. Check that there is an earth on connections MAM and NAM of the diagnostic socket.</p> <p>If the connection or connections are faulty and if there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring or replace it.</p>
<p>Check for a + 12 V supply on connection AP3. Check for earth on connection MG of the connector of component 1222.</p> <p>If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>Switch off the ignition, and disconnect the parking distance control computer to check the insulation, continuity and the absence of interference resistance on the following connections:</p> <ul style="list-style-type: none"> ● Connection code AP3 between components 1222 and 1016. ● Connection code MG between components 1222 and the MG earth. ● Connection code HK between components 1222 and 225. ● Connection code BP19 between components 225 and 1016. ● Connection code NAM between components 225 the earth NAM. ● Connection code MAN between components 225 and earth MAN. <p>If the connection or connections are faulty and there is a repair procedure (see Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair), repair the wiring, otherwise replace it.</p>
<p>If the fault is still present, contact Techline.</p>

AFTER REPAIR	Carry out a complete check using the diagnostic tool .
---------------------	---

ALP2	No buzzer
-------------	------------------

NOTES	Only investigate this customer complaint after a full check using the diagnostic tool (there must be no present or stored faults).
--------------	---



AFTER REPAIR	Check that the system is operating correctly.
---------------------	---

ALP2
CONTINUED 1

A

Using the **diagnostic tool** configuration reading screen, check the tone of the buzzer using configuration reading **LC006 "Buzzer tone"**.

Is the tone loud enough?

NO →

Change the tone of the buzzer using configuration **CF006 "Tone adjustment"**.

YES

Check the connection and condition of the connector on the buzzer.
Replace the connector if necessary.

Using the **diagnostic tool** parameter screen (**PR001 "Left-hand outer sensor distance"**, **PR002 "Left-hand inner sensor distance"**, **PR003 "Right-hand outer sensor distance"**, **PR004 "Right-hand inner sensor distance"**), check that the detection sensors are detecting obstacles (between **26** and **150 cm**).

Do these parameters display distance values (with an obstacle in front of the rear bumper)?

NO →

Apply the interpretation of parameters **PR001 "Left-hand outer sensor distance"**, **PR002 "Left-hand inner sensor distance"**, **PR003 "Right-hand outer sensor distance"**, **PR004 "Right-hand inner sensor distance"**

YES

B

AFTER REPAIR

Check that the system is operating correctly.

ALP2 CONTINUED 2	
-----------------------------------	--

(B)

YES

Place an obstacle in front of the rear bumper to make the tool display a distance reading. During the detection process, check that the buzzer has correct power supply by measuring between connections **151R** and **151S**.

During this test, is the buzzer receiving power?

YES

NO

Check the resistance value of the buzzer by measuring between these two connections. Replace the buzzer if its resistance is not approximately **48Ω**.

Is the fault still present?

YES

NO

Replace the buzzer.

Switch off the ignition, and disconnect the parking distance control computer to check the **insulation and continuity and the absence of interference resistance** on the following connections:
 Connection code **151R**,
 Connection code **151S**.
 Between components **1222** and **1223**.

If there is a repair procedure (See **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace the wiring.

Is the fault still present?

NO

YES

End of fault finding procedure.

Contact the Techline.

AFTER REPAIR	Check that the system is operating correctly.
---------------------	---

ALP3	Buzzer sounds continuously (no obstacle detected)
-------------	--

NOTES	Only investigate this customer complaint after a full check using the diagnostic tool (there must be no present or stored faults).
--------------	---


With no obstacle in front of the rear bumper (less than 150 cm away), check that the distance parameters on the diagnostic tool display **0 cm** for the “out of detection range” (**PR001 “Left-hand outer sensor distance”, PR002 “Left-hand inner sensor distance”, PR003 “Right-hand outer sensor distance”, PR004 “Right-hand inner sensor distance”**).

If the parameters display a setting even though there is no obstacle in front of the rear bumper, make sure nothing is interfering with the reading (sticker, mud, snow etc. on the rear bumper).

Repair if necessary.

WARNING


If heavy rain falls directly on to the head of the sensor (membrane), or if the sensor encounters certain noises (pneumatic drill/hammer), the sensor may pick up these vibrations/waves and this may lead to random beeps. Do not replace the sensor but inform the customer.



AFTER REPAIR	Check that the system is operating correctly.
---------------------	---

ALP4	buzzer sounds continuously (with caravan attachment)
-------------	---

NOTES	<p>Only investigate this customer complaint after a full check using the diagnostic tool (there must be no present or stored faults). Make sure it is a Renault caravan attachment.</p>
--------------	---



AFTER REPAIR	Check that the system is operating correctly.
---------------------	---