

CE

Notes for CE mark in the user manual are replaced by following notes.

These equipments are in conformity with essential requirements of Directive 1999/5/EC.

We declare the product is in conformity with the EMC directive above at nominal mains input 230V, 50 Hz although the rated input of the product is 200V-240V, 50/60Hz.

Model Name :

F139800 (Océ 3122)

Océ 3122

Addendum Fax

Addendum Océ 3122



Facsimile Manual

This document provides information which is new or has changed compared with the Océ 3121 manual.

Common remarks

- The G3 Fax Board-C1 is equipped with a standard 1 MB memory which can hold about 52 pages of A4-size documents. (This can be increased to approximately 240 pages by adding an optional 3 MB of memory and 628 pages by adding an optional 9 MB of memory).
- The fax error lamp flashes when a fax error occurs or when remaining memory falls below 10%.
- To cancel a time setting, press the number key for the preset time setting you wish to delete, then press the Clear key and then the [Ok] key.

New functions

Orientation and order in which received documents are printed Received documents are printed in the order they are received (initial setting). The documents are printed face up when the machine cannot make two-sided copies. The first page received is printed first, and subsequent received pages are output on top of the first page. To avoid having to rearrange received documents into page order later, change the settings to print documents starting from the last page received.

Machines equipped with the optional face-down output unit print received documents face down, the same as machines which can make two-sided copies. Received documents are printed in the order they are received. If you set the machine to print documents starting from the last page received, the time taken to complete printing will be longer than normal, as printing will not begin until all the transmitted pages have been received.

The documents are printed face down in the order in which the pages are received, when the machine can make two-sided copies.



Setting whether to print received documents in page order (Print in RX Order)

- 1 Press the arrow keys to display the 2/2 screen, then press the [Print in RX order] key.
- 2 Select the [On] or the [Off] key, then press the [Ok] key.
The display returns to Printer Settings screen 2/2.

Note: *This feature allows you to set whether documents are arranged in order before printing. The initial setting is 'Off'.*

Page 1-3, Redial: Redialing is not possible when you are using One-touch Speed Dialing, Coded Speed Dialing or Directory Dialing.

Page 2-6, step 4: Press the [Return] key.

Page 3-2, Notice: Because about 2.5mm at the top, bottom, left and right edges of the document cannot be read, this 2.5mm edge cannot be scanned to memory or sent.

Page 3-7, Notice in step 4: Memory sending is automatically selected when delayed transmission or sequential broadcast transmission is specified.

Page 3-11: The minimum original size is 128mm by 148mm.

The tray capacity is: A3 size: 15 (80g/m²)
A4/A5 size: 30 (80g/m²).

Request: Do not place documents that are larger than the maximum allowed size or smaller than the minimum allowed size. This could result in a paper jam or transmission error.

Page 3-22, Memo: Redialing is not possible when you are using One-touch Speed Dialing, Coded Speed Dialing or Directory Dialing.

Page 3-23, Memo: You cannot redial to parties that you dialed by One-touch Speed Dialing.

Page 3-25, Memo: You cannot redial to parties that you dialed by Directory Dialing.

Page 3-27, Memo: Direct Transmission cannot be used together with Sequential Broadcast. When Sequential Broadcast is set, transmission is carried out by memory transmission even if Direct Dialing is checked.
You cannot redial to parties that you dialed by Group Dialing.

Page 4-7, Notice: This feature can only be used when the original is placed on the RDF, it cannot be used when the originals are placed on the platen glass or ADF.

Page 4-19, step 1: Press the [Image Processing] key in the Special Features screen first.

Page 4-20: [Next] is the same button as [Continue].

Page 4-23, Notice: This feature can only be used when the original is placed on the RDF, it cannot be used when the originals are placed on the platen glass or ADF.

Page 5-3, step 3: The [Manual RX] key is new.
Select the receiving mode you want.

- To set Manual Reception: Press the [Manual RX] key.
Memo: Set Memory Lock and Transfer to Off if On. You cannot set Memory Lock or Transfer in Manual Reception.
- To set Automatic Reception: Press the [Auto RX] key.
Memo: When setting Memory Lock to On, set [Memory Lock Setting] in Custom Fax Settings to On beforehand.
When setting Transfer to On, set [Transfer Setting] in Custom Fax Settings beforehand.

Page 5-8: Available paper sizes for received documents:

A3-size originals: A3 -> A4* -> A4R*

A4-size originals: A4 -> A4R -> A5 x 2 -> A5R x 2 -> A3

A5-size originals: A5 -> A5R -> A4 -> A4R -> A3

Page 6-5, Memo: Transaction numbers 5001 to 9999 are for Polling Transmission.

Page 6-19: Documents displayed in the Details screen can be transferred by pressing the [Transfer] key.

Page 7-2, Memo: Polling receiving is possible when receiving a fax from any facsimile machine which has a subaddress feature, regardless of manufacturer. Polling receiving is also possible from a facsimile machine which does not have a subaddress feature (depending on the sending machine's settings).

Page 7-4, Memo: You can set the resolution, density, image quality, sender's name and you can edit originals before sending them.

Page 8-4, Memo: If you are sending to a fax that does not support sub-address or sending by Polling Transmission unconditionally to any party, use polling box No. 00. This special polling box is provided to enable polling without setting sub-address or passwords.

Page 9-2, Notice: Depending on your machine model, it is not necessary to set some of the items in Custom Fax settings. These items do not appear in the display. Also, it is not necessary to set some other items depending on which options have been installed on your machine. These are displayed as shaded items.

Page 9-13 Memo in step 4: Stored user content keys are displayed by pressing the [Special Features] and [Directory] keys in that order.

Page 9-14, step 3: To cancel the setting of a stored standard key, select the [No Settings] key.

Page 9-17, Notice: To prevent transmission to the wrong destinations, carefully look at the display to make sure that you are entering the correct number when registering telephone numbers for One-touch Speed Dialing, Coded Dialing, etc. After you have registered the telephone numbers, print out One-touch Speed Dialing Lists 1 and 2, Coded Speed Dial Lists 1 and 2 and Group Dialing List to check the numbers have been correctly registered. Be careful not to register the wrong telephone numbers by mistake. If a number has been incorrectly registered, the automatic redial function will repeatedly call the other party and greatly inconvenience them.

Page 9-48, Memo: Received documents are output after the error (e.g. Fax has run out of paper) is canceled.

Memo in step 2: When Memory RX is set to Off, and the Fax runs out of paper, the line becomes busy and further documents cannot be received.

Page 9-51, Step 1: Enter the System Settings password and press the [Ok] key if necessary.

Page 9-53, Memo and 9-54 Memo: The communications speed on a general telephone line may sometimes drop below 14400 bps depending on the line conditions.

Page 9-84, Memo in step 2: The initial setting is 'Off'.

Page 9-94, Table: Print in RX order: controls whether the documents are arranged in order before printing.

Page 9-97, Notice: When N on 1 log is set to 'On' the 'Off' setting of cassette selector switch B is disabled.

Page 9-100, Memo:

'Two-Sided Print' and 'N on 1 Log' cannot be used in combination. When these two features are set simultaneously, 'N on 1 Log' takes priority.

Page 9-101, Memo:

Even if the A3 drawer has paper when the A4 drawer is empty, sometimes the machine may not be able to print two A4-size documents on a single sheet of A3-size paper because the sending party's machine may not have the feature necessary to perform this operation (sending machine must have a paper orientation transmission rotation feature, the same as this machine). This applies for all paper sizes.

Page 10-4 (new): Received images are not printed out

- Make sure that the machine's receiving mode is not Memory Reception or Transfer.
- Make sure that there is paper in the machine.
- Make sure that one of cassette selection A, B, C or D is not Off.
Check this in the Basic Features screen. Change the mode to the Automatic Reception in the Special Features screen. (Received documents are sometimes not printed out in the Memory Reception or Transfer mode due to the setting.)

Page 11-15 (new): Memory Clear List

This machine has a function for automatically outputting a list of documents that have been cleared from memory. A Memory Clear List is output when the power is restored.

The Memory Clear List is not printed out if documents in memory are not cleared and are held in memory after a power interruption.

Note: *Make sure that the backup battery built into this machine is fully charged. To charge this battery, leave the machine's power on continuously for at least three days.*

If this battery is not fully charged, received documents may be cleared from memory within 24 hours of turning the machine's power off.

The Memory Clear List is not printed out if there is no paper in the machine after the power is restored.

Preface

Thank you for purchasing the Océ G3 FAX Board-C1. This manual describes the 3121 series, their FAX functions, and their method of use. It also describes the various precautions to be observed in order to ensure safe operation. Please read this manual thoroughly before operating the 3121 series in order to familiarise yourself with its capabilities, and to make the most of its many functions. After reading this manual, store it in a safe place for future reference.

▲ CAUTION

In this manual, CAUTION MESSAGES with this symbol indicate that neglecting the suggested procedure or practice could result in personal injury.

NOTICE:

Considerable effort has been made to ensure that this manual is free of inaccuracies and omissions. However, as we are constantly improving our products, some of the data contained herein may not exactly reflect the current model of the particular product with which this manual has been included. If you have a need for an exact specification, please contact Océ for the current specification

Copyright

Copyright © 1996 Océ, Inc. All Rights Reserved.



This CE Marking shows compliance of this equipment with Directive 73/23/EEC and Directive 89/336/EEC (as amended by Directive 92/31/EEC), both as amended by Directive 93/68/EEC.

L'estampille CE indique que ce matériel est conforme aux dispositions de la Directive 73/23/CEE et de la Directive 89/336/CEE (modifiée par la Directive 92/31/CEE), toutes deux modifiées par la Directive 93/68/CEE.

Diese CE-Markierung weist darauf hin, daß dieses Gerät mit Richtlinie 73/23/EWG und der durch Richtlinie 92/31/EWG geänderten Richtlinie 89/336/EWG übereinstimmt, die beide durch Richtlinie 93/68/EWG geändert wurden.

Denne CE-mærkning indikerer, at dette udstyr følger Direktiv 73/23/EU og Direktiv 89/336/EU (som udvidet med Direktiv 92/31/EU), begge som udvidet med Direktiv 93/68/EU.

CE Märkningen visar att denna utrustning följer direktiven 72/23/EEC och 89/336/EEC (komplement till 92/31/EEC) båda som komplement till direktiv 93/68/EEC.

CE merkintä osoittaa tämän tuotteen yhteensopivuuden direktiivien 73/23/EEC ja 89/336/EEC (täydennetty direktiivillä 92/31/EEC) kanssa, joita on täydennetty direktiivillä 93/68/EEC.

Dette CE merket viser at utstyret er i samsvar med EU direktivene 73/23 og 89/336 (med korreksjon av EU direktiv 92/31), begge med korreksjon av EU direktiv 93/68.

Deze CE markering toont aan dat het produkt in overeenstemming is met de richtlijnen 73/23/EEC en 89/336/EEC (zoals geammenteerd door richtlijn 92/31 EEC), welke beide zijn geammenteerd door de richtlijn 93/68/CEE.

Questo contrassegno CE indica che l'apparecchio è conforme alle Direttive CEE 73/23 e 89/336 (successivamente modificata con la Direttiva 92/31), entrambe modificate con la Direttiva 93/68.

Este símbolo CE indica que el equipo cumple con las Directivas 73/23/EEC y 89/336/EEC (según la enmienda a la Directiva 92/31/EEC), ambas según la enmienda de la Directiva 93/68/EEC.

Esta marca CEE indica que este equipamento está de acordo com as Directivas 73/23/EEC e 89/336/EEC (conforme emenda da directiva 92/31/EEC), ambas emendas da directiva 93/68/EEC.

Αυτή η CE σήμανση δηλώνει την συμφωνία της Συσκευής με την Οδηγία 72/23/ΕΕΚ και την Οδηγία 89/336/ΕΕΚ (όπως τροποποιήθηκαν από την Οδηγία 92/31/ΕΕΚ), όπως αμφότερες έχουν τροποποιηθεί από την Οδηγία 93/68/ΕΕΚ.

Oznaka CE prikazuje, da oprema ustreza predpisu 73/23/EEC, in kot to predpisuje predpis 93/68/EEC.

A CE jelzés tanúsítja, hogy a berendezés megfelel az EEC 92/31 és 93/68 előírásokkal módosított EEC 73/23 és 89/336 követelményrendszernek.

Oznaczenie CE jest potwierdzeniem zgodności niniejszego urządzenia z wymaganiami Dyrektywy 73/23/EEC oraz Dyrektywy 89/336/EEC (zgodnie ze zmianami Dyrektywy 92/31/EEC), obie uzupełnione przez Dyrektywę 93/68/EEC.

Značka CE indikuje, že toto zařízení odpovídá Směrnici 73/23/EEC a Směrnici 89/336/EEC (doplněné Směrnici 92/31/EEC), které byly dále doplněny Směrnici 93/68/EEC.

Käesolev CE-markeerimine näitab, et antud seade vastab Euroopa Liidu Direktiividele 73/23/EEC ja 89/336/EEC (koos muudatustega vastavalt Direktiivile 92/31/EEC) ning võttes arvesse, et mõlemaid direktiive on muudetud vastavalt Direktiivile 93/68/EEC.

CE marķējums norāda, ka šī iekārta atbilst prasībām, kas iekļautas EK direktīvās 73/23 un 89/336 (ar EK direktīvā 92/31 paredzētajām izmaiņām), kurās veikti labojumi saskaņā ar EK direktīvu 93/68.

Ženklas CE reiškia, kad šis įrenginys atitinka direktyvas 73/23/EEC ir 89/336/EEC (atlikus pataisas direktyva 92/31/EEC), kuriose buvo atliktos pataisos direktyva 93/68/EEC.

Маркировка CE указывает на то, что данное оборудование соответствует Директиве 73/23/ЕЕС и Директиве 89/336/ЕЕС (с изменениями в соответствии с Директивой 92/31/ЕЕС), с изменениями, предписываемыми Директивой 93/68/ЕЕС.

Fax III

NOTICE FOR CONNECTION TO TELECOMMUNICATION SYSTEMS IN THE UNITED KINGDOM

Approval Number 606862

Your Océ 3121/G3 FAX Board-C1 has been approved against the requirements of NTR3 for use in the UK and complies with the requirements of 91/263 EEC.

The CE mark is applied in respect of the requirements of 72/23 EEC and 89/336 EEC.

It is intended for connection to analogue two wire public telecommunication networks.



Connect the supplied cable to this socket first, then to the telephone line.

There are two auxiliary sockets to which equipment approved for direct connection to the network may be connected. If required, a suitable adaptor, approved under Approval Number NS/1056/3/V/606862 for direct and indirect connections between the fax machine and any piece of approved telecommunications apparatus, is available from your Océ supplier.

Voltage and current available at these sockets is determined by the network to which the line cable is connected. They will not normally exceed the limits for TNV as described in EN60950.

Océ recommend that any additional equipment connected in the installation is connected to one of these sockets. Do not connect additional equipment through parallel sockets elsewhere on the telephone line.

This equipment is not intended or recommended for making calls to emergency services.

Differences Between Facsimile Manual and Reference Manual

The 3121 series can be expanded to support non-copy functions such as FAX and printer functions. Accordingly, you are provided with a Reference Manual, and in addition to the Reference Manual and manuals for equipped functions, you are provided with a manual for each optional function your machine is equipped with.

Reference Manual: Describes operations common to all machines, such as how to turn the power ON, how to inspect and maintain machines, and how to set and use common functions.

Function related Manual: Describes how to use the copy, FAX and printer functions.

These manuals are designed so that you can easily use them to suit your particular needs. The descriptions of the machine's FAX functions are distributed between the Reference Manual and the Facsimile Manual as listed below. In addition, the back of this manual includes indexes that list the combined contents of the Reference Manual and Facsimile Manual.

This manual refers to transmission and reception as TX and RX, respectively.

Reference Manual

Cautions for ensuring safe use of the machine	(Chapter 1)
Names, functions, and specifications of parts of machine and options.....	(Chapter 1)
How to turn the power ON and OFF.....	(Chapter 2)
Clearing paper jams.....	(Chapter 5)
Loading paper (paper drawer, stack bypass) and adding toner	(Chapter 5)
Cleaning parts when copies appear dirty	(Chapter 5)
How to set common specifications for the following functions.....	(Chapter 3)
• Settings in the screen when power is turned ON	
• Setting on display by Initial function	
• Setting for different-size originals in RDF for purposes other than copy functions	
• Setting Automatic Exposure Adjustment	
• Setting the entry tone, error tone, and job complete tone	
• Setting whether or not each drawer is subject to Auto Drawer Switching	
• Setting paper size and icon for special cassettes	
• Setting on envelope cassettes	
• Setting the size entry screen	
• Selecting TRAY functions	
• Setting the printing order in copy, FAX, and printer operations	
• Setting the system setting password	
• Restricting FAX with control card users	
• Setting the Dept. ID for managing the number of prints by department	
• Returning Custom Common Settings to their defaults	
• Setting Auto Clear Time and Auto Sleep Time	
• Setting the current date and time	

Facsimile Manual




Names and functions of parts when using the FAX functions of the machine	(Chapter 1)
How to place originals	(Chapter 3)
How to send and receive using the modes in the Basic Features and Special Features screen	(Chapters 3 to 6)
How to use send and receive options	(Chapter 7)
How to set Custom FAX Settings for the following functions.....	(Chapter 9)
• Storing destinations for One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling	
• Setting the memory boxes	
• Setting standard keys for the FAX screen	
• Setting the Standard mode for the FAX screen	

Contents

PREFACE	1
Differences between Facsimile Manual and Reference Manual	3
Contents	4
How This Operator's Manual is Organised	9
How to Use This Operator's Manual	11
 Chapter 1 Before You Use the FAX Functions	 1-1
■ Parts and Their Functions	1-2
• Control Panel	1-2
• Touch Panel Display	1-3
• Basic Features Screen	1-3
• Special Features Screen	1-4
• FAX Monitor Screen.....	1-5
• Additional Function Screen.....	1-7
■ Control Panel Key Operations	1-8
• Control Panel	1-8
• Touch Panel Display	1-13
■ Settings to Store After Installing the Machine	1-15
• Selecting the Line Type	1-16
• Storing the User Telephone Number	1-18
• Storing the Company Name and Department Name (UNIT NAME)	1-20
• Setting the Date and Time	1-22
 Chapter 2 How to Use Basic FAX Functions	 2-1
■ The Flow of FAX Operations	2-2
• Sending Documents	2-2
• Cancelling a Transmission	2-5
• Direct Transmission	2-5
• To Cancel a Transmission While Scanning Documents:	2-5
• To Cancel Transmission of All Scanned Documents:.....	2-5
• Receiving Documents.....	2-7
• Automatic Receiving	2-7
■ Inserting the Control Card	2-8
• Operations Before Using FAX Functions.....	2-8
• Operations After Using FAX Functions.....	2-9
■ Entering the Dept. ID and Password	2-10
• Operations After Turning the Power ON.....	2-10
• Operations After Using FAX Functions.....	2-11
 Chapter 3 Sending Documents	 3-1
■ Sending Documents	3-2
• Memory Sending	3-3
• Direct Sending	3-6
■ Placing Originals	3-8
• Document Sizes Used When Sending.....	3-8
• Orientation of Originals.....	3-9
• Placing an Original on the Platen Glass	3-10
• Placing Originals in the ADF	3-11
• How Originals Feed Through the ADF	3-13
• Placing Originals in the RDF	3-14
• How Originals Feed through the RDF (when scanning one side of the original)	3-16
• How Originals Feed through the RDF (when scanning both sides of the document).....	3-17

■ Stamping Sent or Scanned Originals (STAMP)	3-18
■ Scanning Thin Sheet Originals (THIN SHEET ORIGINAL)	3-19
■ Specifying a Destination	3-20
• Specifying Destinations Using Number Keys	3-21
• Specifying the Last Destination Dialed Using Number Keys (REDIAL)	3-22
• Specifying with One-touch Speed Dialling (ONE-TOUCH).....	3-23
• Specifying with Coded Speed Dialling (CODED SPEED dialling)	3-24
• Specifying with Directory (DIRECTORY).....	3-25
■ Specifying Two or More Destinations (SEQUENTIAL BROADCAST)	3-27
• Repeatedly Specifying Destinations	3-27
• To Continue Specifying Destinations After Number Key Dialling	3-27
• To Continue Specifying Destinations After One-touch Speed Dialling, Coded Speed Dialling, or Redialling	3-28
• To Continue Specifying Destinations After Directory Dialling.....	3-29
• To Continue Specifying Destinations with Group Dialling	3-30
■ Setting Resolution, Density, and Image Quality to Match the Original (RESOL., DENSITY, IMAGE QUALITY)	3-31
■ Changing the Sender's Name (SENDER'S NAMES (TII))	3-33
 Chapter 4 Editing Documents Before Sending Them	4-1
■ Document Editing Modes	4-2
• Preparing to Use Document Editing Modes	4-3
■ Sending Facing-page Originals or Two-sided Originals (SCANNING MODE)	4-4
• Sending Facing-page Originals on Two Pages (TWO-PAGE SEPARATION)	4-5
• Sending Two-sided Originals on Two Pages (2→1-SIDED).....	4-7
■ Specifying the Original Scanning Size (DOCUMENT SIZE)	4-8
■ Sending Enlarged or Reduced Documents (ZOOM TRANSMITTING)	4-11
■ Sending Designated Areas of Originals and Originals with Shadows Erased (IMAGE PROCESSING)	4-14
• Erasing Shadows from Originals (ORIG. FRAME ERASE)	4-15
• Designating Areas of the Original (AREA DESIG.)	4-17
• Clearing Designated Areas (CLEAR AREA)	4-19
■ Checking Originals Before Sending Them (TEST PRINT)	4-21
■ Sending a Two-page Original as a Single Page (2 ON 1 TX)	4-23
 Chapter 5 Receiving Documents	5-1
■ Receiving Modes (RX MODE)	5-2
• Changing Receiving Modes.....	5-3
■ Receiving Documents	5-6
• Automatic Receiving.....	5-6
■ Printing Received Documents	5-8
• Paper on Which Received Documents are Printed	5-8
• Orientation and Order in Which Received Documents are Printed	5-8
 Chapter 6 Checking and Changing the Communications Status	6-1
■ Checking and Changing the Communications Status (FAX MONITOR)	6-2
• Displaying the FAX Monitor Screen.....	6-3
■ Checking and Changing the Status of Transmitted Documents (TX DOCUMENT)	6-5
• Canceling Transmission	6-6
• Printing a TX Reserve List.....	6-8
• Checking and Changing Detailed Information of Transmitted Documents	6-9
• Resending Failed Transmissions	6-11
• Changing the Destination of Transmitted Documents	6-12

• Changing the Document Transmission Time	6-14
■ Checking and Changing the Status of Received Documents (RX DOCUMENT)	6-15
• Deleting Received Documents from Memory	6-16
• Printing a DOC. Memory List	6-18
• Displaying the Details Screen to Check the Details of Received Documents	6-19
• Transferring Documents Received from Memory	6-20
■ Checking Communications Results (TX/RX RESULT)	6-22
• Checking the Details of Transmission Results	6-23
• Printing Activity Management Reports	6-24
 Chapter 7 Useful Communications Functions	7-1
■ Receiving Documents from a Remote FAX (POLLING RX)	7-2
■ Specifying the Time to Send a Document (DELAYED TX)	7-4
■ Using the Remote Control Features	7-6
■ Controlling your machine with Remote Control	7-6
■ Special Dialling	7-9
• Calling from an Extension	7-10
• Storing International Telephone Numbers	7-11
• Dialling with an Alternative Telephone Network	7-12
 Chapter 8 Communications Using the Memory Box and Subaddress	8-1
■ Communications Using the Memory Box	8-2
• What is a "Memory Box?"	8-2
• What Can the Memory Boxes Do?	8-3
• Using the Polling Box	8-4
• Using the Confidential Memory Box	8-5
• Using the Relay Memory Box	8-6
• Using the Batch Sending Memory Box	8-7
• Using the Bulletin Board Memory Box	8-8
■ Memory Box Operations (MEMORY BOX)	8-10
• Scanning Originals to a Memory Box	8-10
• Printing and Deleting Documents in the Memory Box	8-13
■ Communications Using the Subaddress (PSWD/SUBADDRESS)	8-16
• Sending Documents	8-16
• Receiving Documents	8-18
 Chapter 9 Storing and Setting Custom FAX Settings	9-1
■ What are "Additional Functions?"	9-2
• Calling Up the Custom FAX Settings Screen	9-2
• Items You Can Store and Set in the Custom FAX Settings Screen	9-3
■ Storing User Settings (USER SETTINGS)	9-5
• Calling up the User Settings Screen	9-6
• Storing Individual's Names (SENDER'S NAME (TTI))	9-7
• Assigning the Transmission Terminal ID (TX TERMINAL ID)	9-8
• Setting the Standard Density for Scanning Documents (DENSITY CONTROL)	9-10
• Setting the Dial Tone (AUDIBLE TONES)	9-10
• Adjusting the Monitor Volume (VOLUME CONTROL)	9-11
• Storing the Names of User Content Keys (SET DIRECTORY GENERAL CONTENTS)	9-12
• Setting Standard Keys 1 and 2 (STANDARD KEY SETTING)	9-14
• Changing the Standard Mode (STANDARD SETTINGS)	9-15
■ Storing Destinations (STORE DESTINATIONS)	9-17
• Calling up the Store Destinations Screen	9-18
• Storing One-touch Speed Dialling Destinations (ONE-TOUCH dialling)	9-19
• Storing Coded Speed Dialling Destinations (CODED dialling)	9-22
• Optional Settings for One-touch Speed Dialling and Coded Speed Dialling Functions	9-23
• Storing Group Dialling Destinations (GROUP dialling)	9-27
• Setting One-touch, Coded, and Directory Dialling Numbers to a Group	9-27
• Deleting One-touch Speed Dialling and Coded Speed Dialling Destinations Stored as a Group Set	9-31

• Deleting Group Dialling Sets	9-34
■ Setting Transmission Functions (TX SETTINGS)	9-35
• Calling Up the TX Settings Screen	9-36
• Setting Whether to Use ECM Transmission (ECM TX)	9-37
• Setting the Pause Time (PAUSE TIME)	9-38
• Automatic Redialling When the Other Party Is Busy (AUTO REDIAL)	9-39
• Setting Whether to Send Documents Going to the Same Destination by Dialling Once (BATCH TX)	9-41
• Setting Whether to Clear Failed Transmissions from Memory (ERASE FAILED TX)	9-41
• Setting Whether to Start Scanning Without Pressing the  (START) Key When Specifying the Destination (TIME OUT)	9-42
• Stamping Scanned or Sent Originals (STAMP DOCUMENT)	9-43
■ Setting Reception Functions (RX SETTINGS)	9-44
• Calling Up the RX Settings Screen	9-45
• Setting Whether to Use ECM Receiving to Automatically Compensate for Errors in Received Documents (ECM RX)	9-46
• Setting the Call Tone When in the Auto Receiving, Transfer, and Memory Lock Modes (INCOMING RING) ...	9-47
• Setting Memory Reception When Paper Runs Out (MEMORY RX)	9-48
• Setting Whether to Print Information on Received Documents (RX PAGE FOOTER)	9-49
■ System Management Settings (SYSTEM SETTINGS)	9-50
• Calling up the System Settings Screen	9-51
• Setting Whether to Restrict Transmission Terminals (RX RESTRICT)	9-52
• Setting the Transmission Start Speed When the Line is Defective (TX START SPEED)	9-53
• Setting the Reception Start Speed When the Line is Defective (RX START SPEED)	9-54
• Setting Whether to Enable the Use of the Remote Control Feature (REMOTE CONTROL)	9-55
• Setting the Receiving Password (RX PASSWORD)	9-56
•  SW Setting ( SW Setting)	9-57
• Selecting the R-key Setting (R-KEY SETTING)	9-58
• Selecting the M-key Setting (M-KEY SETTING) (UK only)	9-59
■ File Settings (FILE SETTINGS)	9-60
• Calling up the File Settings Screen	9-61
• Storing Polling, Confidential, Relay, Batch Sending, Bulletin Board, and General Memory Boxes (MEMORY BOX STORE/SET)	9-62
• Setting the Polling Memory Box	9-63
• Setting the Confidential Memory Box	9-65
• Setting the Relay Memory Box	9-67
• Setting the Batch Sending Memory Box	9-71
• Setting the Bulletin Board Memory Box	9-73
• Setting the General Memory Box	9-76
• Setting Periodical Polling Reception (PRESET POLLING SETTING)	9-84
• Transferring Received Documents (TRANSFER SETTING)	9-86
• Saving Received Documents to Memory (MEMORY LOCK SETTING)	9-90
■ Printer Settings (PRINTER SETTINGS)	9-94
• Calling up the Printer Settings Screen	9-95
• Setting the Number of Received Documents to Print (# OF RX COPIES)	9-96
• Setting Alternate Paper Cassettes (SELECT CASSETTE)	9-97
• Setting Whether to Print Received Documents at a Reduced Size (RX REDUCTION)	9-98
• Setting Whether to Print Received Documents on Both Sides of the Paper (TWO-SIDED PRINT)	9-100
• Setting Whether to Print Two or More Received Documents on Single Sheets of Paper (N ON 1 LOG)	9-101
■ Printing Reports (REPORT SETTINGS)	9-102
• Calling up the Report Settings Screen	9-103
• Setting Printing of TX Reports (TX REPORT)	9-104
• Setting Printing of RX Reports (RX REPORT)	9-105

• Setting Printing of Memory Box Reports (MEMORY BOX REPORT)	9-106
• Setting Printing of Activity Reports (ACTIVITY REPORT)	9-107
■ Printing Lists (PRINT LIST)	9-109
• Calling up the Print List Screen	9-110
• 1-TOUCH SPEED DIAL LIST 1	9-111
• 1-TOUCH SPEED DIAL LIST 2	9-112
• CODED SPEED DIAL LIST 1	9-112
• CODED SPEED DIAL LIST 2	9-112
• GROUP DIAL LIST	9-113
• USER'S DATA LIST	9-113
Chapter 10 Troubleshooting	10-1
■ Troubleshooting	10-2
• Trouble Sending Documents	10-2
• Trouble Receiving Documents	10-4
• Other Problems	10-5
■ Service Call Message	10-6
■ Error Messages	10-7
■ Questions & Answers	10-8
Chapter 11 Appendix	11-1
■ Activity Management Reports and Lists	11-2
• Checking the Communications Status with Activity Management Reports	11-2
• Printing Lists	11-7
■ Main Specifications	11-16
■ Index	11-17


How This Operator's Manual is Organised

<p>Chapter 1 Before You Use the FAX Functions This chapter describes some things you should be familiar with before using the machine's FAX functions, such as names and functions of the machine's parts, and settings to store after installing the machine.</p>	<ul style="list-style-type: none"> • Parts and Their Functions • Control Panel Key Operations • Settings to Store After Installing the Machine
<p>Chapter 2 How to Use Basic FAX Functions This chapter shows basic ways of sending and receiving faxes, and how to cancel transmissions. If you haven't used the machine's FAX functions before, you should read this chapter to understand these functions fully.</p>	<ul style="list-style-type: none"> • The Flow of FAX Operations • Inserting the Control Card • Entering the Dept. ID and Password
<p>Chapter 3 Sending Documents This chapter explains in detail how to send originals after placing them in the machine, and how originals are fed into the machine when it is equipped with the ADF and RDF.</p>	<ul style="list-style-type: none"> • Sending Documents • Placing Originals • Stamping Sent or Scanned Originals (STAMP) • Scanning Thin Sheet Originals (THIN SHEET ORIGINAL) • Specifying a Destination • Specifying Two or More Destinations (SEQUENTIAL BROADCAST) • Setting Resolution, Density, and Image Quality to Match the Original (RESOL., DENSITY, IMAGE QUALITY) • Changing the Sender's Name (SENDER'S NAMES (TTI))
<p>Chapter 4 Editing Documents Before Sending Them This chapter tells how to send facing-page originals (such as magazines or bound books) or two-sided documents, and how to send designated areas of the originals.</p>	<ul style="list-style-type: none"> • Document Editing Modes • Sending Facing-page Originals or Two-sided Originals (SCANNING MODE) • Specifying the Original Scanning Size (DOCUMENT SIZE) • Sending Enlarged or Reduced Documents (ZOOM TRANSMITTING) • Sending Designated Areas of Originals and Originals with Shadows Erased (IMAGE PROCESSING) • Checking Originals Before Sending Them (TEST PRINT) • Sending a Two-page Original as a Single Page (2 ON 1 TX)
<p>Chapter 5 Receiving Documents This chapter describes reception modes, including Automatic Reception which requires no special operations. However, if you want to use any of the machine's other receiving modes, you should read this chapter.</p>	<ul style="list-style-type: none"> • Receiving Modes (RX MODE) • Receiving Documents • Printing Received Documents
<p>Chapter 6 Checking and Changing the Communications Status This chapter describes modes used for checking the status of transmitted or received documents, and the mode used for checking transmission or reception results.</p>	<ul style="list-style-type: none"> • Checking and Changing the Communications Status (FAX MONITOR) • Checking and Changing the Status of Transmitted Documents (TX DOCUMENT) • Checking and Changing the Status of Received Documents (RX DOCUMENT) • Checking Communications Results (TX/RX RESULT)
<p>Chapter 7 Useful Communications Functions This chapter describes useful communications functions, such as delayed transmission and polling receiving.</p>	<ul style="list-style-type: none"> • Receiving Documents from a Remote FAX (POLLING RX) • Specifying the Time to Send a Document (DELAYED TX) • Using the Remote Control Features • Special Dialling

<p>Chapter 8 Communications Using the Memory Box and Subaddress</p> <p>This chapter explains how to transmit or receive documents using the memory boxes and a password/subaddress in Special Features mode.</p>	<ul style="list-style-type: none"> • Communications Using the Memory Box • Memory Box Operations (MEMORY BOX) • Communications Using the Subaddress (PSWD/SUBADDRESS)
<p>Chapter 9 Storing and Setting Custom FAX Settings</p> <p>This chapter shows how to change the machine's default FAX settings to suit your specific needs.</p>	<ul style="list-style-type: none"> • What are "Additional Functions?" • Storing User Settings (USER SETTINGS) • Storing Destinations (STORE DESTINATIONS) • Setting Transmission Functions (TX SETTINGS) • Setting Reception Functions (RX SETTINGS) • System Management Settings (SYSTEM SETTINGS) • File Settings (FILE SETTINGS) • Printer Settings (PRINTER SETTINGS) • Printing Reports (REPORT SETTINGS) • Printing Lists (PRINT LIST)
<p>Chapter 10 Troubleshooting</p> <p>This chapter tells what to do when a self-diagnostic (error) message or service-call message appears in the touch panel display.</p>	<ul style="list-style-type: none"> • Troubleshooting • Service Call Message • Error Messages • Questions & Answers
<p>Chapter 11 Appendix</p> <p>This chapter provides additional information useful for operating this machine, including samples of Activity Management Reports and lists, specifications, and indexes.</p>	<ul style="list-style-type: none"> • Activity Management Reports and Lists • Main Specifications • Index

■ Parts and Their Functions	2
■ Control Panel Key Operations	8
■ Settings to Store After Installing the Machine	15


This chapter gives information you should understand and be familiar with before you use the machine's FAX functions. This information includes the names and functions of the machine's parts, and the settings you'll need to store after installing the machine.



Parts and Their Functions


This section describes the names and functions of the parts on the control panel that you will use with this machine's FAX functions.


Control Panel



Touch Panel Display

Basic Features Screen

When you press the  key on the control panel, the Basic Features screen appears in the touch panel display. When READY TO SEND appears in this screen (the machine is then in Standby mode), you can send documents in the usual way. The Basic Features screen also lets you check the machine's communications status when sending or receiving faxes.



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

Special Features Screen

When you press the [SPECIAL FEATURES] key in the FAX Basic Features screen, the Special Features screen appears in the touch panel display, and shows the machine's Special Feature modes. When you select a Special Feature mode, a more detailed screen for that mode appears in the touch panel display. To close the Special Features screen and return to the Basic Features screen, press the [DONE] key.

■ When the Machine is Equipped with the RDF

<p>[DELAYED TX] Press to send a document at a specified time. (See p. 7-4.)</p>	<p>[POLLING RX] Press to receive a document from a remote FAX by operating your FAX. (See p. 7-2.)</p>	<p>[DIRECTORY] Press to dial a destination telephone number stored in the directory. You can also search for destinations in alphabetical order. (See p. 3-25.)</p>
<p>[MEMORY BOX] Press to scan originals into a memory box, or to print or erase documents from a memory box. (See p. 8-2.)</p>		
<p>[PSWD/SUBADDRESS] Press to send or receive faxes to or from another FAX machine using a subaddress and a password conforming to ITU-T specifications. (See p. 8-16.)</p>	<p>[SCANNING MODE] Press to send facing pages in bound or two-sided documents. (See p. 4-4.)</p>	<p>[SENDER'S NAMES (TTI)] Press to send a original with the sender's name printed at the top of the document instead of the unit name. (See p. 3-33.)</p>
<p>[IMAGE PROCESSING] Press to designate specific areas of the documents to send, or to eliminate shadows from around images in the documents. (See p. 4-14.)</p>	<p>[ZOOM TX] Press to send enlarged or reduced scanned documents. (See p. 4-11.)</p>	<p>[RX MODE] Press to select a receiving mode. (See p. 5-2.)</p>
	<p>[2 ON 1 TX] Press to send two originals on a single page. (See p. 4-23.)</p>	<p>[TEST PRINT] Press to see how the document will look when it is sent. (See p. 4-21.)</p>
		<p>[DOCUMENT SIZE] Press to specify the size of the document to be scanned. (See p. 4-8.)</p>

■ When the Machine is Not Equipped with the RDF

When the machine is not equipped with the RDF, the [SCANNING MODE] key changes to the [TWO-PAGE SEPARATION] key. When it is equipped with the ADF, the [2 ON 1 TX] key changes to the [THIN SHEET ORIGINAL] key. For details on the other Modes, see the description for when the RDF is attached.

<p>[TWO-PAGE SEPARATION] Press to send facing pages or other bound originals on two pages. (See page 4-5.)</p>		<p>[THIN SHEET ORIGINAL] Press to send thin sheet originals such as invoices. (See page 3-19.)</p>
---	--	---


FAX Monitor Screen

When you press the [FAX MONITOR] key in the Basic Features screen, the FAX Monitor screen scrolls down the touch panel display. This screen displays three lists (TX DOCUMENT, RX DOCUMENT, and TX/RX RESULT) that you can use to check the machine's communications status, and communication results of documents.


MEMO

- The [FAX MONITOR] key appears even if other functions such as copy are being used. You can display the FAX Monitor screen by pressing the [FAX MONITOR] key.


■ TX Document Screen




■ RX Document Screen



■ TX/RX Result Screen




Additional Function Screen

When you press the  (ADDITIONAL FUNCTION) key, the Additional Function screen appears in the touch panel display. From this screen you can make settings used by all functions of the machine, as well as specific settings for individual functions. You can also use the [CUSTOM FAX SETTINGS] key to store destination FAX numbers or the sender's name, and to change FAX default settings such as the reception mode.

MEMO


- For details on how to set Custom FAX settings, see the following manuals:
 - Facsimile Manual* : Chapter 9, "Storing and Setting Custom FAX Settings"
 - Copying Manual* : Chapter 8, "Custom Settings"
 - Reference Manual* : Chapter 3, "Setting and Adjusting Custom Common Settings for Each Function"

Additional Function Screen



[CUSTOM FAX SETTINGS]

Custom FAX Settings Screen



1

2

3

4

5

6

7

8

9

10


11

Control Panel Key Operations


Keying operations involve operating keys on the control panel and in the touch panel display.

Control Panel


The following describes the control panel keys you will use with the FAX functions.








- **Number keys**
Press these keys when entering destination FAX numbers, or when entering the ID number.







Example:
The FAX number of the destination you are dialing.



-  (RESET) key
Press this key to cancel settings in the FAX mode. When you press the  (RESET) key, the display returns to the Basic Features screen, all FAX settings that were preset or being set are cancelled, and the machine returns to standard settings.




- FAX key
Press this key to use the machine's FAX functions. (The green lamp lights to show that FAX functions are selected.)






- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

- **(*) (ADDITIONAL FUNCTION) key**
Press this key to set FAX specifications. Pressing this key again returns the display to the FAX screen. (See Chapter 9, "Storing and Setting Custom FAX Settings.")




Example:






- **(?) (GUIDE) key**
Press this key to display the Usage Guide screen or Information Guide screen in the touch panel display.


The Usage Guide screen appears when you press the (?) (GUIDE) key while the Basic Features screen or Special Features screen is displayed. The Feature Guide screen appears when you press the (?) (GUIDE) key while selecting a mode.




Example 1:
If you press the (?) (GUIDE) key while setting Delayed Transmission, the Information Guide screen for Delayed Transmission appears.




Example 2:
If you press the **?** (GUIDE) key while the Basic Features screen is displayed, the screen shown at the right appears in the touch panel display.




- **©** (CLEAR) key
Use this key to clear characters or numbers you've entered.




Example:
Clear the sender's name that you entered.




- **⏻** (START) key
Press this key to start scanning documents.




-  (STOP)key
Press this key to stop scanning originals.

MEMO

- You cannot stop reception of FAX documents.



- One-touch Speed Dialling keys
Use these keys when dialling destinations stored in One-touch Speed Dialling keys.




Touch Panel Display

The following describes keys and icons that appear in the touch panel display.

NOTICE

- Press the touch panel display lightly with the tip of your finger. Do not use pointed items such as mechanical pencils or ball-point pens, as they may scratch or damage the display.



1

2

3

4

5

6

7

8

9

10


11

Mode key: Press this key to select a mode. (The key then becomes highlighted.) When particular modes cannot be used because of the machine's status or settings, those modes appear lightly dimmed in the display.

- Modes that cannot be used in combination with modes already selected are lightly dimmed.

Example:


When the 2 On 1 mode is specified, the Scanning mode is lightly dimmed.



- Modes that are unavailable because of the machine's model or equipment options are not displayed.

Example:

If your machine is not equipped with the RDF, 2 On 1 is not displayed.



Settings to Store After Installing the Machine

After you've installed your machine, you must store the following settings in it before using it.

■ Line type (See p. 1-16.)

This is the type of telephone line connected to the machine: a rotary dial telephone (rotary pulse) line or a touch-tone telephone (touch tone) line.

■ Sender information


When you send a FAX, your machine prints your name, telephone number, and other information on the recording paper output from the receiving FAX. This allows the other party to see immediately who sent the document. This information is called "sender information," and includes the following:

- **Date and time**
The date and time that the document was sent. (See "Setting the Date and Time," on p. 1-22.)
- **Telephone number**
Your machine's telephone number. (See "Storing the User Telephone Number," on p. 1-18.)
- **Sender's name (TTI)**
The sender's name and the unit name (your company's name or department's name). (See "Storing the Company Name and Department Name," on p. 1-20, and "Storing Individual's Names," on p. 9-7.)
- **Destination name**
The name of the destination, stored when using One-touch Speed Dialling or Coded Speed Dialling. (See "Storing Destinations," on p. 9-17.)
- **Page number**

MEMO

- You can send documents even if you haven't stored your sender information.
- You can also disable the printing of the sender information. (See "Storing Sender Information," on p. 9-8.)

When documents are sent, the stored sender information is printed in the following format on the recording paper output from the receiving FAX. (Some FAX models also display all sender information during transmission.)



MEMO

- If you store the sender's name, it will appear in the sender information instead of the unit name.
- The receiving party's name is printed when you've stored that name for One-touch Speed Dialling or Coded Speed Dialling.


NOTICE

- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- Be sure to read this chapter before storing settings after installing the machine, and before using the machine's FAX functions.


Selecting the Line Type

Store the type of telephone line (pulse or tone) connected to your machine.


- 1** Press the  (ADDITIONAL FUNCTION) key.



- 2** The Additional Function screen appears.
Press the [CUSTOM FAX SETTINGS] key.



- 3** The Custom FAX Settings screen appears in the touch panel display.
Press the [USER SETTINGS] key.




4

The User Setting screen appears in the touch panel display.

Press the [▼] or [▲] keys to display the 2/4 screen, then press the [TEL LINE TYPE] key.

MEMO

- The User Setting screen is made up of four screens (1/4 to 4/4). Press the [▼] or [▲] keys to display particular screens and make the required settings.



5

Select the telephone line type.


■ **When using a rotary pulse line:**

Press the [ROTARY PULSE] key, then press the [OK] key.


■ **When using a push-phone line:**

Press the [TOUCH TONE] key, then press the [OK] key.

The line type is stored, and the display returns to that shown in step 4.



6

Press the  key to return to the Standard FAX screen.

1

2

3

4

5

6

7

8

9


10

11


Storing the User Telephone Number

Store the machine's telephone number.
When you FAX a document, the receiving FAX machine includes the stored user telephone number in the sender information it prints on the FAX. Some FAX models also display sender information during transmission.


- 1 Press the  (ADDITIONAL FUNCTION) key



- 2 The Additional Function screen appears.
Press the [CUSTOM FAX SETTINGS] key.




- 3 The Custom FAX Settings screen appears in the touch panel display.
Press the [USER SETTINGS] key.



- 4 The User Setting screen appears in the touch panel display.
Press the [▼] or [▲] keys to display the 1/4 screen, then press the [UNIT TELEPHONE #] key.

MEMO

- The User Setting screen is made up of four screens (1/4 to 4/4). Press the [▼] or [▲] keys to display particular screens and make the required settings.




5

Enter the destination telephone number with the Number keys, then press the [OK] key.


MEMO

- The telephone number can have up to 20 digits.
- When entering a space after the exchange number, press the [SPACE] key. (Spaces can be omitted, however.)
- If you make a mistake when entering the telephone number, press the [BACK SPACE] key to delete the number, then enter the correct number again.

The unit telephone number is stored, and the display returns to that shown in step 4.



6

Press the  key to return to the Standard FAX screen.

1

2

3

4

5

6

7

8

9

10

11


Storing the Company Name and Department Name (UNIT NAME)

Store the company name and department name.

When you FAX a document, the receiving FAX machine includes the stored company name and department name in the sender information it prints on the FAX. Some FAX models also display sender information during transmission.

1


Press the  (ADDITIONAL FUNCTION) key.



2

The Additional Function screen appears.


Press the [CUSTOM FAX SETTINGS] key.



3

The Custom FAX Settings screen appears in the touch panel display.

Press the [USER SETTINGS] key.



4

The User Setting screen appears in the touch panel display.

Press the [▼] or [▲] keys to display the 1/4 screen, then press the [UNIT NAME] key.

MEMO

- The User Setting screen is made up of four screens (1/4 to 4/4). Press the [▼] or [▲] keys to display particular screens and make the required settings.

5


Enter the name, then press the [OK] key.

MEMO

- For details on how to enter letters, see "Entering Letters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- You can enter up to 24 characters in the Upper/Lower Case English and Symbol modes.
- If you make a mistake when entering the unit name, press the [BACK SPACE] key to delete the unit name, then enter the correct number again.

The unit name is stored, and the display returns to that shown in step 4.

6

Press the  key to return to the Standard FAX screen.

1

2

3

4

5

6

7

8

9


10

11


Setting the Date and Time

Set the current date and time. When you FAX a document, the receiving machine includes the current date and time in the sender information it prints on the FAX.

- 1** Press the  (ADDITIONAL FUNCTION) key.




- 2** The Additional Function screen appears.
Press the [TIMER SETTINGS] key.



- 3** The Timer Settings screen appears.
Press the [▼] or [▲] keys to display the 1/2 screen, then press the [DATE & TIME SETTINGS] key.

MEMO

- The Timer Setting screen is made up of two screens (1/2 to 2/2). Press the [▼] or [▲] keys to display particular screens and make the required settings.




4

Enter the current year, date, and time with the Number keys, then press the [OK] key.
Enter two digits for the year, followed by two-digit numbers for the date and time.


MEMO

- The time must be in the range of 00:00 to 23:59.
Example: For 3:01 p.m., enter "1501".

The display then returns to that shown in step 3.



5

Press the  key to return to the Standard FAX screen.

1

2

3

4

5

6

7

8

9


10

11

Chapter 2 How to Use Basic FAX Functions

■ The Flow of FAX Operations	2
■ Inserting the Control Card	8
■ Entering the Dept. ID and Password	10

This chapter describes basic ways of sending and receiving documents by FAX. It also tells how to cancel a transmission. If you haven't used the machine's FAX functions yet, be sure to read this chapter to fully understand them before using them.



The Flow of FAX Operations


This section describes the “flow” of basic FAX operations. It explains how to use the machine’s basic features, shows where related items are described in this manual, and describes the machine’s overall functions.


MEMO

- For details on the following items, see the following items in the *Reference Manual*:
 - “Turning the Power ON/OFF” on p. 2-2
 - “Loading Paper and Adding Toner” on p. 5-2
 - Chapter 4, “Clearing Paper Jams”

Sending Documents

1

Press the  key.




2

Insert a Control Card.

(See “Inserting the Control Card,” on p. 2-8.)

MEMO

- This step is not required if you aren’t using the optional Control Card V.
- This step is also not required if users are not restricted by the Control Card. (See “Restricting Facsimile Control Card Users,” on p. 3-19 in the *Reference Manual*.)




3

Enter the Dept. ID and password, then press the [OK] key.

(See “Entering the Dept. ID and Password,” on p. 2-10.)

MEMO

- This step is not required if you are not using Dept. ID Management.




4

Place the original in the machine.

(See "Placing Originals," on p. 3-8.)

MEMO

- You can also stamp originals fed by the ADF or RDF. (See "Stamping Sent or Scanned Originals," on p. 3-18.)




5

Set the mode in the Basic Features screen or Special Features screen.

MEMO

- You can set the resolution, density, and image quality to match that of the document. (See "Setting Resolution, Density, and Image Quality to Match the Original," on p. 3-31.)
- You can store the unit name (see "Storing the Company Name and Department Name," on p. 1-20) and sender's name (see "Changing the Sender's Name," on p. 3-35) so they will print at the top of the received FAX.
- You can edit the documents to be sent by FAX using various modes. (See Chapters 3, 4, 7, and 8.)
- You can set the machine to send a FAX at a later time. (See "Specifying the Time to Send a Document," on p. 7-4.)


Basic Features screen



[SPECIAL
FEATURES]

[DONE]

Special Features screen




6


Specify the destination.

MEMO

- Specify the destination by dialling with the Number keys, or by using Redialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling. (See "Specifying a Destination," on p. 3-20.)




7

Press the  (START) key.

MEMO

- Normally, documents to be sent are scanned into memory, then sent from memory. However, you can also use the [DIRECT] key to FAX documents directly without first storing them in memory. (See "Direct Sending," on p. 3-6.)
- When you are scanning documents on the platen glass, make sure you have scanned all the documents before pressing the [DONE] key.




8

When you've finished, press the [ID] key at the top right of the touch panel display.

MEMO

- This step is not required if you are not using Dept. ID Management. (See "Custom Common Settings," on p. 3-3 in the *Reference Manual*.)




9

Remove the Control Card.

MEMO

- This step is not required if you are not using the optional Control Card V.



Cancelling a Transmission

How you send documents depends on whether you are sending them from memory, or directly without being scanned to memory.

MEMO

- For details on settings and how to send documents, see “Checking and Changing the Communications Status,” on p. 6-2, and “Sending Documents,” on p. 3-2.)

Direct Transmission


- 1 Press the  (STOP) key.

This cancels any scanning or transmission that may be under way. You can also cancel transmission by pressing the [CANCEL] key in the touch panel display.


MEMO

- When you send documents in Direct Transmission mode, the documents are scanned and sent one by one. This means that if you cancel a transmission, the previous document will already have been sent.

To Cancel a Transmission While Scanning Documents:

- 2 Press the  (STOP) key.

This cancels the transmission.
You can also cancel a transmission by pressing the [CANCEL] key in the touch panel display.




To Cancel Transmission of All Scanned Documents:

- 3 Press the [FAX MONITOR] key.

A list of the documents that have been transmitted appears.

MEMO

- You can also use the [FAX MONITOR] key when using non-FAX functions.



2

Press the [▼] or [▲] keys to display the document you want to cancel, then select that document in the touch panel display.

Sending.		Avail. Memory 88%	
1/ 17			
8:45 SALES DEPT.	1225	Delayed	
8:45 Public Relation	1034	Delayed	
9:28 5164886700	1252	Waiting	
9:36 Legal Div.	1253	Waiting	
10:16 8 7448500	1254	Waiting	
10:24 SO BDC 7 UNITS	1255	Waiting	

Touch an item

PRINT LIST

TX DOCUMENT RX DOCUMENT TX/RX RESULT

3

Press the [CANCEL] key.

Sending.		Avail. Memory 88%	
1/ 17			
8:45 Montreal Office	1225	Delayed	
8:45 Public Relation	1034	Delayed	
9:28 5164886700	1252	Waiting	
9:36 SALES DEPT.	1253	Waiting	
10:16 8 7448500	1254	Waiting	
10:24 SO BDC 7 UNITS	1255	Waiting	

Touch an item

PRINT LIST

TX DOCUMENT RX DOCUMENT TX/RX RESULT

4

Press the [YES] key.

The transmission is cancelled.

MEMO

- If you cancel the transmission of a document that was already scanned, that document is treated as a failed transmission. The machine's default settings cause it to clear from memory all documents that fail transmission. However, you can change the defaults so that those documents are not cleared from memory. (See "Setting Whether to Clear Failed Transmissions from Memory," on p. 9-41.)
If you set the machine so that it doesn't clear failed transmitted documents, these documents will remain in memory and be displayed in the TX Document List. You can then change the document's destination (see "Changing the Destination of Transmitted Documents," on p. 6-12), and re-send it (see "Resending Failed Transmissions," on p. 6-11).
- For details on canceling sequentially broadcast documents, see "Canceling Transmissions," on p. 6-6.

Sending.		Avail. Memory 88%	
1/ 17			
TX/RX NO. : 1034			
DSTN: Public Relation			
Cancel TX?			
YES NO			

PRINT LIST

TX DOCUMENT RX DOCUMENT TX/RX RESULT

Receiving Documents

The machine has three receiving (RX) modes: Automatic Receiving, Memory Lock, and Transfer. This section describes how the machine operates in Automatic Reception mode.

MEMO

- For details on receiving modes, see the following:
 - Reception modes: see “About Reception Modes,” on p. 5-2.
 - Changing Receiving modes: see “Changing Receiving Modes,” on p. 5-3.
 - Reception mode defaults: see “Setting Reception Functions,” on p. 9-44.
 - Transfer: see “Transferring Documents Received from Memory” on p. 6-20.

Automatic Receiving

MEMO


- For information on changing reception modes, see “Changing Receiving Modes,” on p. 5-3.

1

When a document is being received, the FAX Status lamp on the control panel flashes.

MEMO

- When the machine is in Sleep mode, the call tone sounds for about two seconds when the FAX first begins to be received, even if “INCOMING RING” is set to “NO”.




2

When the document is completely received, the FAX Status lamp lights, showing that a document is stored in memory.

MEMO

- The FAX Status lamp lights or flashes even if the machine is in Sleep mode.



3

The machine prints the document on copy paper.

MEMO

- If the machine runs out of paper, the received document remains in memory until more paper is added. (See “Setting Memory Reception When Paper Runs Out,” on p. 9-48.) The G3 FAX Board-C1 is equipped with a standard 1 MB memory which can hold about 52 pages* of A4-size documents. (This can be increased to approximately 244 pages* by adding an optional 3 MB of memory and 628 pages* by adding an optional 9 MB of memory.)

*Based on the CCITT No. 1 Chart, standard setting.

- Documents received into memory print automatically when copy paper is loaded in the drawer.

Inserting the Control Card


If your machine is equipped with the optional Control Card V, you must insert the card before making copies.

MEMO

- If the display shown in step 3 below does not appear in the touch panel display even though the control card is inserted, check the following:
 - Make sure the control card is inserted in the correct direction.
 - Make sure the control card is inserted as far as it can go.
 - Make sure that the control card is not damaged, has not exceeded its set limit, and does not have restricted use.)
- For details on using the control card, see the *Control Card Instruction Manual*.


Operations Before Using FAX Functions

1

Press the  key. The screen on the right appears.


MEMO

- For details on turning the power ON, see "Turning the Power ON," on p. 2-2 in the *Reference Manual*.




2

Insert the control card into the card slot. Be sure it faces the correct direction.



3

The Basic Features screen appears in the touch panel display,



Operations After Using FAX Functions


1

When you've finished using the FAX functions, remove the control card from the machine.

The touch panel display shows the screen for inserting the control card.

NOTICE

- After removing the control card, you must insert it again to be able to send documents by FAX.



1

2

3

4

5

6

7

8

9


10

11

Entering the Dept. ID and Password


If you set the machine to use Dept. ID Management (see “Setting the Dept. ID for Managing the Number of Prints by Department,” on p. 3-20 in the *Reference Manual*), you will need to enter the department ID and password before you can use FAX functions.

MEMO

- If you press the  key when the control card is in use, the message PLEASE INSERT A CONTROL CARD appears in the touch panel display. (See “Inserting the Control Card,” on p. 2-8.)


Operations After Turning the Power ON

1

Press the  key. The screen on the right appears.

MEMO

- For the steps to follow while the machine is warming up after turning the power ON, see “Turning the Power ON/OFF,” on p. 2-2 in the *Reference Manual*.



Enter Dept.ID and password.

DEPT. ID []

PASSWORD []

Once operation is finished,
press the ID key
(in the upper right corner).


OK


FAX MONITOR

2

Press the [DEPT. ID] key, and enter the department ID.

MEMO

- Enter the four-digit department ID with the Number keys.
- If you make a mistake when entering values, press the  (CLEAR) key, and enter the values again.



Enter Dept.ID and password.

DEPT. ID [1234]

PASSWORD []

Once operation is finished,
press the ID key
(in the upper right corner).


OK


FAX MONITOR

3

Press the [PASSWORD] key, then enter the password with the Number keys.

MEMO

- Enter the four-digit password with the Number keys.
- If you make a mistake when entering the password, press the  (CLEAR) key, and enter the password again.
- If no password has been set, proceed to step 4.



Enter Dept.ID and password.

DEPT. ID [1234]

PASSWORD [****]

Once operation is finished,
press the ID key
(in the upper right corner).

OK


FAX MONITOR

4

Press the [OK] key.

The FAX Basic Features screen appears in the touch panel display.

If you make a mistake when entering the department code and ID, the message enter dept. "THIS NUMBER HAS NOT BEEN STORED. ENTER THE NUMBER AGAIN." appears in the touch panel display. If this happens, repeat this procedure beginning with step 2.



Operations After Using FAX Functions


1

When you've finished using the FAX functions, press the [ID] key at the top right of the touch panel display.

The display for entering the department ID and password appears. To return to the FAX functions, enter the department ID and password again.

MEMO

- After finishing with FAX functions, if you forget to press the [ID] key, the screen for entering the password automatically appears after the set time has elapsed. (See "Auto Clear," on p. 2-7 in the *Reference Manual*.)



1

2

3

4

5

6

7

8

9

10

11

Chapter 3 Sending Documents

■ Sending Documents	2
■ Placing Originals	8
■ Stamping Sent or Scanned Originals (STAMP)	18
■ Scanning Thin Sheet Originals (THIN SHEET ORIGINAL)	19
■ Specifying a Destination	20
■ Specifying Two or More Destinations (SEQUENTIAL BROADCAST)	27
■ Setting Resolution, Density, and Image Quality to Match the Original (RESOL., DENSITY, IMAGE QUALITY)	31
■ Changing the Sender's Name (SENDER'S NAME (TTI))	33

This chapter describes in detail how to send documents after placing them, and how documents are fed in machines that have the ADF and RDF.

Ready to send. 81/08 15:00
AUTO

STANDARD: STANDARD: TEXT AUTO RX

RESOL. DENSITY IMAGE QUALITY DIRECT

R M STAMP

CODED SUB-ADDRESS ON-HOOK REDIAL

SPECIAL FEATURES

FAX Dialing... FAX MONITOR

DELAYED TX POLLING RX DIRECTORY

MEMORY BOX PENDING SUB-ADDRESS SENDER'S NAME (TTI)

RX MODE

SCANNING MODE DOCUMENT SIZE TEST PRINT

IMAGE PROCESSING ZOOM TX 2 ON 1 TX

DONE

FAX MONITOR

[With ADF]

Ready to send. 81/08 15:00
AUTO

STANDARD: STANDARD: TEXT AUTO RX

RESOL. DENSITY IMAGE QUALITY DIRECT

R M STAMP

CODED SUB-ADDRESS ON-HOOK REDIAL

SPECIAL FEATURES

FAX Dialing... FAX MONITOR

DELAYED TX POLLING RX DIRECTORY

MEMORY BOX PENDING SUB-ADDRESS SENDER'S NAME (TTI)


RX MODE

SCANNING MODE DOCUMENT SIZE TEST PRINT

IMAGE PROCESSING ZOOM TX THIN SHEET ORIGINAL

DONE

FAX MONITOR



Sending Documents

This machine can send documents in three ways:

■ **Memory Sending (See p. 3-3.)**

This mode sends the documents after they have been scanned into the machine's memory. This means you no longer need to stay near the machine once the documents have been scanned. The G3 FAX Board-C1 is equipped with a standard 1 MB memory which can hold about 52 pages* of A4-size documents. (This can be increased to approximately 244 pages* by adding an optional 3 MB of memory and 628 pages* by adding an optional 9 MB of memory.)

*Based on the CCITT No. 1 Chart, standard setting.

■ **Direct Sending (See p. 3-6.)**

This mode allows you to send documents as soon as they are scanned, without having to first store them in memory. This allows you to make sure each document is sent, and to send documents without worrying about how much memory is left.

NOTICE

- Transmitting two or more documents directly requires use of the ADF and RDF.

MEMO

- If a paper jam occurs in the ADF or RDF while the document is being scanned, transmission is cancelled. To resend, repeat the procedure again for the selected transmission mode.


Memory Sending

Place your originals.

- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.



1

Make sure the machine is ready to send.



2

Set the FAX function in the Basic Features and/or Special Features screen.




3


Specify the destination. (See “Specifying a Destination” on p. 3-20.)


MEMO

- Specify the destination using Number Key Dialling, Redialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling. (See “Specifying a Destination” on p. 3-20.)



4


Press the  (START) key.



The document is then scanned to memory, and the amount of memory remaining is displayed.


■ When the originals are in the ADF or RDF:


The machine begins scanning the originals.


To cancel scanning, press the [CANCEL] key in the touch panel display or the  (STOP) key on the control panel.

■ When the original is on the platen glass:

The machine begins scanning the original on the platen glass.


To send additional originals, remove the first original, place the next original, and press the  (START) key.



- When manually changing the scanning size of the next original, press the [DOCUMENT SIZE] key. The display shown on the right appears. Select the new document size, then press the [OK] key.
- When all originals have been scanned, press the [DONE] key. To cancel the transmission, press the [CANCEL] key in the touch panel display or the  (STOP) key on the control panel.


MEMO

- For instructions on canceling a transmission, see "Canceling a Transmission," on p. 2-5.
- During transmission, the reference number, destination telephone number, and page number currently being sent are displayed.



5

After all originals have been scanned, the machine waits a few moments, then begins sending the documents from memory (the transaction number is displayed during sending).



MEMO

- If memory becomes full during transmission or reception, an error results, and any documents currently being scanned cannot be stored in memory. If this happens, do one of the following:
 - Erase unwanted documents from memory using the Memory Box function, then resend the remaining documents.
 - Erase unwanted documents from memory (see "Checking and Changing the Status of Transmitted Documents," on p. 6-5), then resend the remaining documents.
 - Send the documents in Direct Transmission mode.
- When a transmission error occurs, the transaction number is important for verifying the content of Activity Management Reports. If an error occurs, you should write down the reference number.

After all documents have been sent, the display returns to the FAX Standby screen.

MEMO

- If there is no response from the receiving FAX or a transmission error occurs, the machine's Automatic Redial feature automatically attempts to send the document again. By default, Automatic Redial is carried out twice at two-minute intervals. (See "Automatic Redialling When the Other Party is Busy," on p. 9-39.)

1

2

3

4

5

6

7

8

9

10

11

Direct Sending

Place your originals.

- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.

NOTICE

- In the Direct Transmission mode, only one original can be scanned and sent at a time when placed on the platen glass.

1

Make sure the machine is ready to send, then press the [DIRECT] key.

A tick “✓” appears in the box to the left of DIRECT.

Ready to send. 31/03 15:00
AUTO

☎ =

STANDARD : STANDARD : TEXT AUTO RX

RESOL. : DENSITY : IMAGE QUALITY ☒ DIRECT

R M ☐ STAMP

CODED DIALING ON-HOOK REDIAL

SPECIAL FEATURES

FAX MONITOR

2

Select a FAX mode in the Basic Features and/or Special Features screen.

Ready to send. 31/03 15:00
AUTO

☎ =

STANDARD : STANDARD : TEXT AUTO RX

RESOL. : DENSITY : IMAGE QUALITY ☒ DIRECT

R M ☐ STAMP

CODED DIALING ON-HOOK REDIAL

SPECIAL FEATURES

FAX MONITOR

DELAYED TX POLLING RX DIRECTORY

MEMORY BOX PSWD/ SUBADDRESS SENDER'S NAMES (TTI)

RX MODE

SCANNING MODE DOCUMENT SIZE TEST PRINT

IMAGE PROCESSING ZOOM TX 2 ON 1 TX

DONE


FAX MONITOR

3

Specify the destination. (See “Specifying a Destination,” on p. 3-20.)

MEMO

- Specify the destination using Number Key Dialling, Redialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling. (See “Specifying a Destination,” on p. 3-20.)
- Only one destination can be specified at a time.



1


2

4


Press the  (START) key.

The document is sent as soon as it is scanned.

MEMO

- To cancel a transmission, press the [CANCEL] key or the  (STOP) key. Scanning and transmission of documents from subsequent keying operations onwards are cancelled.
- During transmission, the reference number, destination telephone number, and page number currently being sent are displayed.

After the document has been sent, the display returns to the FAX Standby screen.



3

4

5

6

7

8

9

10

11

Placing Originals

You can place originals to be sent one of two ways. The method you use will depend on the size and type of the original you're sending, the FAX transmission mode, and your machine's optional equipment.

■ **Platen glass (See p. 3-10.)**

Place originals face down on the platen glass. Use this method when sending pages from books, transparencies, or originals on particularly heavy or light paper.

■ **ADF (Automatic Document Feeder) (See page 3-11.)**

Place a stack of originals in the original supply tray, and they are continuously and automatically fed to the platen glass for transmission. Place originals face down in the ADF in page order. Once scanned, originals are fed to the original exit tray.

MEMO

- If the Light Original mode is set, faint originals such as invoices can be fed by the ADF for scanning. (See Scanning Thin Sheet Originals, page 3-19.)

■ **Recirculating Document Feeder (RDF) (See p. 3-14.)**

Place a stack of sheet originals in the original supply tray, face up in the RDF in page order. When sending, the machine reverses them automatically and feeds them to the platen glass for scanning. Two-sided originals are automatically reversed and fed to the platen glass, allowing both sides to be sent. Once scanned, the originals are fed to the document tray.

Document Sizes Used When Sending

The document size used when sending has already been set to "Auto", and so the original size is automatically scanned before the original is sent. However, the original may be reduced to the size of the paper loaded in the receiving fax if the paper loaded in the receiving fax is not the same size as the document size. Furthermore, regardless of whether the original is positioned vertically or horizontally, it is automatically rotated when sending.

The size of some originals cannot be automatically detected. When this happens, send the original after specifying the sending size with [DOCUMENT SIZE]. (See "Specifying the Original Scanning Size," on p. 4-8.)

Orientation of Originals


You can place originals vertically or horizontally. Always align the top edge of your original with the back edge of the platen glass, as shown below.

NOTICE

- If an original is scanned facing the wrong direction, the sender information will not be printed at the correct position on the FAX.

MEMO

- A4/A5-size originals can be placed vertically or horizontally. The machine scans vertical originals somewhat faster than it does horizontal originals. You must place originals horizontally when reducing or enlarging standard sizes such as A3.
- A4R and A5R-sizes refer to horizontally placed A4 and A5-size paper.



1

2

3

4

5

6

7

8

9

10

11

Placing an Original on the Platen Glass


Place originals face down on the platen glass when your machine is not equipped with an ADF or RDF, or when you want to send pages from books, transparencies, or originals on particularly heavy or light paper.

MEMO

- Originals are sent in the order in which they are scanned.


1


Lift up the platen cover (or ADF or RDF).



2


Place your original.

The original must be face down. Align the corner of the document with the  mark in the left inner corner of the platen glass.



MEMO

- Place books and other bound originals on the platen glass in the same way.




3

Gently lower the platen cover (or ADF or RDF).

NOTICE

- When placing originals on the platen glass, the size of the original is detected after the platen cover (or ADF or RDF) has been lowered. Always lower the platen cover (or ADF or RDF) before sending or copying.




Placing Originals in the ADF

Place a stack of originals on the original supply tray, and they are continuously and automatically fed to the platen glass for transmission. Place originals face down on the platen glass in page order. Once scanned, originals are fed to the Document Tray. (See Reference Manual, Parts and Their Functions, page 1-7.)

You can place the following originals in the original supply tray:

- Weight : 35 g/m² to 105 g/m²
- Size : Standard size: A5, A4, A3
Non-standard sizes: Originals within the following range



MEMO

- When sending originals larger than the maximum original size, make a reduced copy of the original before sending. When sending originals smaller than the minimum original size, make an enlarged copy of the original before sending.
- When sending originals such as invoices that are less than 50 g/m², set the mode to the Thin Original mode.

NOTICE

Do not place the following types of originals in the ADF:

- Originals with tears or large binding holes
- Severely curled originals or originals with sharp folds
- Clipped or stapled originals
- Carbon-backed paper or other originals which might not feed smoothly
- Transparencies and other highly transparent originals

Do not bring paper or your hands within 5 cm of the original sensor on the ADF while originals are being sent. The sensors might accidentally operate, resulting in a transmission error.

MEMO

- Originals are sent in the order in which they are scanned.
- For details on names and functions of parts in the ADF, see Reference Manual ADF-F1 (Automatic Document Feeder), page 6-8.


REQUEST

- Do not press down hard on the ADF when scanning bound originals such as books placed on the platen glass. Doing so might crack or break the platen glass.
- Do not place objects in the original exit tray. Doing so might damage originals that are output to the exit tray.

1 Adjust the slide guides to fit the originals.

MEMO

- Place the first sheet at the bottom, with the side to be sent facing down.




2


Stack your originals neatly in the original supply tray, face down in page order.

The original supply tray's capacity is as follows:

- A3-size originals : 15 pages
- A4 or A5-size originals : 30 pages



When placing originals vertically, place them with their top edges facing up. When placing originals horizontally, place them with their top edge facing left.



Once scanned, the originals are output to the document tray.

REQUEST


- Do not place objects on the document tray, or you might damage only originals that are output to the tray.

NOTICE

- After scanning begins, do not add or remove originals.

MEMO

- Originals are fed from the bottom original in the order in which they are scanned.




How originals Feed Through the ADF

Neatly stack your originals face down in page order in the original supply tray.

Scanning is carried out from the lowermost original.
The scanning unit is fixed. (flow scanning function*)

* The "flow scanning function" refers to scanning originals by moving the originals by the ADF over a fixed scanning unit.

Once scanned, originals are output to the document tray.



REQUEST

- Do not place objects in the document tray.
Doing so might damage originals that are output to the document tray.

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

Placing Originals in the RDF

Place a stack of sheet originals on the original supply tray, face up in the RDF in page order. When sending, the machine reverses them automatically and feeds them to the platen glass for scanning. Two-sided originals are automatically reversed and fed to the platen glass, allowing both sides to be sent. Once scanned, the originals are fed to the document tray. (See “Parts and Their Functions,” on p. 1-7 in the *Reference Manual*.)

Originals in the original supply tray must meet these specifications:

- Weight : 50 to 105 g/m²
- Size : A5, A4, A3 (non-standard sizes can also be used)
- Tray capacity : A3-size : 25 (80 g/m²)
A4/A5-size : 50 (80 g/m²)

- Do not place the following types of originals in the RDF:
 - Originals with tears or large binding holes
 - Severely curled originals or originals with sharp folds
 - Originals with staples or paper clips
 - Carbon-backed paper or other materials that might not feed smoothly
 - Transparencies or other highly transparent materials

NOTICE

- You should not send any particular original more than 50 times, or the original might fold or wrinkle and no longer feed properly.

REQUEST


- Do not press down hard on the RDF when scanning bound originals such as books, or the platen glass might crack or break.
- Do not place objects in the document tray, or you could damage any originals output to the tray.

1

Adjust the slide guides to fit the originals.

MEMO

- Place the first sheet on top, with the side to be sent facing up.




2

Stack your originals neatly in the original supply tray, face up and in page order.


The original supply tray's capacity is as follows:

- A3-size documents (80 g/m²) : 25 pages
- A4 or A5-size documents (80 g/m²) : 50 pages




MEMO

- Before placing the following types of originals in the RDF, flip open the auxiliary tray:
 - A3/A4R-size originals (horizontal orientation)
 - A4/A5-size originals (vertical orientation)



When placing originals vertically, place them with their top edges facing up. When placing originals horizontally, place them with their top edges facing right.



Once scanned, the originals are output to the document tray.

REQUEST


- Do not place objects on the document tray, or you might damage any originals that are output to the tray.

NOTICE

- After scanning begins, do not add or remove originals.

MEMO

- Originals are fed from the top down, scanned, and sent in page order.



1 _____

2 _____

3 _____

4 _____

5 _____

6 _____

7 _____

8 _____


9 _____

10 _____


11 _____

How Originals Feed Through the RDF (when scanning one side of the original)


Neatly stack your originals in the original supply tray, face up in page order.




Originals are fed from the uppermost original to the platen glass.




When the original reaches the platen glass, the original is scanned by a moving scanning unit.




The next original (2) is fed to the platen glass.



The first scanned original (1) is fed to the document tray.



All documents in the RDF are scanned in the same way.



How Originals Feed Through the RDF (when scanning both sides of the document)

Neatly stack your originals in the original supply tray, face up in page order.

Originals are fed from the uppermost.


First, the front of the uppermost original is fed to the platen glass.

When the original reaches the platen glass, the original is scanned by a moving scanning unit.

The original is then reversed, and its opposite side is fed to the platen glass, and is scanned.

The original is reversed again.

The first scanned original (1, 2) is fed to the document tray.



1

2

3

4

5

6

7

8

9

10

11

Stamping Sent or Scanned Originals

(STAMP)


The machine can print a stamp about 1/8" (3 mm) in diameter on the rear side of scanned or sent originals. You can also set Document Stamp mode to differentiate between scanned and sent originals.

MEMO

- You can set the machine to print the document stamp only in Direct Transmission mode (the document stamp is printed when transmission ends), or in both Direct Transmission and Memory Transmission modes (the document stamp is printed when scanning ends). (See "Stamping Scanned or Sent Originals," on p. 9-43.)
- When using the ADF, the stamp is printed about 20 mm from the trailing edge of originals, and about 16 mm to the right of the centre of the paper. When using the RDF, the stamp is printed about 20 mm from the trailing edge of originals, and about 50 mm to the right of the centre of the paper.
- When scanning both sides of originals placed in the RDF, only the front side is stamped.

Place your originals. (See p. 3-8.)

- Placing originals in the ADF (See p. 3-11.)
- Placing originals in the RDF (See p. 3-14.)




- 1 Make sure the machine is ready to send, then press the [STAMP] key.

A tick "✓" appears in the box to the left of the [STAMP] key.

MEMO

- To turn the document stamp OFF, press the [STAMP] key again.



You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)

Originals output to the document tray are stamped with an "O" mark.

Scanning Thin Sheet Originals

(THIN SHEET ORIGINAL)

MEMO

- This feature can be used when the machine is equipped with the ADF.

When the Thin Sheet Original mode is set, faint originals of 50 g/m² or less such as invoices placed in the ADF can be scanned.

MEMO


- If the Thin Sheet Original mode is set for a normal copy stock of 50 to 105 g/m², it may take longer to scan the originals.

1

Place your originals in the ADF. (See "Placing originals in the ADF," on p. 3-11.)

2

Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.




3

Press the [THIN SHEET ORIGINAL] key, then press the [DONE] key.

MEMO

- To cancel the setting, press the [THIN SHEET ORIGINAL] key again.

The display returns to the Basic Features screen.



Proceed to send the original in the usual way.

(See "Sending Documents," on p. 3-2.)

Specifying a Destination

This machine gives you five ways to specify the destination you're sending the FAX to:

■ **Specifying Destinations Using Number Keys (See p. 3-21.)**

Specify one or more destinations with the Number keys on the control panel.

■ **Specifying the Last Destination Dialed Using Number Keys (See p. 3-22.)**

Specify the last destination that was dialed with the Number keys by using the [REDIAL] key in the touch panel display.

■ **Specifying with One-touch Speed Dialling (See p. 3-23.)**

Specify one or more destinations with the One-touch Speed Dialling keys on the control panel. Note that destinations specified this way must already be stored to One-touch Speed Dialling keys. (See "Storing Destinations," on p. 9-17.)

■ **Specifying with Coded Speed Dialling (See p. 3-24.)**

Specify one or more destinations with the [CODED DIALLING] key in the Basic Features screen. Note that destinations specified this way must already be stored to Coded Speed Dialling. (See "Storing Destinations," on p. 9-17.)


■ **Specifying with Directory (See p. 3-25.)**

Specify the destination with the [DIRECTORY] key in the Special Features screen. This lets you specify any destinations stored to One-touch Speed Dialling and Coded Speed Dialling. (See "Storing Destinations," on p. 9-17.)

MEMO

- You can store two or more destinations to One-touch Speed Dialling or Coded Speed Dialling as a group. (See "Storing Group Dialling Destinations," on p. 9-27.)
- You can specify two or more destinations at once. (See "Specifying Two or More Destinations," on p. 3-27.)
- You can set whether to send without pressing the Ⓢ (START) key after specifying two or more destinations. (See "Setting Transmission Functions," on p. 9-35.) The default for this setting is "Yes."


Before dialling, make sure the message **READY TO SEND** appears in the touch panel display: this means the machine is ready to send.



Specifying Destinations Using Number Keys

1

Make sure the machine is ready to send.



2

Enter the other party's fax number with the Number keys.

[BACK SPACE]:

If you make a mistake, press the [BACK SPACE] key to delete the number, then enter the correct number.

[PAUSE]:

Press this key after entering an outside line access number, and before entering the telephone number. (See "Setting the Pause Time," on p. 9-38.)

[TONE]:

Press this when directly calling an extension line connected to a PBX (public exchange line) that accepts only push signals from a dial line.

[DT]:



Press to confirm the dial tone when dialling or registering facsimile numbers.

[NEXT]:

Press this to specify another destination with the Number keys.

MEMO

- You can specify the next destination with the Number keys, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.



You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)


Specifying the Last Destination Dialed Using Number Keys (REDIAL)

This mode allows you to specify the last destination that was dialed with the Number keys. This feature comes in handy when sending several documents to the same destination.

MEMO

- If you specified more than one destination with the Number keys, you can only redial the last destination specified.

- 1 Make sure the machine is ready to send, then press the [REDIAL] key.



You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)


Specifying with One-touch Speed Dialling (ONE-TOUCH)

Specify the destination with One-touch Speed Dialling.


MEMO

- To use this feature, you must store the destinations beforehand on. (See “Storing One-touch Speed Dialling Destinations,” on p. 9-19.)


1 Make sure the machine is ready to send.



2 Press a One-touch Speed Dialling key that has a destination stored to it.



The FAX number and name stored under the One-touch Speed Dialling key appear in the touch panel display.



You can now send the next document in the usual way.

MEMO

- You can specify the next destination with Redialling, Number Key Dialling, One-touch Speed Dialling, or Coded Speed Dialling.

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

Specifying with Coded Speed Dialling (CODED DIALLING)


Specify the destination with a three-digit Coded Speed Dialling Number.

MEMO

- To use this feature, you must store the destinations beforehand. (See “Storing Coded Speed Dialling Destinations,” on p. 9-22.)


1

Make sure the machine is ready to send.



2

Press the [CODED DIALLING] key.




3

Enter a Coded Speed Dialling Number (000 to 139) for the destination.

The FAX number and name of the selected destination appear in the touch panel display.

MEMO

- If you make a mistake when specifying the destination, press the Coded Speed Dialling number again.
- When no destination has been stored to the Coded Speed Dialling number you entered, the message “Not registered” appears in the touch panel display.



You can now send the document in the usual way.

(See “Sending Documents,” on p. 3-2.)


MEMO

- You can specify the next destination with Redialling, Number Key Dialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.


Specifying with Directory (DIRECTORY)

This mode allows you to specify destinations stored to One-touch Speed Dialling and Coded Speed Dialling from a directory displayed on the touch panel display. The following example shows how you would specify “Océ,” which has been stored to “C”.

1 Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.




2 Press the [DIRECTORY] key.
The contents of the directory appear in the touch panel display.



3 Press the [ABC] key.
Destinations stored to [ABC] appear in the touch panel display.

MEMO


- You can also specify destinations stored to Additional Function keys (GENERAL 1 and GENERAL 2). (See “Storing Destinations,” on p. 9-17.)



4 Press the [▼] or [▲] keys to display the destination, then select the destination and press the [DONE] key.

MEMO

- You can specify another destination by pressing the [DIRECTORY CONTENTS] key. Return to step 3.




- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

5

Press the [DONE] key again.


The display returns to the Basic Features screen.



You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)

The FAX number and name of the selected destination appear in the touch panel display.



Specifying Two or More Destinations

(SEQUENTIAL BROADCAST)

This section describes how to specify two or more destinations at once. Sending a document to two or more specified destinations is called the Sequential Broadcast function. You can specify multiple destinations in two ways:


- **Repeatedly Specifying Destinations**
You can specify multiple destinations with Number Key Dialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.
- **Specifying the Destination with Group Dialling**
You can specify multiple destinations with Group Dialling. Group Dialling refers to storing two or more One-touch Speed Dialling or Coded Speed Dialling destinations to a single One-touch Speed Dialling or Coded Speed Dialling key.

Repeatedly Specifying Destinations

To Continue Specifying Destinations After Number Key Dialling

- 1
- Specify the destination with the Number keys.

(See “Specifying Destinations Using Number Keys,” on p. 3-21.)



2

Specify the next destination.

■ **When specifying with the Number keys:**

Press the [NEXT] key.


Specify the next destination. Repeat this operation and enter the number of the next destination.

■ **When specifying with One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling:**

You can specify the next destination using any of these methods.

MEMO


- If you store the [DIRECTORY] key as a standard key (see “Setting Standard Keys 1 and 2,” on p. 9-14), you can specify the destination in the directory after Number Key Dialling.



To Continue Specifying Destinations After One-touch Speed Dialling, Coded Speed Dialling, or Redialling

1

Specify the next destination after One-touch Speed Dialling, Coded Speed Dialling, or Redialling.
(See “Specifying a Destination,” on p. 3-20.)



2

You can specify the next destinations using Number Key Dialling, Redialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.

MEMO

- If you store the [DIRECTORY] key as a standard key (see “Setting Standard Keys 1 and 2,” on p. 9-14), you can specify the destination in the directory after One-touch Speed Dialling, Coded Speed Dialling, or Redialling.


To Continue Specifying Destinations After Directory Dialling

1

Specify the destination with Directory Dialling.

MEMO

- For information on specifying with directory, see "Specifying with Directory," on p. 3-25.




2

Specify the next destination.

■ When specifying with Directory Dialling:

Press the [DIRECTORY CONTENTS] key.
Display the directory, then specify the destination.



■ When specifying with Number Key Dialling, Redialling, or Coded Speed Dialling:

Display the Basic Features screen.
You can specify the next destination using Number Key Dialling, Redialling, One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.

1

2

3

4

5

6

7

8

9

10

11

To Continue Specifying Destinations with Group Dialling


1

Store two or more destinations to One-touch Speed Dialling or Coded Speed Dialling key as a group.

(See “Storing Destinations,” on p. 9-27.)

2

Specify the desired destinations using One-touch Speed Dialling or Coded Speed Dialling keys that have been stored for Group Dialling.



Setting Resolution, Density, and Image Quality to Match the Original

(RESOL., DENSITY; IMAGE QUALITY)

To ensure that the receiving FAX gets an easy-to-read document, set the resolution, density, and image quality to match the originals you are sending. (An asterisk * indicates default settings.)

■ RESOLUTION (RESOL.)

- STANDARD* Use when the characters are standard-size.
- FINE Use to send documents at twice the detail of Standard mode.
- SUPERFINE Use to send documents at four times the detail of Standard mode. If the receiving FAX does not support this mode, the document will automatically be sent in Fine mode.
- ULTRAFINE Use to send documents at 16 dots/mm x 15.4 lines/mm (during memory reception) or 400 x 400 dpi (during direct reception). If the receiving FAX does not support this mode, the document will automatically be sent in Super-fine or Fine mode.

MEMO

- Superfine and Ultrafine modes are only available when the optional memory has been installed.
- When using Ultrafine mode with the Image Quality mode to Photo, some documents may transmit slowly.
- If the receiving FAX does not support Super-fine or Ultra-fine modes, documents will be sent at the resolution of the receiving FAX.

■ DENSITY

- AUTO Use to automatically adjust the density.
- DARK/STANDARD*/LIGHT Select the option that best matches the document.

■ IMAGE QUALITY

This setting is particularly important when sending documents that contain photographs.

- TEXT* Use this when sending documents that contain mainly text.
- TEXT/PHOTO Use this when sending documents that contain text and photographs or other images with half-tones. This cannot be used with the "Light" or "Dark" exposure settings
- PHOTO Use this when sending photographs or other images with half-tones enhanced.

NOTICE

- Text mode requires the least time, followed by Text/Photo and Photo modes.

MEMO

- You can set resolution, density, and image quality to levels that you use frequently. (See "Setting the Standard Density for Scanning Documents," on p. 9-15.)
- Mode settings, specified before documents are sent, return to Standard mode when transmission ends or the preset Auto Clear time is reached.
- Although documents sent with Fine, Superfine, Ultrafine, Photo, or Text/Photo modes have enhanced clarity, transmission takes longer than with normal modes.

1

2

3

4

5

6

7

8

9

10


11

Place your documents.

- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.

1

Make sure the machine is ready to send, then press the [RESOL./DENSITY/IMAGE QUALITY] key.



2


Set the resolution, density, and image quality to match the document, then press the [DONE] key.

NOTICE

- When Image Quality is set to TEXT/PHOTO, the density adjustment setting is invalid.

MEMO

- Superfine and Ultrafine modes are only available when the optional memory has been installed.



You can now send the document in the usual way.

(See “Sending Documents,” on p. 3-2.)

Changing the Sender's Name


(SENDER'S NAMES (TTI))

Change the stored sender's name in the Special Features screen.
When the sender's name is stored, that name is printed in the sender information on the FAX, instead of the unit name.


MEMO

- To store the sender's name, first enter the Additional Function screen, then press the [CUSTOM FAX SETTINGS] key. (See "Storing the Company Name and Department Name," on p. 1-20.)

- Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.




- Press the [SENDER'S NAMES (TTI)] key.



- Press the [▼] or [▲] keys to display the name, select it, and press the [OK] key.

MEMO

- You can also enter the number corresponding to the name with the Number keys.





- Press the [DONE] key.
The display returns to the Basic Features screen.

Chapter 4

Editing Documents Before Sending Them

This chapter describes how to edit documents before sending them.

■ Document Editing Modes.....	2
■ Sending Facing-page Originals or Two-sided Originals (SCANNING MODE).....	4
■ Specifying the Original Scanning Size (DOCUMENT SIZE).....	8
■ Sending Enlarged or Reduced Documents (ZOOM TRANSMITTING)	11
■ Sending Designated Areas of Originals and Originals with Shadows Erased (IMAGE PROCESSING)	14
■ Checking Originals Before Sending Them (TEST PRINT)	21
■ Sending a Two-page Original as a Single Page (2 ON 1 TX).....	23



Document Editing Modes

This chapter describes the features that your machine offers for editing documents before they are sent.

■ **[SCANNING MODE] (See p. 4-4.)**

This feature has two modes:

- **[TWO-PAGE SEPARATION] (See p. 4-5.)**
This mode sends facing pages on two sheets (in a bound document, for example) in a single step.
- **[2 ► 1-SIDED] (See p. 4-7.)**
This mode is used to scan the front and back of two-sided originals one side at a time. With this mode, two-sided originals placed in the feeder are automatically turned over when scanning and sending.

■ **[DOCUMENT SIZE] (See p. 4-8.)**

This mode enables you to specify the document scanning size. It also allows you to store two non-standard document sizes.

■ **[ZOOM TX] (See p. 4-11.)**

This mode enables you to enlarge or reduce and send scanned originals.

■ **[IMAGE PROCESSING] (See p. 4-14.)**

This feature has two modes:

- **[AREA DESIG.] (See p. 4-17.)**
This mode enables you to send only designated portions of originals.
- **[ORIG. FRAME ERASE] (See p. 4-15.)**
This mode allows you to eliminate shadows from originals you send.

■ **[TEST PRINT] (See p. 4-21.)**

This mode enables you to scan and print documents so you can see beforehand how they will look when they are sent.

■ **[2 ON 1 TX] (See p. 4-23.)**

This mode allows you to send a two-page original as a single sheet. This allows you to reduce or enlarge the image that is sent.

Preparing to Use Document Editing Modes


1

Place your originals.


- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.

2

Press the [SPECIAL FEATURES] key.



The Special Features screen appears in the touch panel display.




The following descriptions assume that you are operating from the Special Features screen.

Sending Facing-page Originals or Two-sided Originals (SCANNING MODE)

This feature has the following modes:


■ **[TWO-PAGE SEPARATION]** (See p. 4-5.)

This mode sends facing pages on two sheets (in a bound document, for example) in a single step.



■ **[2 ►1-SIDED]** (See p. 4-7.)

This mode scans and sends both sides of a two-sided original.



MEMO

- When not equipped with the RDF, the [TWO-PAGE SEPARATION] key appears in the Special Features screen instead of the [SCANNING MODE] key.

**Sending Facing-page Originals on Two Pages
(TWO-PAGE SEPARATION)**

NOTICE

- This feature can be used with the following combinations of model and options:

Original Placement Series Name	Where to place the original	
	Platen glass	RDF
3121 series	Yes	Yes

This mode sends facing pages on two sheets (in a bound original, for example) in a single step.

1

2

3

4

5

6

7

8

9



10

11

1

Press the [SCANNING MODE] key.

If your machine is not equipped with the RDF, the display on the right appears. Press the [TWO-PAGE SEPARATION] key, and proceed to step 3.




2

Select the [TWO-PAGE SEPARATION] key, then press the [OK] key.

MEMO

- To cancel the Two-page separation mode, press the [C] key.



3

Press the [DONE] key.

The display returns to the Basic Features screen.

You can now send the document in the usual way.

(See “Sending Documents,” on p. 3-2.)

Sending Two-sided Originals on Two Pages
(2 ► 1-SIDED)

NOTICE


- This feature can be used with the following combinations of model and options:

Original Placement Series Name	Where to place the original	
	Platen glass	RDF
3121 series	Yes	Yes

This mode lets you send both sides of a two-sided original at once.
You can also set this mode to scan only the front of the first original. This function comes in handy when sending a single-sided cover sheet for two-sided originals, for example.

1

Press the [SCANNING MODE] key.




2

Select the [2 ► 1-SIDED] key, then press the [OK] key.

MEMO

- Select Cover Sheet "YES" when scanning only the front of the first document.

The display returns to the Special Features screen.



3

Press the [DONE] key.

The display returns to the Basic Features screen.

You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)

1 _____

2 _____

3 _____

4 _____

5 _____

6 _____

7 _____

8 _____

9 _____

10 _____

11 _____

Specifying the Original Scanning Size

(DOCUMENT SIZE)

This mode enables you to specify the original scanning size.

The machine automatically detects the document size so it can scan the original at the proper size. However, the size of some originals (such as 3-D objects or non-standard sizes) cannot be automatically detected. If this happens, you need to specify the document size in the Document Size mode before sending it.


This mode also enables you to store two non-standard sizes that you frequently use to send documents.

MEMO


- Document sizes are detected depending on where the documents are placed:
 - When scanning an original on the platen glass : Document size is detected when the platen cover (or ADF or RDF) is closed.
 - When scanning originals in the ADF : The original size is detected as soon as it is placed in the ADF.
 - When scanning originals in the RDF : The leading edge of the document is detected as soon as it is placed in the RDF, and the length of the document is detected when the document is fed to the platen glass.

When scanning parts of an original in Document Size mode, the scanning area depends on how the original is placed:


When placed on the platen glass



When placed in the ADF




When placed in the RDF



1

Press the [DOCUMENT SIZE] key.



2

Set the size for scanning documents.

- **When scanning at standard sizes:**
Select one of the displayed sizes.

MEMO

- The initial setting is "AUTO".

1

2

MEMO

- If you press the [INCH SIZE] key, the display on the right appears. In this display, you can specify inch-size originals.

3

4

- **When scanning at non-standard sizes:**
Press the [OTHER SIZE] key.

5

6

- **When scanning by an already stored size:**
Select the [REGISTERED SIZE 1] or [REGISTERED SIZE 2] key, then press the [OK] key. The display returns to that shown in step 2.

7

8

9

10


11

■ **When storing a new size to scan originals by:**

Select the [STORE SIZE] key.
 Select the [REGISTERED SIZE 1] or [REGISTERED SIZE 2] key, enter the document size at [X] and [Y] with the Number keys, then press the [OK] key.
 [X]: Enter the width of the original.
 [Y]: Enter the length of the original.

MEMO

- If you make a mistake when entering values, press the © (CLEAR) key and enter the correct value.
- You can enter the document size with the [-] [+] keys in 1-mm increments.



Next, press the [OK] key.
 The display returns to that shown in step 2.

3


Press the [OK] key.

The display returns to the Special Features screen.

4

Press the [DONE] key.

The display returns to the Basic Features screen.
 The size set by the [DOCUMENT SIZE] key is displayed as shown on the right.



Document size set by the [DOCUMENT SIZE] key

You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)


Sending Enlarged or Reduced Documents

(ZOOM TRANSMITTING)

This mode provides you with two ways to send scanned original at enlarged or reduced sizes:


■ Enlarging/reducing documents at standard ratios

Use this method to enlarge or reduce documents at standard ratios (e.g. A3 to A4).



■ Enlarging/reducing documents by % increments

This method lets you enlarge or reduce documents at any ratio, in 1% increments.




MEMO

- Even if you specify the size of the document you're sending, it may nevertheless be printed on a different size of paper if the receiving FAX does not have paper of the size you set on your FAX.

1

Press the [ZOOM TX] key.



2

■ When enlarging/reducing at a standard size:

Press the [R] or [E] key.




The standard enlargement/reduction ratios appear.
Select the ratio you want, then press the [DONE] key.

■ When enlarging/reducing at a % ratio:

Enter the ratio with the Number keys or the [-] [+] keys.

■ To return the ratio to 100%:

Press the [1:1] key to return the ratio to 100%.



<div>3</div>	<div>Press the [OK] key.</div> <div>The display returns to the Special Features screen.</div>	<div>1</div>
<div>4</div>	<div>Press the [DONE] key.</div> <div>The display returns to the Basic Features screen.</div>	<div>2</div>
	<div>You can now send the document in the usual way.</div> <div>(See “Sending Documents,” on p. 3-2.)</div>	<div>3</div>
		<div>4</div>
		<div>5</div>
		<div>6</div>
		<div>7</div>
		<div>8</div>
		<div>9</div>
		<div>10</div>
		<div>11</div>


Sending Designated Areas of Originals and Originals with Shadows Erased

(IMAGE PROCESSING)

The machine provides the following modes for processing scanned images before sending them.

■ Original Frame Erase (See p. 4-15.)


Sometimes shadows appear around the edges of original documents when they are sent (see the figure at right), especially when the originals were scanned with the platen cover (or ADF or RDF) open, or when objects such as thick books were scanned on the platen glass. The Original Frame Erase mode allows you to prevent these shadows from appearing.




■ Area Designation (See p. 4-17.)

This mode lets you send only specified rectangular areas of originals. With Area Designation mode, you can choose to send only the inside of designated areas (Framing), or only the outside of designated areas (Blanking).

● Framing




● Blanking



■ How to Designate Areas

To designate an area on the original, you must use the Number keys to designate the top right and bottom left corners. These corners are designated (in millimeters) by the coordinate pairs ([X1], [Y1]) and ([X2], [Y2]), and the top right corner when the front view is the reference. You can designate up to four areas on an original.

Designate [X1], [X2], [Y1] and [Y2] as follows:



- [X1]: Length from the right edge of the original to the right edge of the area
- [X2]: Length from the right edge of the original to the left edge of the area
- [Y1]: Length from the top edge of the original to the top edge of the area
- [Y2]: Length from the top edge of the original to the bottom edge of the area


NOTICE:

- The maximum allowable values for X and Y are as follows:
X: 432 mm Y: 297 mm


Erasing Shadows from Originals (ORIG. FRAME ERASE)

This feature eliminates the dark borders and frame lines that often appear on the edges of documents when sending facing pages or bound documents placed on the platen glass.

- 1 Press the [IMAGE PROCESSING] key.



- 2 Press the [ORIG. FRAME ERASE] key.



3

Select the document size, then press the [OK] key.


If the document is A/B-size, press the [A/B SIZE] key.

If the document is inch-size, press the [INCH-SIZE] key.

MEMO

- To cancel, press the [C] key.

The display returns to that shown in step 2.



4

Press the [DONE] key.

The display returns to the Special Features screen.

5

Press the [DONE] key.

The display returns to the Basic Features screen.


You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)


Designating Areas of the Original (AREA DESIG.)

Designate an area within the original as follows.

- 1 Press the [IMAGE PROCESSING] key.



- 2 Press the [AREA DESIG.] key.



- 3 Designate the area by pressing the [X1], [Y1], [X2], and [Y2] keys, and entering each of the values using the Number keys. Then press the [OK] key.


MEMO

- [X1]: Length from the right edge of the document to the right edge of the area
 [X2]: Length from the right edge of the document to the left edge of the area
 [Y1]: Length from the top edge of the document to the top edge of the area
 [Y2]: Length from the top edge of the document to the bottom edge of the area

- If you enter the wrong values, press the © (CLEAR) key and start again.

NOTICE


- The maximum allowable values for X and Y are as follows:
 X: 432 mm Y: 297 mm



- 4 Select the image process ([FRAMING] or [BLANKING]) to be applied to the designated area, then press the [OK] key.

MEMO

- To designate additional areas, press the [AREA 2] key, then repeat the procedure beginning with step 3.
- You can clear designated areas by pressing the [CLEAR AREA] key. Then repeat the procedure from step 3.



5



Designate additional areas, or end designating areas.

■ To end designating areas:

Press the [DONE] key, and proceed to step 7.

■ To continue designating areas:

Press the [NEXT] key. The display on the right appears in the touch panel display. Repeat the procedure beginning with step 2.



6

Press the [DONE] key.

The display returns to the Basic Features screen.

MEMO

- For instructions on clearing designated areas, see "Clearing Designated Areas," on p. 4-19.

You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2.)

Clearing Designated Areas (CLEAR AREA)


Clear designated areas as follows.

MEMO

- You can cancel by pressing the  (RESET) key.

1


Press the [AREA DESIG.] key.



2

Designate the areas to be cleared.

- To clear all already designated areas:**
Press the [C] key. Proceed to step 5.
- To clear a specific area:**
Press the [CLEAR AREA] key.




3

Select the area to clear, then press the [OK] key.

MEMO

- Stored areas are indicated by solid lines.



1

2

3

4

5

6

7

8

9

10

11

4

Select whether or not to continue clearing areas.

■ **To continue designating areas:**


Press the [NEXT] key.

Repeat the procedure from step 2 of Designating Areas (See p. 4-20).

■ **To end designating areas:**

Press the [DONE] key.

Proceed to step 5.



5

Press the [DONE] key.

The display returns to the Basic Features screen.

Checking Originals Before Sending Them

(TEST PRINT)

This mode enables you to scan and print documents under the same conditions they will be sent. This enables you to estimate how the document will look on the receiving FAX before you actually send it.

MEMO

- Since the documents appearance depends on the receiving FAX, it may look different from the results of Test Print mode.
- Check documents one at a time when using Test Print mode on documents placed on the platen glass.

1

Place your originals.

- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.

2

Set the FAX mode. (See “Preparing to Use Document Editing Modes,” on p. 4-3.)

3

Press the [TEST PRINT] key in the Special Features screen.

The settings of the current mode appear.

MEMO

- You can display the resolution, density, image quality, and document size.

Do you wish to test print?

C

RESOL. : STANDARD

DENSITY : STANDARD

IMAGE QUALITY : TEXT

DOCUMENT SIZE : AUTO

START TEST PRINT

FAX MONITOR

1

2

3

4

5

6

7

8

9

10

11



4

Make sure the settings are OK, then press the [START TEST PRINT] key.

The original is scanned and printed using the current mode.

MEMO

- To cancel printing, press the [CANCEL] key.



You can now send the document in the usual way.

(See "Sending Documents," on p. 3-2).

Sending a Two-page Original as a Single Page


(2 ON 1 TX)

NOTICE


- This feature can be used with the following combinations of model and options:

Original Placement Series Name	Where to place the original	
	Platen glass	RDF
3121 Series	Yes	Yes


This mode allows you to send a two-page original as a single sheet, which lets you reduce or enlarge the image you're sending.



1 Press the [2 ON 1 TX] key.



2 Select the original size and sending size (TX SIZE), then press the [OK] key.



3

Press the [DONE] key.

The display returns to the Basic Features screen.

You can now send the document in the usual way.



(See "Sending Documents," on p. 3-2.)

Chapter 5

Receiving Documents

This chapter describes how to receive documents using the machine's FAX receiving modes (Automatic Receiving, Memory Receiving, and Transfer). The machine normally uses Automatic Receiving mode, which requires no special operations. However, if you want to use any of the machine's other receiving modes, you should read this chapter.

■ Receiving Modes (RX MODE)	2
■ Receiving Documents	6
■ Printing Received Documents	8



Receiving Modes (RX MODE)

This machine is provided with three receiving modes: Automatic Receiving, Memory Lock, and Transfer. This section describes these three receiving modes, and tells how to manually switch between them.

■ **Automatic Receiving mode (AUTO RX)**

When the incoming call is a FAX document, the machine automatically receives and prints the document.

■ **Memory Lock mode (MEMORY LOCK)**

When the machine is in Memory Lock mode, documents are stored in memory, and are printed when the machine is taken out of Memory Lock mode.

MEMO

- You can set a password to limit changing to Memory Lock mode. (See "Saving Received Documents to Memory," on p. 9-90.)
- You can set the time to receive documents in memory. (See "Saving Received Documents to Memory," on p. 9-90.)

■ **Transfer mode (TRANSFER)**


When the machine is set to Transfer mode, it transfers all documents it receives to a preset destination.

MEMO


- You can set the destination to transfer documents. (See "Transferring Received Documents," on p. 9-86.)
- You can set the time to transfer documents. (See "Transferring Received Documents," on p. 9-86.)
- You can set a password to limit access to Transfer mode settings. (See "Transferring Received Documents," on p. 9-86.)

Changing Receiving Modes

- 1 Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.




- 2 Press the [RX MODE] key.



- 3 Select the [AUTO RX] mode.

■ To set Memory Lock/Transfer to OFF:


Press the [OFF] key for Memory Lock and Transfer.



The display on the right appears.
Enter the Memory Lock/Transfer passwords.

MEMO

- This operation is not required if you have not set Memory Lock/Transfer passwords.







■ **To set Memory Lock/Transfer to ON:**

Select the [AUTO RX] key, then press the [ON] key for Memory Lock and Transfer.

The display on the right appears.
Enter the Memory Lock/Transfer passwords.

MEMO

- This operation is not required if you have not set Memory Lock/Transfer passwords.



<div>4</div>	<div>Press the [DONE] key.</div> <div>The display returns to the Special Features screen.</div>	<div>1</div>
<div>5</div>	<div>Press the [DONE] key.</div> <div>The display returns to the Basic Features screen.</div>	<div>2</div>
		<div>3</div>
		<div>4</div>
		<div>5</div>
		<div>6</div>
		<div>7</div>
		<div>8</div>
		<div>9</div>
		<div>10</div>
		<div>11</div>

Receiving Documents

No special operations are needed to receive documents because machine is received in Auto Receiving mode. When the incoming call is a FAX document, the document is automatically received and printed.

MEMO

- When the machine is set to Memory Lock mode, documents are held in memory, and are printed when the machine is taken out of Memory Lock mode (cancelled). (See "Receiving Modes," on p. 5-2.)


Automatic Receiving

1

When documents start to be received, the FAX Status lamp on the control panel flashes.

MEMO

- You can also set the machine so that the call tone sounds when there is an incoming call. (See "Setting the Call Tone When in the Auto Receiving, Transfer, and Memory Lock Modes," on p. 9-47.)
- During reception, the transaction number and other information relating to the other party are displayed. (See "Basic Features Screen," on p. 1-3.)




2

When documents have finished being received, the FAX Status lamp on the control panel lights. This indicates that documents are stored in memory.

MEMO

- The FAX Status lamp lights or flashes even if the control panel power supply is OFF (when the machine is in Sleep mode).



The document prints.

MEMO

- The G3 FAX Board-C1 is equipped with a standard 1 MB memory which can hold about 52 pages* of A4-size documents. (This can be increased to approximately 244 pages* by adding an optional 3 MB of memory and 628 pages* by adding an optional 9 MB of memory.)

* Based on the CCITT No. 1 Chart, standard setting.

Documents received in memory are automatically printed when paper is loaded in the drawer.

- You can set the machine so that the call tone rings when receiving documents in the Auto Receiving mode. (See "Setting the Call Tone in the Auto Receiving, Transfer and Memory Lock Modes," on p. 9-47.)

1

2

3

4

5

6

7

8

9

10

11

Printing Received Documents

Paper on Which Received Documents are Printed

Received documents are printed on the paper from the paper drawer or the stack bypass that has the same size as the document. If paper of the correct size for the received document is not available, the machine instead automatically selects a different size of paper in the order shown below.

If the machine runs out of paper, it stores the document in memory. (See "Setting Memory Reception When Paper Runs Out," on p. 9-48.) When the paper drawer is then reloaded with paper, the remaining pages of the document are automatically printed.

<Available Paper Sizes for Received Documents>

- A3-size originals : A3
- A4-size originals : A4R → A4 → A3
- A5-size originals : A5R → A5 → A4R → A4 → A3

Received documents are automatically reduced before being printed on the paper sizes indicated by an asterisk (*).

This size of paper is automatically selected in the same order, even if paper runs out during printing.

MEMO

- You can control which drawer the machine uses for printing. (See "Setting Whether or Not a Drawer is Subject to Auto Drawer Switching," on p. 3-11 in the *Reference Manual*.) The default setting is to use all paper sources (drawers/stack bypass) except the stack bypass.
- You can set the machine to reduce received documents by 70%, 90%, 95%, or 97% if the document is larger than any of the available paper sizes. (See "Setting Whether to Print Received Documents at a Reduced Size," on p. 9-97.)
- You can change the order in which paper sizes are selected. (See "Setting Alternate Paper Cassettes," on p. 9-96.)
- You can set the machine to print received documents on both sides of the paper. (See "Setting Whether to Print Received Documents on Both Sides of the Paper," on p. 9-101.)

Orientation and Order in Which Received Documents are Printed


Received documents are printed face down, in the order in which the pages are received.

Chapter 6

Checking and Changing the Communications Status

This chapter describes modes for checking the transmission and reception status of FAX documents, and explains how to check transmission and reception results.

■ Checking and Changing the Communications Status (FAX MONITOR).....	2
■ Checking and Changing the Status of Transmitted Documents (TX DOCUMENT).....	5
■ Checking and Changing the Status of Received Documents (RX DOCUMENT).....	15
■ Checking Communications Results (TX/RX RESULT)	22



Checking and Changing the Communications Status (FAX MONITOR)

You can use the FAX Monitor screen to check the following:

- Status of TX documents (ready to send, sending, error, etc.)
- Status of RX documents (reception result, memory reception, etc.)
- Transmission/reception results

These three conditions are collectively referred to as the “communications status.”

When you press the [FAX MONITOR] key in the Basic Features screen, the FAX Monitor screen scrolls down the touch panel display.

To return to the Basic Features screen, press the [RETURN] key.

MEMO

- You can press the [FAX MONITOR] key during any FAX operation except when scanning documents or printing lists or received documents.

The FAX Monitor screen is made up of the following three screens:

■ TX Document screen

This screen appears when you press the [TX DOCUMENT] key in the FAX Monitor screen. This screen lets you check or change the status of transmitted documents in memory.

FAX Sending.				RETURN
1 / 17		Avail. Memory 80%		
8:45	21011250	1243	Sending	
9:28	1 432 2060	1247	Waiting	
9:36	SALES DEPT.	1246	Waiting	
10:16	516 488 6700	1245	Waiting	
10:24	SO BDC 7 UNITS	1244	Waiting	

Touch an item

PRINT LIST [Left Arrow] [Right Arrow] DETAILS CANCEL

TX DOCUMENT RX DOCUMENT TX/RX RESULT

■ RX Document screen

This screen appears when you press the [RX DOCUMENT] key in the FAX Monitor screen. This screen lets you check or change the status of received documents in memory.

FAX Sending.				RETURN
17		Avail. Memory 80%		
8:45	21011250	5250	MEMORY LOCK	
8:46	1 432 2060	5249	MEMORY LOCK	
9:28	516 488 6700	5249	MEMORY LOCK	
9:36	4167951111	5248	MEMORY LOCK	
10:16	87448500	5247	MEMORY LOCK	
10:24	5163285841	5246	MEMORY LOCK	

Touch an item

PRINT LIST [Left Arrow] [Right Arrow] DETAILS ERASE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

■ TX/RX Result screen

This screen appears when you press the [TX/RX RESULT] key in the FAX Monitor screen. This screen lets you check the results of the last 40 transactions.

FAX Dialing...				RETURN
1 / 40				
12:45	SEQ TX	4167951111	2242 OK	
12:16	TX	8 7448500	2241 NG	
11:41	CONF TX	516 328 5841	2240 OK	
10:19	RX	Legal Div.	5581 NG	
9:28	RX	Finance Div.	5580 OK	
8:27	TX	Toronto Office	2239 OK	

Touch an item

PRINT LIST [Left Arrow] [Right Arrow] DETAILS

TX DOCUMENT RX DOCUMENT TX/RX RESULT

Displaying the FAX Monitor Screen

1

Press the [FAX MONITOR] key in the Basic Features screen.





MEMO

- The [FAX MONITOR] key can be pressed during any FAX function except when document scanning or printing lists or received documents.

The TX Document screen appears.

- To display the RX Document screen:**
Press the [RX DOCUMENT] key.

The RX Document screen appears.



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

- **To display the TX/RX Result screen:**
Press the [TX/RX RESULT] key.

The TX/RX Result screen appears.

FAX Dialing ...				RETURN	
1 / 17		Avail. Memory		80%	
8:45	21011250	1243	Sending		
9:28	1 432 2060	1247	Waiting		
9:36	SALES DEPT.	1246	Waiting		
10:16	516 488 6700	1245	Waiting		
10:24	SO BDC 7 UNITS	1244	Waiting		
Touch an item					
PRINT LIST		DETAILS		CANCEL	
TX DOCUMENT		RX DOCUMENT		TX/RX RESULT	

FAX Dialing ...				RETURN	
1 / 40					
12:45	SEQ TX	4167951111	2242	OK	
12:16	TX	8 7448500	2241	NG	
11:41	CONF TX	516 328 5841	2240	OK	
10:19	RX	Legal Div.	5581	NG	
9:28	RX	Finance Div.	5580	OK	
8:27	TX	Toronto Office	2239	OK	
Touch an item					
PRINT LIST		DETAILS			
TX DOCUMENT		RX DOCUMENT		TX/RX RESULT	

Checking and Changing the Status of Transmitted Documents (TX DOCUMENT)

If you press the [TX DOCUMENT] key in the FAX Monitor screen, the TX Document screen appears. In this screen, you can check or change the status of any transmitted documents stored in memory. You can also check the following items relating to transmitted documents:

■ **Times scanned**

You can check the times when transmitted documents were scanned.

■ **Destinations**

You can check the destinations of transmitted documents.

The unit name is displayed if it is already stored. Otherwise, the telephone number is displayed.

■ **Transaction number**

You can check the transaction numbers of transmitted documents. These numbers come in useful when verifying reports.

MEMO

- Transaction numbers 0001 to 4999 are assigned in the order in which documents are scanned. The transaction number returns to 0001 after 4999.

■ **Transmitted document status**

You can check a document's transmission status when it is stored in memory for sending, or even if it is currently being sent.

[TX Document screen]

Destination

Transaction Number

FAX Dialing...

1/ 17

Avail. Memory 88%

Times scanned

8:45

21011250

1243

Sending

9:28

1 432 2060

1247

Waiting

9:36 SALES DEPT.

1246

Waiting

10:16 516 488 6700

1245

Waiting

10:24 50 BDC 7 UNITS

1244

Waiting

Touch an item

PRINT LIST

DETAILS

CANCEL

TX DOCUMENT

RX DOCUMENT

TX/RX RESULT

Transmitted Document Status

Sending : The document is being sent.

Waiting : The document is stored in memory until the machine is ready to send.

NG : A communications error occurred.

You can also carry out the following operations in the TX Document screen:

■ **Canceling transmission (See p. 6-6.)**

You can cancel transmission of selected documents.


■ **Printing a list of transmitted documents (See p. 6-8.)**

You can print a list of all transmitted documents in memory to check the information for each.

■ Checking and changing detailed information of transmitted documents (See p. 6-9.)

If you select a document and press the [DETAILS] key, the Details screen appears in the touch panel display. This screen lets you check the date and time that the selected document was scanned, and the number of pages in the document. When using sequential broadcast to send documents to two or more destinations, you can also use this screen to check the documents' destinations, and the time the documents are to be sent.

[Details screen]



■ Resending Failed Transmissions (See p. 6-11.)

You can use the Details screen to resend documents that failed to transmit.

Cancelling Transmission

Documents that are in the process of being sent from memory are displayed in the TX Document Screen. This section describes how to cancel documents from the TX Document Screen.

MEMO

- To cancel a transmission of a document while it is still being scanned, press the (STOP) key.


1

Display the TX Document List screen.

(See "Displaying the FAX Monitor Screen," on p. 6-3.)


2

Press the [▼] or [▲] keys to display the document to be cancelled, then select the document.



3

Press the [CANCEL] key.



1

2

4

A screen for confirming the cancellation appears in the touch panel display.

Press the [YES] key. The transmission of the selected document is cancelled.

To stop the cancellation and allow the transmission to proceed, press the [NO] key. The procedure then returns to step 2.

The display on the right appears for about two seconds, and then returns to the display shown in step 2.



3

4

MEMO

- To return to the Basic Features screen, press the [RETURN] key.
- Transmitted documents cancelled in the TX Document screen are treated as documents that failed to transmit. The machine's default settings are to clear all such documents from memory, though you can change the settings so that these documents are not cleared. (See "Setting Whether to Clear Failed Transmissions from Memory," on p. 9-41.) When the machine is set not to clear documents that failed to transmit, the documents remain in memory, and are displayed in the TX Document screen. You can also change the document's destination (see "Changing the Destination of Transmitted Documents," on p. 6-12), and resend them (see "Resending Failed Transmissions," on p. 6-11).



5

6

7

8

9


10

11

MEMO

- The display on the right appears when sequential broadcast documents are being sent with destinations that were specified by a method other than Group Dialling.

To cancel only the transmission that is currently under way, press the [ONLY ONE] key. To cancel all transmissions, press the [ALL] key. (Transmission of the selected document is cancelled in either case.) To not cancel the transmission, press the [DON'T CANCEL] key. The procedure returns to step 2.



Printing a TX Reserve List

The Transmitted Document List allows you to check the following information for the last 40 documents that were sent:

- Transmission start time
- Destinations
- Sender's name
- Transaction number
- Communication modes
- Number of pages

MEMO


- For an example of a TX reserve list, see “Checking Communications Status With Activity Management Reports,” on p. 11-2.

1

Display the TX Document screen. (See “Displaying the FAX Monitor Screen,” on p. 6-3.)

2

Press the [PRINT LIST] key.




3

A TX reserve list is printed.


MEMO

- To cancel printing, press the [CANCEL] key.
- To return to the Basic Features screen, press the [RETURN] key.




Checking and Changing Detailed Information On Transmitted Documents

You can display the Details screen to check the details of each transmitted document. In this screen, you can check the date and time that the document was sent, as well as the number of pages in the document. When using sequential broadcast to send documents to two or more destinations, the Details screen also lets you check the documents' destinations.




1 Display the TX Document screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)

2 Press the [▼] or [▲] keys to display the document whose details you want to confirm, then select the document.



3 Press the [DETAILS] key.



The Details screen for the selected document appears in the touch panel display.

■ **To check the destinations of sequential broadcast documents:**

Press the [BDCST LIST] key. A list of sequential broadcast destinations appears.

If the list contains more than six destinations, press the [▼] or [▲] keys to scroll the list.

FAX Dialing... RETURN

SET TIME	09/06 18:45	TX/RX NO.	1244
MODE	SEQUENTIAL BROADCAST	NO. OF PAGES	2
DSTN	SO BDC 7 UNITS BDCST LIST		
RESULT	Waiting	START TIME	10:00

PRINT RESEND CHANGE DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

FAX Dialing... RETURN

SO BDC	7 UNITS	TX/RX NO.	1244
Singapore Office		NG	
Australia Office		OK	
Legal Div.		OK	
516 488 6700		Waiting	
416 795 1111		Waiting	

1/2 [▼] [▲] DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

4

Press the [DONE] key.

The display returns to the Details screen shown in step 2, above.

5

Press the [DONE] key.

The display returns to the TX Document screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

Resending Failed Transmissions

Documents that could not be sent are treated as failed transmissions. If you set ERASE FAILED TX (see p. 9-41) to "YES" (the default setting is "NO"), the documents that failed to transmit are displayed in the TX Document Screen.

This section describes how to resend failed transmissions from the TX Document Screen.

MEMO

- Leaving too many failed transmissions in memory will reduce the amount of available memory. (See "Deleting Received Documents from Memory," on p. 6-16.)
- You can set whether to save failed transmissions to memory. (See "Setting Whether to Clear Failed Transmissions from Memory," on p. 9-41.)

1

2

3

4

5

6

7

8

9


10

11

1 Display the TX Document screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)

2 Display the Details screen for the document to be resent (see p. 6-9), then press the [RESEND] key.

- MEMO**
- If you press the [DONE] key, the display returns to the TX Document screen.



3 Press the [YES] key.

The failed transmission is resent.
To cancel resending, press the [NO] key, then proceed to step 2.



4 Press the [DONE] key.

The display returns to the TX Document screen.

- MEMO**
- To return to the Basic Features screen, press the [RETURN] key.

Changing the Destination of Transmitted Documents

You can use the Details screen to add, correct, or delete destinations of transmitted documents.

NOTICE

- You cannot correct destinations specified by One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling.
- The destinations of documents waiting to be sent can be corrected, but cannot be changed or deleted.

1

Display the TX Document screen. (See “Displaying the FAX Monitor Screen,” on p. 6-3.)

2

Display the Details screen for the document whose destination you want to change (see p. 6-9), then press the [CHANGE] key.

FAX Dialing... RETURN

SET TIME	09/06 18:45	TX/RX NO.	1243
MODE	SEQUENTIAL BROADCAST	NO. OF PAGES	2
DSTN	SO BDC 7 UNITS	BDCST LIST	
RESULT	Waiting	START TIME	10:00

PRINT RESEND CHANGE DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

3

Press the [DESTINATION] key.

FAX Dialing... RETURN

Select item you want to change.

DESTINATION TX START TIME

DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

The document's destination appears.

FAX Dialing... RETURN

Select item you want to change.

21011250
14322060
5164886700
4167951111
87448500

Touch an item

ADD DELETE CHANGE DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

■ **To add a destination:**

Press the [ADD] key. The display on the right appears in the touch panel display. Specify the destination to add, then press the [OK] key. The destination is added.

MEMO

- You can specify the destination with One-touch Speed Dialling (see p. 3-23), Coded Speed Dialling (see p. 3-24), Directory Dialling (see p. 3-25), or Number Key Dialling (see p. 3-21).

■ **To delete a destination:**

Select the destination to be deleted, then press the [DELETE] key.

A confirmation screen appears.

Press [YES] to confirm the deletion.


Press [NO] to cancel the deletion and return to the document destination display.

■ **To correct a destination:**

Select the destination to be corrected, then press the [CHANGE] key. Correct the destination, then press the [OK] key. The destination is corrected.

MEMO

- Press the [◀] or [▶] keys to move the cursor to the character after the number to be corrected, then press the [BACK SPACE] key to delete that character. Then enter the correct number with the Number keys.
- You can only correct destinations that were specified with the Number keys.



4

Press the [DONE] key.

The display returns to the Details screen shown in step 2.

5

Press the [DONE] key.

The display returns to the TX Document screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

1

2

3

4

5

6

7

8

9

10

11

Changing the Document Transmission Time

You can use the Details screen to change the preset time (Specified in Delayed TX mode) that a document is to be sent.

- 1 Display the TX Document List screen. (See “Displaying the FAX Monitor Screen,” on p. 6-3.)

- 2 Display the Details screen for the document whose transmission time you want to change (see p. 6-9), then press the [CHANGE] key.

FAX Dialing... RETURN

SET TIME	09/06 8:45	TX/RX NO.	1243
MODE	NG	NO. OF PAGES	2
DSTN	21011250 Océ USA		
RESULT	Waiting	START TIME	10:00

PRINT RESEND CHANGE DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

- 3 Press the [TX START TIME] key.

FAX Dialing... RETURN

Select item you want to change.

DESTINATION TX START TIME

DONE

TX DOCUMENT RX DOCUMENT TX/RX RESULT

The current date and time and the time to start transmitting the document appear.

■ **To cancel the transmission start time:**

Press the [CANCEL DELAYED TX] key, then press the [OK] key.

The document now remains in memory until you send it.

■ **To change the transmission start time:**

Enter the new time with the Number keys, then press the [OK] key.

FAX Dialing... RETURN

Enter the start time. C

13/06 '96 15:00

⌚ [10:00]

(00:00~23:59)

CANCEL DELAYED TX

OK

TX DOCUMENT RX DOCUMENT TX/RX RESULT

- 4 Press the [DONE] key.

The display returns to the TX Document screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

Checking and Changing the Status of Received Documents (RX DOCUMENT)

If you press the [RX DOCUMENT] key in the FAX Monitor screen, the RX Document screen appears. This screen lets you check or change the status of received documents stored in memory, and also allows you to check the following information about the received documents:

- **Time received**
You can check the times when the documents were received.
 - **Sender**
You can check the senders of received documents.
 - **Transaction Number**
You can check the transaction numbers of received documents. These are useful when verifying reports.
- MEMO**
- Transaction numbers 5001 to 9999 are assigned in the order in which the documents are received. The transaction number returns to 5001 after 9999.
- **Received Document status**
The RX Document screen enables you to check the receiving status of documents. You can check, for example, whether a received document is stored in memory, or is waiting to be printed due to lack of paper in the machine.

[RX Document List screen]

Sender

Transaction number

FAX Dialing ...

1 / 17

Avail. Memory 88%

8:45	21011250	5250	MEMORY LOCK
8:46	14322060	5249	MEMORY LOCK
9:28	5164886700	5249	MEMORY LOCK
9:36	4167951111	5243	MEMORY LOCK
10:16	87448500	5247	MEMORY LOCK
10:24	5163285841	5246	MEMORY LOCK

PRINT LIST

▼

DETAILS

ERASE

TX DOCUMENT

RX DOCUMENT

TX/RX RESULT

Time received

Received Document Status
MEMORY LOCK : Received documents are stored in memory.


You can also carry out the following operations in the Received Document List screen.

- **Deleting Received Documents from Memory (See p. 6-16.)**
You can erase selected received documents from memory.
- **Printing a DOC. Memory List (See p. 6-18.)**
You can print a list of all received documents in memory to check the information of each of the documents.

■ Displaying the Details screen to check the details of received documents (See p. 6-19.)

If you select a document and press the [DETAILS] key, the Details screen appears in the touch panel display. In this screen, you can check the date and time that the document was received, and the number of pages in the document.

[Details screen]



■ Transferring received documents from memory (See p. 6-20.)

You can transfer received documents from memory. This is useful, for example, if the machine runs out of paper and cannot print the document.

Deleting Received Documents from Memory


Received documents stored in memory are displayed in the RX Document screen. This section describes how to delete a specific received document from the RX Document screen.

1

Display the RX Document screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)


2

Press the [▼] or [▲] keys to display the document you want to delete, then select the document.



3

Press the [ERASE] key.




1

2

4

Press the [YES] key. The selected document is deleted from memory.

To cancel this process, press the [NO] key. The display returns to that shown in step 2.




3

4

The display on the right appears in the touch panel display for about two seconds.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.



5

6

7

8

9

10

11

Printing a DOC. Memory List

The DOC. Memory List allows you to check the following information for all documents in memory:

- Dates and times documents were scanned or received
- Destinations
- Transaction numbers
- Communication modes
- Number of pages


(See "Printing Lists," on p. 11-7.)

1

Display the RX Document screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)

2

Press the [PRINT LIST] key.



A DOC. Memory List is printed.

MEMO

- To cancel printing, press the [CANCEL] key.
- To return to the Basic Features screen, press the [RETURN] key.

Displaying the Details Screen to Check the Details of Received Documents

You can use the Details screen to check the details of each received document: you can check the date and time that each document was received, and the number of pages in the document.

Press to transfer the received documents.

1

Display the RX Document screen. (See “Displaying the FAX Monitor Screen,” on p. 6-3.)

2

Press the [▼] or [▲] keys to display the document whose details you want to check, then select the document.

3

Press the [DETAILS] key.

The Details screen for the selected document appears in the touch panel display.

4

Press the [DONE] key.

The display returns to the RX Document screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

Transferring Documents Received from Memory

You can transfer received documents in the Details screen.

1

Display the RX Document List screen. (See “Displaying the FAX Monitor Screen,” on p. 6-3.)

2

Press the [▼] or [▲] keys to display the Details screen (see p. 6-19) for the document you want to transfer, then select the [TRANSFER] key.

The screen displays the following information:

SET TIME	09/06 8:45	TX/RX NO.	5250
MODE	AUTO RX	NO. OF PAGES	2
CONNECTION	21011250		
RESULT	MEMORY LOCK		

At the bottom, there is a [TRANSFER] button on the left and a [DONE] button on the right. Below the screen, three tabs are visible: TX DOCUMENT, RX DOCUMENT (selected), and TX/RX RESULT.

3

Specify the transfer destination, then press the [OK] key.

MEMO

- You can specify the destination with One-touch Speed Dialling (see p. 3-23), Coded Speed Dialling (see p. 3-24), Directory Dialling (see p. 3-25), or Number Key Dialling (see p. 3-21).

The screen displays the following information:

Specify destination. [C]

☎ = 5164887600

At the bottom, there are buttons for CODED DIAL, DIRECTORY, PAUSE, BACK SPACE, TONE, and OK. Below the screen, three tabs are visible: TX DOCUMENT, RX DOCUMENT (selected), and TX/RX RESULT.



4

Press the [YES] key.

To cancel the transfer, press the [NO] key. The display then returns to that shown in step 2.

The display on the right appears for about two seconds, and then returns to the display shown in step 2.

Proceed to step 3.



5

Press the [DONE] key.

The display returns to the RX Document screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

1

2

3

4

5

6

7

8

9

10

11

Checking Communications Results

(TX/RX RESULT)

If you press the [TX/RX RESULT] key in the FAX Monitor screen, the TX/RX Result screen appears. In this screen, you can check the results of the last 40 transactions (transmissions and receptions), including the following items:

■ Time sent or received

You can check the times when documents were sent or received.

■ Destination

You can check the senders of received documents and destinations of transmitted documents. When the unit name is stored, the unit name is displayed. Otherwise, the telephone number is displayed.

■ Transaction Number

You can check the reference numbers of received and transmitted documents. These numbers are useful when verifying reports.

MEMO

- Transaction numbers 0001 to 4999 are assigned in the order in which documents are sent. The transaction number returns to 0001 after 4999. Transaction numbers 5001 to 9999 are assigned in the order in which documents are received. The reference number returns to 5001 after 9999.

■ Communication Results

You can use the Communication Results screen to check the communication results of documents. For example, OK appears when the document was successfully sent or received, and NG appears when the transmission or reception failed.

[TX/RX Result screen]

The screenshot shows the TX/RX Result screen with the following data:

Time sent/received	Communication mode	Destination	Transaction number	Communication Results
12:45	TX	4167951111	2242	OK
12:16	TX	8 7448500	2241	NG
11:41	CONF TX	516 328 5841	2240	OK
10:19	RX	Legal Div.	5581	NG
9:28	RX	Finance Div.	5580	OK
8:27	TX	Toronto Office	2239	OK

Labels pointing to the screen elements:

- Destination: Points to the destination column.
- Communication mode: Points to the communication mode column.
- Transaction number: Points to the transaction number column.
- Time sent/received: Points to the time sent/received column.
- Communication Results: Points to the OK/NG column.

Legend:

- OK : Documents were successfully sent or received.
- NG : Transmission or reception of documents failed.

Buttons at the bottom: PRINT LIST, TOUCH AN ITEM, DETAILS, TX DOCUMENT, RX DOCUMENT, TX/RX RESULT.

You can also use the TX/RX Result screen to perform the following operations:

■ Printing activity management reports (See p. 6-24.)

You can print a list of all received documents in memory to check the information of each of the documents.

■ Checking the details of communication results (See p. 6-23.)

If you select a document and press the [DETAILS] key, the Details screen appears in the touch panel display. In this screen, you can check the dates and times that documents were sent or received, and the number of pages in the documents.


Checking the Details of Transmission Results

1

Display the TX/RX Result screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)


2

Press the [▼] or [▲] keys to display the document whose details you want to check, then select the document.




3

Press the [DETAILS] key.



The Details screen for the selected document appears in the touch panel display.



Transmission time

4

Press the [DONE] key.
The display returns to the TX/RX Results screen.

MEMO

- To return to the Basic Features screen, press the [RETURN] key.

Printing Activity Management Reports

Activity Management Reports allow you to check the following information for the past 40 transactions:

- Dates and times the documents were sent or received
- Destinations
- Reference numbers
- Communications modes
- Number of pages in the documents


(See "Checking Communications Status with Activity Management Reports," on p. 11-2.)

1

Display the TX/RX Result screen. (See "Displaying the FAX Monitor Screen," on p. 6-3.)

2

Press the [PRINT LIST] key.




3

The Activity Management Report is printed.

MEMO


- To cancel printing, press the [CANCEL] key.
- To return to the Basic Features screen, press the [RETURN] key.




Chapter 7

Useful Communications Functions

This chapter describes additional communications functions that the machine provides, such as delayed transmission.



- Receiving Documents from a Remote FAX (POLLING RX) 2
- Specifying the Time to Send a Document (DELAYED TX) 4
- Using the Remote Control Features 6
- Special Dialling 9



Receiving Documents from a Remote FAX


(POLLING RX)

Polling Receiving mode allows you to use your machine to make a remote FAX send documents to your machine, even if the other party is out of the office.
If the remote FAX does not have a password, polling cannot be performed.
To use polling reception, the password "255" must be set in the remote FAX.


MEMO

- You can set your machine for polling receiving at a specific time. This is called "Preset Polling." (See "Setting Periodical Polling Reception," on p. 9-84.)
- Polling Receiving mode also enables you to receive documents from multiple remote FAX machines. After receiving documents from two or more destinations, the machine prints a Multi TX report.
- You can use polling receiving to receive documents at a specified time in combination with Delayed Transmission mode (see p. 7-4). In this case, you must first set Delayed Transmission mode in the Special Features screen before specifying the destination.
- To carry out polling sending to a FAX that does not conform to the ITU-T standard, use box number "00" (the special memory box assigned for polling transmission).

- 1 Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.



- 2 Select [POLLING RX], then press the [DONE] key.
The display returns to the Basic Features screen.



3

Specify the destination.

Specify the destination. 31/03 15:00
AUTO

☎=5164887600

STANDARD : STANDARD : TEXT

RESOL.	DENSITY	IMAGE QUALITY	<input type="checkbox"/> DIRECT
R	M		<input type="checkbox"/> STAMP
CODED DIALING	ON-HOOK	REDIAL	
			SPECIAL FEATURES
			<input type="checkbox"/> FAX MONITOR


1 _____

2 _____

4

Press the  (START) key.

Polling receiving is initiated.



3 _____

4 _____

5 _____

6 _____

7 _____

8 _____

9 _____

10 _____

11 _____

Specifying the Time to Send a Document

(DELAYED TX)

The machine's Delayed Transmission mode allows you to scan documents to memory, then send them at a later time. This enables you to send during times with lower telephone rates.

MEMO

- You can also cancel transmission of documents scanned to memory, or change their destinations. (See "Checking and Changing the Status of Transmitted Documents," on p. 6-5.)


NOTICE

- When a transmission made in Delayed Transmission mode ends, the timer is automatically cancelled and documents are deleted from memory.


Place your originals.

- For instructions on how to place an original on the platen glass, see "Placing an Original on the Platen Glass," on p. 3-10.
- For instructions on how to place originals in the ADF, see "Placing Originals in the ADF," on p. 3-11.
- For instructions on how to place originals in the RDF, see "Placing Originals in the RDF," on p. 3-14.

- 1 Make sure the FAX is ready to send, then press the [SPECIAL FEATURES] key.



- 2 Press the [DELAYED TX] key.




3

Enter the time you want the document to be transmitted with the Number keys, then press the [OK] key.

MEMO

- Enter the transmission time, from 00:00 to 23:59. Use two digits for the hours and for the minutes.
- To cancel Delayed Transmission mode, press the [C] key.



1

2


4

Press the [DONE] key.

The display returns to the Basic Features screen.

3

5

Press the  (START) key.

The documents are scanned to memory, and will be sent at the preset transmission time.

4

5

6

7

8

9

10

11

Using the Remote Control Features

The remote control features enable you to send documents to your 3121 series machine in Memory Lock mode, or to transfer memory lock documents from your 3121 series machine in the office by sending tone signal commands from a remote fax.

Controlling Your Machine with Remote Control

MEMO

- Use this procedure to control your 3121 Series machine from another remote fax.
Make sure that the remote control features are enabled beforehand with the Custom FAX Setting (See "Setting Whether to Enable the Use of the Remote Control Feature," on p. 9-55).
- If the remote fax/telephone is connected through a rotary pulse line, it is necessary to set the signal to tone before pressing #. To set to tone signal, refer to the operation manual of the remote fax/telephone. Remote fax units/telephones connected through a rotary pulse line which cannot transmit tone signals are not applicable for use with the remote control features.

1

Pick up the handset of the other fax from which you wish to call your 3121 series machine.

MEMO

- To send the document to your 3121 series machine in Memory Lock mode, the document must be set on the other fax.

2

Use the number keys to dial the fax number of your 3121 series machine.

3

Press # when you hear the beep from your 3121 series machine.

4

Use the number keys to enter the remote control commands after you hear the beeping (three short beeps followed by a long one), confirming the signal has been received successfully.

MEMO

- If you hear a quick beeping sound, repeat step 1 to 3 again to establish the connection.
- You will hear a tone while entering commands to confirm that the command has been acknowledged. Refer to the list of remote commands on p. 7-8 for details.

5 Press # twice to end the remote control.

When the remote commands are acknowledged successfully, you will hear three short beeps followed by a long one.

MEMO

- Enter #999# when you make a mistake and repeat from step 4.

6 Press START.

The 3121 series machine will start transmission based on the remote command entered.

7 Hang up the handset.

1

2

3

4

5

6

7

8

9

10

11

List of remote control commands

Use the keypad keys (0-9, *, #) on the remote fax machine to send tones to your 3121 series machine that can control it remotely.

Function	Command	Comments
Memory Lock	#100#	Use this command when Memory Lock has been turned off on your 3121 series machine, but you wish to receive a document in Memory Lock mode. This document is then received in memory without printing.
Memory Lock Transfer	#110* MEMORY LOCK PASSWORD#	Use this command to transfer "memory locked" documents from your 3121 series machine to the remote fax that you are calling from. Enter 0000 if a password is not registered.
Communication Report	#900* TRANSACTION NUMBER#	Informs the result of the communication with a tone.
Command Cancel	#999#	Cancels the remote commands for your 3121 series machine.
End	##	Terminates the remote operations for your 3121 series machine.

List of remote control acknowledgements

Your 3121 series machine responds to the remote control commands with the following signals.

Response	Tone	Comments
1. ACKNOWLEDGED	Three short beeps followed by one long beep	The command is successfully acknowledged.
2. NOT ACKNOWLEDGED	Three short intermittent double beeps	The command is not successfully acknowledged.
3. REJECTED	Three short beeps	The command is rejected.
4. CANCELED	One long beep	The command is cancelled.
5. END	One low-pitched tone	The communication has successfully ended.
6. ERROR	Short siren-like tones	The communication has not successfully ended.
7. NO DOCUMENT	Long siren-like tones	The document is not found.
8. REDIAL	Three intermittent triple rings	Redialling and standing by.
9. RESERVE	Five alternating high-low tones	Preset and delayed transaction is operated.

Special Dialling

Enter telephone numbers as described below when the 3121 is connected to an extension, when you want to store international telephone numbers or when you subscribe to an alternative long-distance service such as the 2300 Service of Mercury Communications Limited.

■ **Calling from an Extension**

When calling an outside line from an extension, the outside line access number (such as 0) is normally dialed before the telephone number of the destination. In the same manner, when the 3121 is connected to an extension, the outside line access number is stored before telephone numbers. A pause time (i.e., the amount of time the unit waits after dialling the outside line access number when calling from an extension) can also be stored together with these numbers.

■ **International Dialling**

A pause time (i.e., the amount of time the unit waits after dialling the international telephone number) can be stored together with an international telephone number.

■ **Dialling with an Alternative Telephone Network (UK only)**

If you subscribe to an alternative long-distance service such as the 2300 Service of Mercury Communications Limited, you can use this service by using the M key. In this case, the M key is pressed first before dialling a telephone number. A “pause time”, an amount of time that the unit waits after dialling an alternative telephone network access number, can also be stored with these numbers. It is also possible to store telephone numbers for Coded Speed Dialling or One-Touch Speed Dialling. However, before you can use an alternative long-distance service, you must first make sure that an access code is registered in the System Management Settings. (See “System Management Settings,” on p. 9-51.)

1

2

3

4

5

6

7

8

9


10

11

Calling from an Extension

Only the procedure for entering telephone numbers is described here.
See "Selecting the R-key Setting," on p. 9-58 for setting the R-key.

1 Press the [R] key.



2 Enter the pause time between the outside line access number and the telephone number.

e.g.:

Outside line access number: R


Telephone number: 516 328 5841

0 [PAUSE] 516 328 5841

Press [PAUSE] after entering the outside line access number and before entering the telephone number.

Enter the pause time equivalent in length to the time required for the outside line dial tone to be heard after the outside line access number is called.

If you make a mistake during entry, press the [BACK SPACE] key to delete the number, then enter the correct number again. Or press [◀] and [▶] to move the cursor, then overwrite, or press the © (CLEAR) key to erase the entire number, then re-enter from the beginning.




3 Press [OK].

The telephone number is now entered.

MEMO

- The difference between the pause time entered in the middle of a telephone number and at the end of a telephone number is as follows.
- The pause time entered in the middle of a telephone number (lower-case p) is 4 seconds long.
- The pause time entered at the end of a telephone number (upper-case P) is 10 seconds long. (This length cannot be changed.)
- Two or more pauses can be entered consecutively.
- The length of pause time entered in the middle of a telephone number is preset to 4 seconds for each time you press [PAUSE]. However, this length can be changed to any whole number between 4 and 11 seconds. (See "Setting the Pause Time," on p. 9-38.)



Storing International Telephone Numbers

Describes the procedure for entering pauses with international telephone numbers that you want to store.

1


Enter the international telephone number and the pause time.

- If using an international telephone service:

e.g.
01015164806700
International Dialling Code: 010
Country code: 1
Area code: 516
Telephone number: 480-6700
[PAUSE]

Enter a pause time equal to the time required for the dial tone to be heard after dialling is completed. A pause entered at the end of a telephone number is 10 seconds long.

If you make a mistake during entry, press the [BACK SPACE] key to delete the number, then enter the correct number again. Or press [◀] and [▶] to move the cursor, then overwrite, or press the © (CLEAR) key to erase the entire number, then re-enter from the beginning.



Pause time (10 sec.)


2

Press [OK].

The international telephone number is now stored.

MEMO

- The pause time differs in length, depending on whether it is entered in the middle or end of a telephone number.
- The pause time entered in the middle of a telephone number (lower-case p) is 4 seconds long.
- The pause time entered at the end of a telephone number (upper-case P) is 10 seconds long. (This length cannot be changed.)
- Two or more pauses can be entered consecutively.
- The length of the pause time entered in the middle of a telephone number is preset to 4 seconds for each time you press [PAUSE]. However, this length can be changed to any whole number between 4 and 11 sec. (See "Setting the Pause Time," on p. 9-38.)
- The location of a pause and the actual pause time may differ depending on the telephone system. Contact your Service representative or your local telephone company for further details.



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15


16

17


Dialling with an Alternative Telephone Network (UK only)

Only the procedure for entering telephone numbers is described here.
See "Selecting the M-key Setting," on p. 9-59 for setting the M-key.


1 Press the [M] key.



2 Enter the telephone number with the Number keys.
e.g.:
Mercury Communications 2300 Service access number: M
Telephone number: 516 328 5841




3 Press [OK].




Chapter 8

Communications Using the Memory Box and Subadress

This chapter tells how to transmit and receive documents using “memory boxes” and passwords/subaddresses in Special Features mode.



■ Communications Using the Memory Boxes.....	2
■ Memory Box Operations (MEMORY BOX).....	10
■ Communications Using the Subadress (PSWD/SUBADDRESS).....	16



Communications Using the Memory Box

What is a “Memory Box?”

A “memory box” is a special section of the machine’s memory that you can think of as rather like a pigeon-hole you might use for receiving mail. You can use the machine’s memory boxes for receiving documents by FAX, storing scanned documents to be sent, or printing received documents. The memory box requires you to use subaddresses and RX passwords defined in the ITU-T standard. (The ITU-T is a committee within the International Telecommunications Union established for setting communications standards.)

The memory boxes allow you to use functions with not only other Océ machines, but also any other machine that supports subaddress and RX passwords that conform to the ITU-T standard.

MEMO

- Increasing numbers of manufacturers have begun using the ITU-T standard for their machines’ communications signals.

The machine uses subaddresses to distinguish between different memory boxes, and RX passwords to prevent mistakes when sending or receiving documents.

When a subaddress or password conforming to the ITU-T standard is set, the sender and the receiver can communicate only when they use the same subaddress and RX password. (See “Storing Polling, Confidential, Relay, Batch Sending, Bulletin Board, and General Memory Boxes,” on p. 9-62.)

MEMO

- When subaddress or RX passwords have been set, communication is possible when the subaddresses match or the RX passwords for the transmitting machine and receiving machine match.
- Communication is possible only when the subaddresses or RX passwords, including spaces, match.

What Can the Memory Boxes Do?

The following briefly introduces a few of the functions that the memory boxes provide.

- (1) **Naming documents**
Giving documents a name makes it easier to search for them when scanning documents to a memory box or printing documents stored in a memory box.
- (2) **Limiting the number of memory box users**
Assigning memory boxes an ID number allows you to limit the number of users that can use them to scan, print, or change settings.
- (3) **Sending documents in response to a request from another party's FAX**
You can scan documents into a memory box so they can be sent in response to requests from another party's FAX machines.
- (4) **Limiting the number of FAX destinations**
Assigning an RX password to a memory box allows you to prevent the machine from receiving documents that have different RX passwords.
Once you've assigned an RX password, you can send documents only if the RX password matches that in the receiving FAX, even if a remote FAX requests that your machine transmit documents in a memory box.
- (5) **Sending documents at a preset time**
Documents in a memory box can be sent automatically at a preset time and date.

By combining these functions, you can set up your own unique memory box. (See "Setting the General Memory Box," on p. 9-76.)

The machine comes equipped with the following five memory boxes. The functions for these boxes are preset, which does away with the need for making complicated settings.

- **Polling box (See p. 8-4.)**
- **Confidential memory box (See p. 8-5.)**
- **Relay memory box (See p. 8-6.)**
- **Batch sending memory box (See p. 8-7.)**
- **Bulletin board memory box (See p. 8-8.)**

This chapter describes how to use each of these memory boxes

1

2

3

4

5

6

7

8


9

10

11

Using the Polling Box

If you dial your machine from a remote FAX and request Polling Reception, documents already scanned to the polling box can be sent to the remote FAX.



1

Set the polling box.

The following items are stored and set in File Settings under Custom FAX Settings. (See "Setting the Polling Memory Box," on p. 9-63.)

- Box name*
- Password to limit the numbers of users who have access to perform operations and settings to the memory box
- Delete documents YES/NO

MEMO

- The above items marked by asterisks (*) need not be stored or set.

2

Scan the document to the polling box. (See "Scanning Originals to a Memory Box," on p. 8-10.)


3

Dial your machine's telephone number from the remote FAX, and request Polling Receiving.

The machine then sends the document to the remote FAX.

Using the Confidential Memory Box

This memory box is for receiving confidential documents. When sending documents to the confidential memory box, the other party must specify the confidential memory box's subaddress and RX password in addition to your machine's telephone number. You must enter the password to print documents from the confidential memory box.



1

Set a confidential memory box.

The following items are stored and set in File Settings under Custom FAX Settings. (See "Setting the Confidential Memory Box," on p. 9-65.)

- Box number
- Box name*
- Password to limit the numbers of users who have access to perform operations and settings to the memory box
- Subaddress
- RX password* to limit the documents that can be received by the memory box

MEMO

- The above items marked by asterisks (*) need not be stored or set.

2

Give the subaddress and RX password to the parties who will be sending documents to the memory box.

3

The other parties can now send documents to the confidential memory box.

4

Enter the password to print documents stored in the confidential memory box. (See "Printing and Deleting Documents in the Memory Box," on p. 8-13.)

1

2

3

4

5

6

7

8


9

10

11

Using the Relay Memory Box

The relay memory box allows you to forward received documents to other parties from your machine. It also allows you to send an entire set of documents at a specified time. If you ask another party's FAX located far from your machine to relay a document through your machine to several destinations located near your machine, you can in effect send the document to those destinations with only one long-distance call, thus reducing the telephone charges for the other party's FAX.



1

Set the relay memory box.

The following items are stored and set in File Settings under Custom FAX Settings. (See "Setting the Relay Memory Box," on p. 9-67.)

- Box number
- Box name*
- Password* to limit the numbers of users who have access to perform operations and settings to the memory box
- Subaddress
- RX Password* to limit the documents that can be received by the memory box
- Selection of original unit ON/OFF
- Original relay unit*
- Printing of received original ON/OFF
- Destination
- Transmission start time*
- Relay transmission report ON/OFF

MEMO

- The above items marked with asterisks (*) need not be stored or set.

2

Give the subaddress and password to the parties who will be using your machine to relay documents.

3


The other parties can now send documents to the relay memory box, and the documents it receives will be sent on to the destinations you've specified.

MEMO

- Documents can be received only when the other party's FAX dials the correct subaddress and RX password.
- Your machine prints a report each time it receives a document in its relay memory box.

Using the Batch Sending Memory Box

The batch sending memory box allows you to send documents scanned to it to a specific destination at a specific time every day. Since the machine can send several documents at once, this reduces the time it takes to send the documents and so reduces transmission costs. You can reduce costs even further by setting the machine to transmit during a period with low telephone rates



1

Set the batch sending memory box.

The following items are stored and set in File Settings under Custom FAX Settings. (See "Setting Batch Sending Memory Box," on p. 9-71.)

- Box number
- Box name*
- Password* to limit the numbers of users who have access to perform operations and settings to the memory box
- Destination
- Transmission start time

MEMO

- The above items marked with asterisks (*) need not be stored or set.

2

Scan the document to the batch sending memory box. (See "Scanning Originals to a Memory Box," on p. 8-10.)

3

The scanned document is sent at the preset time.

1

2

3

4

5

6

7

8

9


10

11

Using the Bulletin Board Memory Box

Documents scanned to the bulletin board memory box can be sent to another party's FAX if the other party specifies the bulletin board memory box's subaddress and RX password along with your machine's telephone number.

You could, for example, scan important information relating to inventory or new products to the bulletin board memory box, so that anyone who needs the information could retrieve it.



1

Set the bulletin board memory box.

The following items are stored and set in File Settings under Custom FAX Settings. (See "Setting the Bulletin Board Memory Box," on p. 9-73.)

- Box number
- Box name*
- Password* to limit the numbers of users who have access to perform operations and settings to the memory box
- Subaddress
- RX password*
- Delete document ON/OFF*

MEMO

- The above items marked with asterisks (*) need not be stored or set.

2

Scan the document to the bulletin board memory box. (See "Scanning Originals to a Memory Box," on p. 8-10.)

3

Give the subaddress and RX password to the parties who will be using your machine to receive documents from the bulletin board memory box.

MEMO

- Documents can be received only when the other party's FAX dials the correct subaddress and RX password.

4

The other party can now dial your machine's telephone number, along with the bulletin board memory box's subaddress and RX password, and request Polling Receiving.

1

The document is sent to the other party's FAX

2

3

4

5

6

7

8

9

10

11

Memory Box Operations (MEMORY BOX)

Scanning Originals to a Memory Box

MEMO

- Memory boxes must be stored and set before you can use them. (See “Storing Polling, Confidential, Relay, Batch Sending, Bulletin Board, and General Memory Boxes,” on p. 9-62.)

Place your originals.

- For instructions on how to place an original on the platen glass, see “Placing an Original on the Platen Glass,” on p. 3-10.
- For instructions on how to place originals in the ADF, see “Placing Originals in the ADF,” on p. 3-11.
- For instructions on how to place originals in the RDF, see “Placing Originals in the RDF,” on p. 3-14.

MEMO

- You can set the resolution, density, and image quality to suit the document you’re sending. (See “Setting Resolution, Density, and Image Quality to Match the Original,” on p. 3-31.)
- You can set the sender’s name. (See “Changing the Sender’s Name,” on p. 3-33.)
- You can edit originals before sending them. (See Chapter 4, “Editing Documents Before Sending Them.”)

1

Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.

Ready to send. 3/1/03 15:00
AUTO

☎ =

STANDARD : STANDARD : TEXT AUTO RX

RESOL. : DENSITY : IMAGE QUALITY

R M

CODED DIALING ON-HOOK REDIAL

SPECIAL FEATURES

FAX MONITOR

2

Press the [MEMORY BOX] key.

DELAYED TX POLLING RX DIRECTORY

MEMORY BOX PSWD/ SUBADDRESS SENDER'S NAMES (TTI)

RX MODE

SCANNING MODE DOCUMENT SIZE TEST PRINT

IMAGE PROCESSING ZOOM TX 2 ON 1 TX

DONE

FAX MONITOR


3


The memory boxes you have stored or set appear.


Press the [▼] or [▲] keys to display the memory box you want, then select the box number.

MEMO

- You can also enter the box number directly with the Number keys, instead of selecting the box number in the touch panel display.

 :Indicates that the box does not contain a document.


 :Indicates that the box contains a document.



4

If you've set a password for the selected memory box, the display on the right appears in the touch panel display.


Enter the password, then press the [OK] key




- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

5


Select the [SCAN] key.




The display on the right appears.





6

Press the  (START) key.

- **When originals are placed in the ADF/RDF:**
The display on the right appears. Continue to scan originals.



- **When an original is placed on the platen glass:**
 - The display on the right appears for each original you scan. To continue scanning documents, press the  (START) key. When you have finished scanning, press the [DONE] key.



- To manually change the scanning size of the next document, press the [DOCUMENT SIZE] key. The display on the right appears in the touch panel display. Select the scanning size, then press the [OK] key.

The machine scans the originals to the specified memory box, and automatically sends them according to the memory box settings.

MEMO

- To cancel scanning, press the [C] key.

Specify the document size.

A4 A4B A3
A5 A5B A6B
B4 B5 B5B

A/B-SIZE INCH-SIZE

C OTHER SIZE AUTO

OK

FAX MONITOR

1

Printing and Deleting Documents in the Memory Box

Follow the procedure below to manually print or delete documents in the memory box.

1

Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.

Ready to send. 9/1/03 15:00 AUTO

STANDARD STANDARD TEXT AUTO RX

RESOL. DENSITY IMAGE QUALITY DIRECT

R M STAMP

CODED DIALING ON-HOOK REDIAL

SPECIAL FEATURES

FAX MONITOR

2

Press the [MEMORY BOX] key.

DELAYED TX POLLING RX DIRECTORY

MEMORY BOX PSWD/ SUBADDRESS SENDER'S NAMES (TTI)

RX MODE

SCANNING MODE DOCUMENT SIZE TEST PRINT

IMAGE PROCESSING ZOOM TX 2 ON 1 TX

DONE

FAX MONITOR

3

Press the [▼] or [▲] keys to display the memory box, then select the box number.

MEMO

- You can also enter the box number directly with the Number keys, instead of selecting the box number in the touch panel display.

:Indicates that the box does not contain a document.

:Indicates that the box contains a document.

Select a memory box. (00~99)

00 POLLING RX:

01 RELAY:

02 BATCH SEND:

03 BULLETIN BOARD:


DONE

FAX MONITOR

4


If a password has been set for the specified memory box, the display on the right appears in the touch panel display.

Enter the password, then press the [OK] key.



5

Select the document to print or delete.



6

■ **To print documents:**

Press the [OUTPUT] key.

The display on the right appears, and the selected document is printed.

MEMO

- To cancel printing, press the [CANCEL] key.

When the document is printed, the display returns to that shown in step 5.



■ **To delete documents:**

Press the [ERASE] key.

The display on the right appears.

MEMO



- Select the [YES] or [NO] key.



6

Press the [DONE] key.

The display returns to that shown in step 3.



7

Press the [DONE] key.

The display returns to the Special Features screen.

8

Press the [DONE] key.

The display returns to the Basic Features screen.

1

2

3

4

5

6

7

8

9

10

11

Communications Using the Subaddress

(PSWD/SUBADDRESS)

To send or receive documents to and from a FAX machine using subaddresses and RX passwords defined in the ITU-T standard (ITU-T is a committee within the International Communications Union established to set communications standards), the subaddresses and RX passwords must be dialed in addition to the telephone numbers.

MEMO

- The subaddress and RX password can be stored for One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling. (See "Storing Destinations," on p. 9-17.)

Sending Documents

1

Make sure you know the other party's subaddress and RX password.

2

Place your originals.

- For instructions on how to place an original on the platen glass, see "Placing an Original on the Platen Glass," on p. 3-10.
- For instructions on how to place originals in the ADF, see "Placing Originals in the ADF," on p. 3-11.
- For instructions on how to place originals in the RDF, see "Placing Originals in the RDF," on p. 3-14.

MEMO

- You don't have to set the resolution, density, and image quality to suit the document you're sending. (See "Setting Resolution, Density, and Image Quality to Match the Original," on p. 3-31.)
- You can set the sender's name. (See "Changing the Sender's Name," on p. 3-33.)
- You can edit originals before sending them. (See Chapter 4, "Editing Documents Before Sending Them.")

3

Make sure the machine is ready to send, then press the [SPECIAL FEATURES] key.

Ready to send. 31/03 15:00
AUTO

☎ =

STANDARD : STANDARD : TEXT AUTO RX


RESOL.	DENSITY	IMAGE QUALITY	DIRECT
R	M		STAMP
CODED DIALING	ON-HOOK	REDIAL	

SPECIAL FEATURES

FAX MONITOR

4

Press the [PSWD/SUBADDRESS] key.



1

2

5

Enter the subaddress and RX password of the other party's FAX with the Number keys, then press the [OK] key.

■ **To enter the subaddress:**

Press the [SUBADDRESS] key, then enter the sub-address.


■ **To enter the TX password:**

Press the [PASSWORD] key, then enter the RX password.

MEMO

- You don't have to enter the subaddress and RX password if the other party has not set them.

The display returns to the Special Features screen.



3

4

6

Press the [DONE] key.

The display returns to the Basic Features screen.

6

7

7

Specify the other party's telephone number. (See "Specifying a Destination," on p. 3-20.)


MEMO


- If the specified telephone number is appended with a subaddress or RX password when specifying a destination by One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling after specifying the address, this subaddress and RX password take precedence.

8

9

8

Press the  (START) key.



10

11

Receiving Documents

1

Make sure the machine is ready to receive. Press the [SPECIAL FEATURES] key.

Ready to send. 31/03 15:00
AUTO

☎ =

STANDARD | STANDARD | TEXT | AUTO RX

RESOL. | DENSITY | IMAGE QUALITY | DIRECT

R | M | STAMP

CODED DIALING | ON-HOOK | REDIAL

SPECIAL FEATURES

FAX MONITOR

2

Press the [PSWD/SUBADDRESS] key.

DELAYED TX | POLLING RX | DIRECTORY

MEMORY BOX | PSWD/SUBADDRESS | SENDER'S NAMES (TT)

RX MODE

SCANNING MODE | DOCUMENT SIZE | TEST PRINT

IMAGE PROCESSING | ZOOM TX | 2 ON 1 TX

DONE

FAX MONITOR

3

Enter the subaddress and RX password of the other party's FAX with the Number keys, then press the [OK] key.

■ **To enter the subaddress:**

Press the [SUBADDRESS] key, then enter the sub-address.

■ **To enter the RX password:**

Press the [PASSWORD] key, then enter the RX password.

MEMO

- Do not enter the RX password if the other party has not set it.

The display returns to the Special Features screen.

Enter subaddress/password. (Up to 20 digits.) C

SUB-ADDRESS []


PASSWORD []

SPACE | BACK SPACE | OK

FAX MONITOR

4

Press the [POLLING RX] key.



1

2

5

Press the [DONE] key.

The display returns to the Basic Features screen.

3

6

Specify the other party's telephone number. (See "Specifying a Destination," on p. 3-20.)

MEMO

- If the specified telephone number is appended with a subaddress and RX password when specifying a destination by Redialling, One-touch Speed Dialling, Coded Speed Dialling and Directory Dialling after specifying the address, this subaddress and RX password take precedence.

4

5

7

Press the  (START) key. The documents are sent from the other party's FAX.

MEMO

- If your machine does not receive the documents after several attempts, check again to make sure the subaddress and RX password match.

6

7

8

9


10

11


Chapter 9

Storing and Setting Custom FAX Settings

This chapter describes how to change your machine's default settings to suit your specific needs.



■ What are "Additional Functions?"	2
■ Storing User Settings (USER SETTINGS)	5
■ Storing Destinations (STORE DESTINATIONS)	17
■ Setting Transmission Functions (TX SETTING)	35
■ Setting Reception Functions (RX SETTING)	44
■ System Management Settings (SYSTEM SETTINGS)	50
■ File Settings (FILE SETTINGS)	60
■ Print Settings (PRINT SETTINGS)	94
■ Printing Reports (REPORT SETTINGS)	102
■ Printing Lists (PRINT LIST)	109



What are “Additional Functions?”

When you turn the power ON or press the [Z] (RESET) key, the machine returns to its default settings.

“Additional functions” is another term for custom settings. Additional functions allow you to change default values for each of the machine’s modes, or to choose whether a mode is to be used.

This section describes how to make and store Custom FAX Settings.


MEMO

- For additional information, see the following: For Custom Common Settings, see “What are ‘Additional Functions’,” on p. 3-2 in the *Reference Manual*. For Timer Settings, see “Timer Settings,” on p. 3-29 in the *Reference Manual*. For Adjustment/Cleaning, see “Adjustment/Cleaning,” on p. 3-36 in the *Reference Manual*.
- For information on Custom Copy Setting, see Chapter 8 of the *Copying Manual*.

Calling Up the Custom FAX Settings Screen

1


Press the [⊕] (ADDITIONAL FUNCTION) key.



2


The Additional Function screen appears.

Select the [CUSTOM FAX SETTINGS] key in the screen.



3

The Customs FAX Settings screen appears in the touch panel display.



Items You Can Store and Set in the Custom FAX Settings Screen

You can store and set the following items with the [CUSTOM FAX SETTINGS] key.

Setting Mode	Store/Set Item	Screen No.	See Page
User Settings	UNIT TELEPHONE #	1/4	1-18
	UNIT NAME		1-20
	SENDER'S NAMES [TTI]		9-7
	TX TERMINAL ID	2/4	9-8
	DENSITY CONTROL		9-10
	TEL LINE TYPE		1-16
	AUDIBLE TONES	3/4	9-10
	VOLUME CONTROL		9-11
	SET DIRECTORY GENERAL CONTENTS		9-12
	STANDARD KEY1 SETTING	4/4	9-14
Store Destinations	STANDARD KEY2 SETTING		9-14
	STANDARD SETTING		9-15
	ONE TOUCH DIALLING	—	9-19
	CODED DIALLING		9-22
	GROUP DIALLING		9-27

MEMO

- You can also store One-touch Speed Dialling, Coded Speed Dialling, and Group Dialling destinations for directory dialling.

Transmission Settings	ECM TX	1/3	9-37
	PAUSE TIME		9-38
	AUTO REDIAL		9-39
	BATCH TX	2/3	9-41
	ERASE FILED TX		9-41
	TIME OUT		9-42
	STAMP DOCUMENT	3/3	9-43
Reception Settings	ECM RX	1/3	9-46
	INCOMING RING		9-47
	MEMORY RX	2/3	9-48
	RX PAGE FOOTER	3/3	9-49
System Settings	RX RESTRICT	1/3	9-52
	TX START SPEED		9-53
	RX START SPEED		9-54
	REMOTE CONTROL	2/3	9-55
	RX PASSWORD		9-56
	☎ SW Setting		9-57
	R-KEY SETTING	3/3	9-58
	M-KEY SETTING		9-59

1

2

3

4

5

6

7

8

9

10

11

Setting Mode	Store/Set Item	Screen No.	See Page
File Settings	MEMORY BOX STORE/SET PRESET POLLING SETTING TRANSFER SETTING	1/2	9-62 9-84 9-86
	MEMORY LOCK SETTING	2/2	9-90
Print Settings	# OF RX COPIES SELECT CASSETTE RX REDUCTION	1/2	9-96 9-97 9-98
	TWO-SIDED PRINT N ON 1 LOG	2/2	9-100 9-101
Report Settings	TX REPORT RX REPORT MEMORY BOX REPORT	1/2	9-104 9-105 9-106
	ACTIVITY REPORT	2/2	9-107
Print Lists	1-TOUCH SPEED DIAL LIST 1 1-TOUCH SPEED DIAL LIST 2 CODED SPEED DIAL LIST 1	1/2	9-111 9-112 9-112
	CODED SPEED DIAL LIST 2 GROUP DIAL LIST USER'S DATA LIST	2/2	9-112 9-113 9-113

Storing User Settings (USER SETTINGS)


You can use the User Settings screen to store and set the following items.

NOTICE

- This section does not describe the items listed in "Settings to Store After Installing the Machine," on p. 1-15.

MEMO

- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 of the *Reference Manual*.

Store/Set Item and Description	Initial Setting (*) and Available Settings	See Page	Screen No.
UNIT TELEPHONE # This is your machine's telephone number. The receiving FAX prints this number on the FAX document as part of the sender information.	No default* (up to 20 digits)	1-18	1/4
UNIT NAME This is your company or department name. The receiving FAX prints this name on the FAX document as part of the sender information.	No default* (up to 24 characters)	1-20	
SENDER'S NAMES [TTI] This is your section name or an individual's name. If you set the sender's name when sending documents, the receiving FAX prints it instead of the unit name on the FAX document.	No default* (up to 99 names, 24 characters)	9-7	
TX TERMINAL ID Controls whether the machine prints the transmission terminal ID on FAX documents. (TTI IN/OUTSIDE OF IMAGE) This controls where the transmission terminal ID is printed. (TELEPHONE # MARK) This selects the icon printed before the telephone number.	ON* OFF OUTSIDE* INSIDE FAX* 	9-8	2/4
DENSITY CONTROL Sets the standard scanning density for FAX operations.	5* 1 to 9	9-10	
TEL LINE TYPE Sets the type of telephone line connected to your machine.	ROTARY PULSE TOUCH TONE*	1-16	
AUDIBLE TONES (DIAL TONE) Sets the dial tone ON or OFF.	ON* OFF	9-10	3/4
VOLUME CONTROL (MONITOR VOL.) Sets the volume of communication tones.	4* 0 to 8	9-11	
SET DIRECTORY GENERAL CONTENTS Allows you to store the names of the two user content keys in the Directory screen.	GENERAL1*, GENERAL2* (up to 8 characters)	9-12	
STANDARD KEY1/2 SETTING Controls the standard key displayed in the Basic Features screen.	NO* (keys in Special Features screen can be set)	9-14	4/4
STANDARD SETTINGS Sets the FAX Standard mode when the power is turned ON or the RESET key is pressed. You can set the default values for resolution, density, image quality, direct transmission, and document stamp. These settings can also be returned to their original values.	Resolution: Standard* Density: Normal* Image quality: Text* Direct: OFF* Stamp: OFF*	9-15	

1

2

3

4

5

6

7

8


9

10

11

Calling Up the User Settings Screen

- 1 Press the [USER SETTINGS] key in the Custom FAX Settings screen.




- 2 The User Settings screen appears. This screen is made up of four screens (1/4, 2/4, 3/4, and 4/4).


Press the [▼] or [▲] keys to display the desired screen and make the required settings.

[User Settings Screen]


1/4 screen




2/4 screen



3/4 screen



4/4 screen



The descriptions in the rest of this section assume that you are operating from the User Settings screen.

Storing Individual's Names (SENDER'S NAME (TTI))

You can store up to 99 names (individual names, department names, section names, etc.) in the machine. When you have sent an original, the name stored by Sender's Name (TTI) is printed on the recording paper output on the remote FAX as sender information. Some FAX models also display sender information during communication.


MEMO

- If the sender's name is selected in the Special Features mode while sending originals, the stored sender's name is printed in the sender information instead of the unit name.
- Select the sender's name under Sender's Name in the Special Features screen. (See "Changing the Sender's Name," on p. 3-33.)

- 1 Press the [▼] or [▲] keys to display the 1/4 screen, and press the [SENDER'S NAMES (TTI)] key.

MEMO


- When the machine first comes from the factory, no sender's name is stored.



- 2 Press the [▼] or [▲] keys to display the number to store the sender's name to. Select the number, then press the [STORE] key.

MEMO


- You can also enter and display the number directly with the Number keys, instead of selecting the box number on the touch panel display.
- You can store up to 99 names.



- 3 The name entry display appears. Enter the sender's name, then press the [OK] key.

MEMO

- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- You can enter up to 24 characters in the UPPER, LOWER, and OTHER modes. (UPPER and LOWER refer to upper- and lower-case letters, respectively, and OTHER refers to special letters and symbols.)



The display returns to User Settings screen 1/4.

Assigning the Transmission Terminal ID (TX TERMINAL ID)


You can set the machine to print the transmission terminal ID in the headers of the documents you send.
(See the following page.)

1

Press the [▼] or [▲] keys to display the 2/4 screen, then press the [TX TERMINAL ID] key.

MEMO

- The default setting is "ON."




2

Select the [ON] or [OFF] key.

■ To enable printing of the transmission terminal ID:

Press the [ON] key, select the printing position ([OUTSIDE] or [INSIDE]) and the telephone number mark to be printed, then press the [OK] key.

- Printing position
 - [OUTSIDE] of image:
This prints the transmission terminal ID outside the image area on the output FAX.
 - [INSIDE] of image:
This prints the transmission terminal ID inside the image area on the output FAX.
- Telephone number mark
 - [FAX]:
This prints the letters "FAX" before the telephone number.
 - [☎]:
This prints the ☎ (telephone) mark before the telephone number.




■ To disable printing of the transmission terminal ID:

Press the [OFF] key, then press the [OK] key.

The display returns to User Settings screen 2/4.

The following shows two examples of how headers are printed on FAX documents.



1

2

3

4

5

6

7

8

9

10

11


Setting the Standard Density for Scanning Documents

(DENSITY CONTROL)

You can use the Basic Features screen to set the standard density for scanning documents in Density Control mode.

1

Press the [▼] or [▲] keys to display the 2/4 screen, then press the [DENSITY CONTROL] key.




2

Press the [LIGHT] or [DARK] keys to set the scanning density, then press the [OK] key.

MEMO

- The scanning density can be set from 1 to 9.
- The initial default setting is 5.




The display returns to User Settings screen 2/4.

Setting the Dial Tone (AUDIBLE TONES)

1

Press the [▼] or [▲] keys to display the 3/4 screen, then press the [AUDIBLE TONES] key.




2

Set the dial tone ([DIAL TONE]), then press the [OK] key.

[DIAL TONE]:

Set the dial tone (the tone that sounds when dialing another party's telephone number) ON or OFF.



1

2


3

4

Adjusting the Monitor Volume (VOLUME CONTROL)

1

Press the [▼] or [▲] keys to display the 3/4 screen, then press the [VOLUME CONTROL] key.



5

6


7

2

Press the [▲] or [▼] keys to set the monitor volume ([MONITOR VOL.]), then press the [OK] key.
The volume can be set from 0 to 8.

■ [MONITOR VOL.]:

Set the volume of the tones used during communications (for example, the tone you can hear when your machine connects with another FAX).



8

9

10

11

The display returns to the User Settings screen 3/4.

Storing the Names of User Content Keys


(SET DIRECTORY GENERAL CONTENTS)

The directory is provided with alphabetical content keys and two general keys (GENERAL 1 and GENERAL 2). You can name these user content keys, and display them in the Directory screen. This section describes how to change and store names to these user content keys.


MEMO

- For details on how to store One-touch Speed Dialling and Coded Speed Dialling destinations to user content keys, see “Storing Destinations,” on p. 9-17.

- 1 Press the [▼] or [▲] keys to display the 3/4 screen, then select the [SET DIRECTORY GENERAL CONTENTS] key.




- 2 Select the content key for the user whose name you want to change.



- 3 Enter the new name (content), then press the [OK] key.

MEMO


- For details on how to enter characters, see “Entering Characters on the Touch Panel Display,” on p. 2-5 in the *Reference Manual*.



4

Press the [DONE] key.


The display returns to User Settings 3/4.



1

2

Once stored, the user content keys are displayed in the touch panel display as shown on the right.



3

4

5

6

7

8

9


10

11

Setting Standard Keys 1 and 2 (STANDARD KEY SETTING)

You can set standard keys to be displayed in the Basic Features screen. Choose from any two keys that appear in the Special Features screen.


- 1 Press the [▼] or [▲] keys to display the 4/4 screen, then press the [STANDARD KEY 1 SETTING] or [STANDARD KEY 2 SETTING] key.



- 2 Press the [▼] or [▲] keys to display the mode you want to store as a standard key. Select the desired item, then press the [OK] key.


MEMO

- Functions that are displayed for standard keys appear in screens 1/3, 2/3, and 3/3.
- If you want to store no standard keys, select "NO SETTING" in screen 1/3.



Once stored, standard keys 1 and 2 are displayed in the touch panel display as shown on the right.

[Basic Features Screen]



Standard key 1

Standard key 2

- 3 Press the [DONE] key.

The display returns to User Settings 4/4.

Changing the Standard Mode (STANDARD SETTINGS)

This allows you to set the FAX Standard mode that the machine enters when the power is turned ON or the RESET key is pressed.

You can set the default values for resolution, density, image quality, direct transmission, and document stamp, and you can return these settings to their initial values.

MEMO

- Initial settings are as follows:
Resolution : Standard Density : AUTO
Image quality : Text

1

2

3

4

5

6

7

8


9

10

11

Set and store the Resolution, Density, Image Quality, Direct Transmission, and Document Stamp modes in the Basic Features screen.


1 Press the [▼] or [▲] keys to display the 4/4 screen, then press the [STANDARD SETTINGS] key.




2 Select the [STORE] or [INITIALIZE] key.



■ To store a Standard mode:
If you select the [STORE] key, the display on the right appears.
Press the [YES] key.
To cancel, press the [NO] key.




The display on the right appears for about two seconds, and then returns to the previous display.




■ **To initialize a Standard mode:**

If you select the [INITIALIZE] key, the display on the right appears. Press the [YES] key.
To cancel, press the [NO] key.



The display on the right appears for about two seconds, and then returns to the previous display.



3

Press the [DONE] key.

The display returns to User Settings 4/4.

Storing Destinations (STORE DESTINATIONS)

You can set and store the following items in the Store Destinations screen.


MEMO

- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- If you change the stored settings for One-touch Speed Dialling, Coded Speed Dialling, or Group Dialling while sending a document, or while the machine is ready for transmission, the document is sent using the old settings.

Store/Set Item and Description	Initial Setting(*) and Setting Item	See Page
One-touch Speed Dialling Select which One-touch Speed Dialling key you want to store the dialling destination to. Telephone number Store the other party's telephone number with the Number keys. Other party's name Store a name for the destination. Optional settings Set the transmission time, sending speed, long distance, subaddress, and password. Location in directory Set where to store the name in the directory.	(up to 60 destinations) (up to 120 digits) (up to 24 characters) Transmission time: (up to 5) Sending speed: 14,400 bps* Long distance: Domestic* Subaddress: None* Password: None*	9-19 9-23 9-20
Coded Speed Dialling Select to which coded key the dialling destination is to be stored. Telephone number Store the other party's telephone number with the Number keys. Other party's name Store a name for the destination. Optional settings Set the transmission time, sending speed, long distance, subaddress, and password. Location in directory Set where to store the name in the directory.	(up to 140 destinations) (up to 120 digits) (up to 24 characters) Transmission time: (up to 5) Sending speed: 14,400 bps* Long distance: Domestic* Subaddress: None* Password: None*	9-22 9-23 9-20
Group Dialling Select which to store the destination to: One-touch Speed Dialling, Coded Speed Dialling. Telephone number Store the destination from One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling. Other party's name Store a name for the group. Optional settings Set the transmission time. Location in directory Set where to store the name in the directory.	(up to 199 destinations can be stored together with One-touch Speed Dialling and Coded Speed Dialling) (up to 120 digits) (up to 24 characters) (up to 5 separate times using the 24-hour clock) Select from A to Z, and two user content keys.	9-27 9-20

Calling Up the Store Destinations Screen

- 1 Press the [STORE DESTINATIONS] key in the Custom FAX Settings screen.




- 2 The Store Destinations screen appears. Select the [ONE-TOUCH DIALLING], [CODED DIALLING], or [GROUP DIALLING] key, and set the desired items in the screen.

If a destination has already been stored, that destination's stored settings appear.

MEMO

- Only "OPTION" has an initial setting.

If no destination has been set, the display on the right appears in the touch panel display.



The descriptions in the rest of this section assume that you are operating from the Store Destinations screen.

Storing One-touch Speed Dialling Destinations (ONE-TOUCH DIALLING)

You can store up to 60 destinations to the One-touch Speed Dialling keys. Each One-touch Speed Dialling key can store a telephone number (of up to 120 digits) and a name for the destination (up to 24 characters).

MEMO

- In addition to the telephone number and other party's name, you can also set communication options such as the set time and subaddress. (See p. 9-23.)

1 Press the [ONE-TOUCH DIALLING] key.




2 Press the [▼] or [▲] keys to display a One-touch Speed Dialling key number that does not already contain a destination, then press the [STORE] key.

To change a destination already stored to a One-touch Speed Dialling key, display the desired One-touch Speed Dialling key number and press the [STORE] key.

MEMO

- You can display One-touch Speed Dialling numbers by pressing the One-touch Speed Dialling keys on the control panel.
- You can also display One-touch Speed Dialling numbers by entering One-touch Speed Dialling numbers with the Number keys.
- To delete stored settings, display the setting you want to delete, then press the [DELETE] key.



1

2

3

4

5

6

7

8

9

10


11

3

Enter the telephone number with the Number keys, then press the [OK] key.

MEMO

- The telephone numbers can have up to 120 digits.
- If you make a mistake when entering the telephone number, press the [BACK SPACE] key to delete the number, then enter the correct number again. Or, press the [◀] or [▶] keys to move the cursor to the wrong digit, then enter the correct digit.
- To cancel, press the [C] key. The telephone number will not be stored, and the display will return to the previous screen.



- [PAUSE] : When you register a long distance number, you may have to insert a pause either within or after the number. For long distance dialling, the location and length of the pause may differ depending on the telephone system. (See "Setting the Pause Time," on p. 9-38.)
If you press the [PAUSE] key between numbers, "p" is displayed. If you press the [PAUSE] key at the end of a number, "P" is displayed.
- [TONE] : Press this key before entering the extension number when directly calling an extension number connected to a PBX (Public Switched Telephone Network) that accepts only touch-tone signals from a rotary dial line.
- [DT] : Press this key to confirm the dial tone in the middle of the facsimile number before dialling the rest of the number. A dot will be displayed.
- [+] : Press this key to enter a + in your facsimile number.
- [R] : Press this key before entering the telephone number to enter the PBX type through which your machine is connected. Before you can use this key, you have to set it (See "Selecting the R-key Setting," on p. 9-58).
- [M] : Press this key before dialling the number when using an alternative longdistance service such as the 2300 Services of Mercury Communication Limited. Before you can use this key, you have to register it (See "Selecting the M-key Setting," on p. 9-59).
- [OPTION] : Press this key when setting optional communication settings, such as a set time or subaddress. (See p. 9-23.)
- [SPACE] : Press this key to insert a space between numbers.

NOTICE


- Pauses or spaces cannot be entered before telephone numbers.

4

Enter the name, then press the [OK] key.

MEMO

- You can enter up to 24 characters in the UPPER, LOWER, and OTHER modes.
- You can also omit names by pressing the [OK] key without first entering characters.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.




5 Specify where to store the name in the directory, then press the [OK] key.


Example:
To store the name to [A] in the directory,
press the [ABC] key. ABC appears.

MEMO


- You can also store specific dial numbers to user content keys ([GENERAL1] and [GENERAL2]). This feature is handy for storing destinations that you frequently send documents to.
- You can also store any name you like to user content keys ([GENERAL1] and [GENERAL2]).



6 Select the [A] key, then press the [OK] key.



The display on the right appears for about two seconds, then the display returns to the display for storing the One-touch Speed Dialling destinations.



7 Press the [DONE] key.

The display returns to the Store Destinations screen.

Storing Coded Speed Dialling Destinations (CODED DIALLING)

You can store up to 140 destinations to the Coded Speed Dialling keys. Each Coded Speed Dialling key can store a telephone number (of up to 120 digits) and a name for the destination (up to 24 characters).

MEMO

- In addition to the telephone number and abbreviation, you can set communication options such as the set time and subaddress. (See p. 9-23.)

- 1 Press the [CODED DIALLING] key.

Specify the position for storing.
(You can also use the Number keys.)

ONE-TOUCH DIALLING CODED DIALLING GROUP DIALLING

*001 Atlanta Office
416 795 1111

DIRECTORY A

DELETE [Navigation Icons] STORE DONE

FAX MONITOR

- 2 Press the [▼] or [▲] keys to display a Coded Speed Dialling key number that does not already contain a destination, then press the [STORE] key.
To change a destination already stored to a Coded Speed Dialling key, display the desired Coded Speed Dialling key number, then press the [STORE] key.

MEMO

- To delete stored settings, display the setting you want to delete, then press the [DELETE] key.
- You can display Coded Speed Dialling numbers by entering Coded Speed Dialling numbers with the Number keys.

Specify the position for storing.
(You can also use the Number keys.)

ONE-TOUCH DIALLING CODED DIALLING GROUP DIALLING

*002 Not registered.

DIRECTORY

DELETE [Navigation Icons] STORE DONE

FAX MONITOR

- 3 Repeat steps 3 to 6 for One-touch Speed Dialling.

- 4 Press the [DONE] key.
The display returns to the Store Destinations screen.

Optional Settings for One-touch Speed Dialling and Coded Speed Dialling Functions

In addition to the telephone number and other party's name, you can also set communication options such as the transmission time, sending speed, long distance, subaddress, and password.

■ Transmission Time

You can set the machine to send documents automatically up to five times a day.

Specifying the transmission time allows you to periodically send documents to a specific destination. This reduces communications costs.

■ Sending Speed

You can set the sending speed to suit the condition of the telephone line. The initial setting is "14,400 bps." At this setting, your machine automatically determines the best sending speed by matching the receiving FAX machine's speed before sending the document. When sending documents to destinations on bad telephone lines, change this setting first to "9,600 bps." If this does not work, change the setting to "4,800 bps."

■ Long Distance

Set this item if errors often occur when making overseas calls. The initial setting is "DOMESTIC." If errors start occurring, change the setting to "LONG DISTANCE(1)." If errors still occur, change the setting to "LONG DISTANCE(2)," and then to "LONG DISTANCE(3)."

■ PSWD/Subaddress

You can store subaddresses and passwords (of up to 20 digits each) that conform to the ITU-T standard.

- 1 Press the [ONE-TOUCH DIALLING] or [CODED DIALLING] key.

- 2 Press the [▼] or [▲] keys to specify One-touch Speed Dialling or Coded Speed Dialling, then press the [STORE] key.


MEMO

- You can specify One-touch Speed Dialling by pressing the One-touch Speed Dialling keys on the control panel.
- You can also specify One-touch Speed Dialling or Coded Speed Dialling by entering the number with the Number keys.

3

Press the [OPTION] key.

Option setting items appear.



4

Set the items as desired.

■ **To set the transmission time:**



Select the [SET TIME] key.

This setting allows you to periodically send documents to a specific destination.

Enter the transmission time, then press the [OK] key.

MEMO

- Enter a transmission time in the range 00:00 to 23:59.
- You can set up to five transmission times.



■ **To set the sending speed:**

Select the [SENDING SPEED] key.





Select the sending speed (the speed at which transmission is started), then press the [OK] key.

If errors occur frequently at 14,400 bps, change this setting to “9,600 bps”. If errors still occur, change the setting to “4,800 bps”.

■ **To set long distance calls:**

Select the [LONG DISTANCE] key.

Select the [DOMESTIC] key or a [LONG DISTANCE] key, then press the [OK] key.



- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

- **To set the subaddress/password:**
Select the [PSWD/SUBADDRESS] key.

Set the subaddress and password for communicating with a memory box in another party's FAX according to the ITU-T standard.

Enter the subaddress and password, then press the [OK] key.

MEMO

- Subaddresses and passwords can have up to 20 digits .
- Subaddresses and passwords can include spaces.
- If you make a mistake, press the [BACK SPACE] key to delete the number, then enter the correct number.

5

When you finish, press the [OK] key.

6

Continue from step 3 of storing One-touch Speed Dialling destinations.

Storing Group Dialling Destinations (GROUP DIALLING)

Group Dialling lets you select several already stored One-touch Speed Dialling or Coded Speed Dialling destinations, and store them in a single One-touch Speed Dialling or Coded Speed Dialling key. This allows you to specify several destinations in a single operation. You can store up to 199 One-touch Speed Dialling and Coded Speed Dialling destinations in a single Group Dialling set. You can also store the group name.

MEMO

- In addition to storing destinations, you can also set the transmission time. (See p. 9-23.)
- To store destinations in a Group Dialling set, you must have first stored them as One-touch Speed Dialling or Coded Speed Dialling destinations. (See "Storing One-touch Speed Dialling Destinations," on p. 9-19, and "Storing Coded Speed Dialling Destinations," on p. 9-22.)

Setting One-touch, Coded, and Directory Dialling Numbers to a Group

1

Select the [GROUP DIALLING] key.

2

Specify the One-touch Speed Dialling or Coded Speed Dialling numbers to be stored as a Group Dialling set.

■ To specify One-touch Speed Dialling:

Press the [ONE-TOUCH DIALLING] key and press the [▼] or [▲] keys to display a One-touch Speed Dialling number that does not contain a destination, then press the [STORE] key.

MEMO

- You can display One-touch Speed Dialling numbers used for storing Group Dialling sets by pressing One-touch Speed Dialling keys on the control panel, or by entering One-touch Speed Dialling numbers with the Number keys.

■ To specify Coded Speed Dialling:

Press the [CODED DIALLING] key and press the [▼] or [▲] keys to display a Coded Speed Dialling number that does not contain a destination, then press the [STORE] key.

MEMO


- You can display Coded Speed Dialling numbers used for storing Group Dialling sets by entering Coded Speed Dialling numbers with the Number keys.

3

Select the destinations you want to store for Group Dialling from those stored in One-touch Speed Dialling or Coded Speed Dialling keys, or from the Directory.


■ **To specify One-touch Speed Dialling destinations:**

Press the [ONE-TOUCH DIALLING] key, specify One-touch Speed Dialling destinations with the Number keys or One-touch Speed Dialling keys, then press the [OK] key.




■ **To specify Coded Speed Dialling destinations:**

Press the [CODED DIALLING] key, specify Coded Speed Dialling destinations with the Number keys, then press the [OK] key.



■ **To specify destinations from the Directory:**


Press the [DIRECTORY] key. The display on the right appears. Select one of the keys listed under [DIRECTORY CONTENTS] key.



Press the [▼] or [▲] keys to display the destination you want, select the number, then press the [DONE] key.


MEMO

- You can also display the number directly with the Number keys instead of selecting the number in the touch panel display.
- If you make a mistake when storing a destination, press the [▼] or [▲] keys to display the destination. Then select the destination's corresponding number and press the [DELETE] key.



4 To set the transmission time, press the [SENDING TIME] key. The display on the right appears. If the set time does not need to be changed, proceed to the next step.


You can set up to five transmission times.
Set the time in 24-hour form (00:00 to 23:59)
with the Number keys, then press the [OK] key.



5 Make sure the specified dialling destination is correct, then press the [OK] key.

MEMO


- With this menu, you can also delete unwanted destinations. To delete a destination, select the destination in the list, then press the [DELETE] key.



6 Enter the Group name, then press the [OK] key.

MEMO


- You can enter up to 24 characters in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- You can also omit group names.
- To cancel, press the [C] key.



7 Enter where in the directory to store the group name, then press the [OK] key.

MEMO

- You can also store specific Group Dialling numbers in the user content keys ([GENERAL 1] and [GENERAL 2]). This is handy for storing destinations that you frequently send to.
- You can also register a name to the user content keys ([GENERAL 1] and [GENERAL 2]). (See p. 9-12.)



8

[STU] appears.

Select [S], then press the [OK] key.

The display on the right appears for about two seconds.

Then the display on the right appears.

To store another group, repeat the procedure beginning with step 1.

02] Select where to store destination. C

S T U

ABC DEF GHI JKL MNO

PQR STU VWX YZ

GENERAL 1 GENERAL 2 OK

FAX MONITOR

Store in memory. C

ONE-TOUCH DIALING CODED DIALING GROUP DIALING

02 SALES DEPT. A-GROUP

GROUP DIAL 11

DELETE [down] [up] STORE DONE

FAX MONITOR

Specify the position for storing.
(One-touch dial key entry OK).

ONE-TOUCH DIALING CODED DIALING GROUP DIALING

03 Not registered.

DELETE [down] [up] STORE DONE

FAX MONITOR

9

Press the [DONE] key.

The display returns to the Store Destinations screen.

Deleting One-touch Speed Dialling and Coded Speed Dialling Destinations Stored as a Group Set

You can delete any One-touch Speed Dialling or Coded Speed Dialling destination that is stored in a Group Dialling set.

- 1 Press the [GROUP DIALLING] key.

- 2 Specify the One-touch Speed Dialling keys or Coded Speed Dialling keys that contain the destinations you want deleted.

- **One-touch Speed Dialling:**
Press the [ONE-TOUCH DIALING] key.
- **Coded Speed Dialling:**
Press the [CODED DIALING] key.

- 3 Press the [▼] or [▲] keys to specify the Group Dialling set containing the destinations to be deleted, then press the [STORE] key.

MEMO

- If you press the [▼] or [▲] keys, One-touch Speed Dialling and Coded Speed Dialling destinations stored or not stored in a Group Dialling set are displayed.
- You can also specify the One-touch Speed Dialling or Coded Speed Dialling keys by entering the destination number with the Number keys.

- 4 Press the [▼] or [▲] keys to display the One-touch Speed Dialling or Coded Speed Dialling key to be deleted, select the item, then press the [DELETE] key.

- 5** To delete a destination, press [YES].
To cancel, press the [NO] key.




- 6** Make sure the destination number has been deleted from the displayed list.

To delete more destinations, repeat steps 4 and 5.
If you're done deleting destinations, press the [OK] key.

NOTICE


- If all stored destination numbers are deleted, Group Dialing destinations are also deleted.



- 7** If the Group Dialing name need not be changed, press the [OK] key.

MEMO

- For details on changing the Group Dialing name, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.



8

If the directory in which the Group Dialling name is stored need not be changed, press the [OK] key.

The display on the right appears for about two seconds.

The display on the right appears.

To delete the One-touch Speed Dialling destination numbers or Coded Speed Dialling numbers stored in another Group Dialling set, repeat this procedure beginning with step 2.


Press the [DONE] key.

The display returns to the Store Destinations screen.

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

Deleting Group Dialling Sets


1 Press the [GROUP DIALLING] key.



2 Press the [▼] or [▲] keys to select the Group Dialling destinations you want deleted, then press the [DELETE] key.

MEMO

- If you press the [▼] or [▲] keys, One-touch Speed Dialling and Coded Speed Dialling destinations stored or not stored as a Group Dialling set are displayed.
- You can also specify the One-touch Speed Dialling or Coded Speed Dialling keys by entering the destination number with the Number keys.



3 Confirm that you want to delete the group dialling set.

■ To delete the set:

Press the [YES] key.
The set is deleted, and the display returns to the Store Destination screen.

■ To cancel:

Press the [NO] key.
The procedure returns to step 2.



Setting Transmission Functions (TX SETTINGS)

You can set and store the following items in the TX Settings screen.

Store/Set Item and Description	Initial Setting(*) and Setting Item	See Page	Screen No.
ECM TX Sets ECM (Error Correction Mode) transmission ON or OFF.	ON* OFF	9-37	1/3
PAUSE TIME Sets the length (in seconds) of the pause inserted by the PAUSE key.	2* (from 4 to 11 seconds)	9-38	
AUTO REDIAL Controls whether the machine automatically redials when the other party is busy. (REDIAL TIMES) This controls how many times the machine automatically redials when the other party is busy. (REDIAL INTERVAL) This sets the redial interval. (TX ERROR REDIAL) This selects which page to automatically resend when a transmission error occurs.	ON* OFF 2* (from 1 to 3 times) 2* (from 2 to 99 minutes) ERROR & 1ST PAGE* ALL PAGES OFF	9-39	
BATCH TX Controls whether the machine will batch send all documents to the same destination in memory.	ON* OFF	9-41	2/3
ERASE FAILED TX Selects whether the machine automatically deletes from its memory documents that failed to transmit.	ON* OFF	9-41	
TIME OUT Controls whether to start scanning without pressing the START key when specifying the destination.	ON* OFF	9-42	
STAMP DOCUMENT Selects the conditions for stamping sent or scanned originals.	DIRECT & MEMORY TX* DIRECT TX	9-43	3/3

1

2

3

4

5

6

7

8

9


10

11

Calling Up the TX Settings Screen

1

Press the [TX SETTINGS] key in the Custom FAX Settings screen.




2

The TX Settings screen appears.


The TX Settings screen is made up of three screens (1/3, 2/3, and 3/3). Press the [▼] or [▲] keys to display the desired screen and make the required settings.

[TX Settings Screen]



1/3 screen



2/3 screen



3/3 screen



The descriptions in the rest of this section assume that you are operating from the TX Settings screen.


Setting Whether to Use ECM Transmission (ECM TX)

Your machine features the ability to send using Error Correction Mode (ECM). (The machine's initial setting is ON.)
When using ECM mode, the machine continuously checks the communications status to prevent errors from occurring.


MEMO

- Even if communications are carried out in the ECM mode, image errors can still occur depending on the condition of the telephone line. If line problems do occur, communications may take longer than normal while the machine works to correct errors in the transmission.
- If the other party is not using ECM mode, communications are carried out in regular mode.

1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [ECM TX] key.



2 Select the [ON] or the [OFF] key, then press the [OK] key.



3 The display returns to TX Settings screen 1/3.

1

2

3

4

5

6

7

8

9

10

11


Setting the PAUSE TIME (PAUSE TIME)

When you register a long distance number, or machine is connected to an extension, you may have to insert a pause either within or after the number. For long distance dialling, the location and length of the pause may differ depending on the telephone system. This section describes how to set the pause time (in seconds).

MEMO

- Pauses entered at the end of dialed telephone numbers are always 10 seconds long.


- 1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [PAUSE TIME] key.



- 2 Set the pause time with the Number keys or the [-] [+] keys, then press the [OK] key.

MEMO

- The pause time must be from 4 to 11 seconds.
- You can also increase or decrease the entered values directly with the [-] [+] keys in the touch panel display.



- 3 The display returns to TX Settings screen 1/3.

Automatic Redialling When the Other Party is Busy (AUTO REDIAL)

The Auto Redial feature lets your machine automatically resend documents when the other party is busy or does not respond, or when a transmission error occurs. (Initial setting: Auto Redial.) This section describes Auto Redial settings.

- When using Auto Redial, your machine waits for two minutes before automatically redialling the other party, and outputs a transmission error report. (See p. 9-104.)

■ Redial Times

This is the number of times the machine redials automatically. (Initial setting: two times.)


■ Redial Interval

This is how long the machine waits before automatically redialling the other party. (Initial setting: two minutes.)

■ TX Error Redial

This controls whether the machine redials when a transmission error occurs, and determines which pages of the document to resend. (Initial setting: error & 1st page.)

- 1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [AUTO REDIAL] key.



- 2 Select the [ON] or the [OFF] key.


■ To set Auto Redial to ON:

Press the [ON] key.


■ To set Auto Redial to OFF:

Press the [OFF] key, then press the [OK] key.

Proceed to step 5.



- 3 Press the [OPTIONAL SETTING] key.



4



Set the number of times you want the machine to redial, the redial interval, whether to resend when a transmission error occurs, and, if so, what pages to resend.

■ To set the number of times to redial:

Press the [REDIAL TIMES] key.
Enter the number of times to redial with the Number keys, then press the [OK] key.

MEMO

- The machine can redial from 1 to 3 times.
- You can also increase or decrease the entered values directly with the [-] [+] keys in the touch panel display.




■ To set the redial interval:

Press the [REDIAL INTERVAL] key.
Enter the redial interval with the Number keys, then press the [OK] key.


MEMO

- The redial interval must be from 2 to 99 minutes.
- You can also increase or decrease the entered values directly with the [-] [+] keys in the touch panel display.



■ To set transmission error redial:

Press the [TX ERROR RESEND] key.
Select the [ERROR & 1ST PAGE] key (only the first page and page on which the error occurred are resent), the [ALL PAGES] key (all pages are resent), or the [NO] key (the machine does not redial automatically), then press the [OK] key.



5

Press the [DONE] key.

The display returns to TX Settings screen 1/3.


Setting Whether to Send Documents Going to the Same Destination by Dialling Once (BATCH TX)

Set whether the machine sends documents going to the same destination by dialling the number only once.


MEMO

- The initial setting is "ON"

- 1
- Press the [▼] or [▲] keys to display the 2/3 screen, then press the [BATCH TX] key.



- 2
- Select the [ON] or the [OFF] key, then press the [OK] key.



- 3
- The display returns to TX Settings screen 2/3.

Setting Whether to Clear Failed Transmissions from Memory (ERASE FAILED TX)

You can select whether the machine automatically deletes from its memory documents that fail to transmit.

MEMO

- The initial setting is "ON"

1

2

3

4

5

6

7


8

9


10

11

- 1** Press the [▼] or [▲] keys to display the 2/3 screen, then press the [ERASE FAILED TX] key.




- 2** Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to TX Settings screen 2/3.

Setting Whether to Start Scanning Without Pressing the Ⓢ (START) Key When Specifying the Destination (TIME OUT)


- 1** Press the [▼] or [▲] keys to display the 2/3 screen, then press the [TIME OUT] key.



- 2** Select the [ON] or the [OFF] key, then press the [OK] key.

MEMO

- The initial setting is "ON"



The display returns to TX Settings screen 2/3.

Stamping Scanned or Sent Originals (STAMP DOCUMENT)

When your machine is equipped with the ADF or RDF, it can stamp scanned documents. You can set whether to stamp documents in Memory Transmission and Direct Transmission modes, or only in Direct Transmission mode.


MEMO

- The initial setting is "DIRECT & MEMORY TX."

- 1 Press the [▼] or [▲] keys to display 3/3 screen, then press the [STAMP DOCUMENT] key.

NOTICE

- The stamp setting is available only when your machine is equipped with the ADF or RDF.




- 2 Select the [DIRECT & MEMORY TX] or the [DIRECT TX] key, then press the [OK] key.

[DIRECT & MEMORY TX]:

This stamps documents after they are scanned.

[DIRECT TX]:

This stamps documents after they are sent only in the Direct Transmission mode.



The display returns to TX Settings screen 3/3.

Setting Reception Functions (RX SETTINGS)


You can set and store the following items in the Reception Settings.

Store/Set Item and Description	Initial Setting(*) and Setting Item	See Page	Screen No.
ECM RX Selects whether to receive in ECM mode.	ON* OFF	9-46	1/3
INCOMING RING Selects whether to sound the call tone in Auto Receiving mode, Transfer mode, and Memory Lock mode. (RING COUNT) This sets the number of rings.	ON OFF* 2* (1 to 99 rings)	9-47	
MEMORY RX Selects whether to receive documents in memory when the machine runs out of paper.	ON* OFF	9-48	2/3
RX PAGE FOOTER Selects whether to print the time received, transaction number, and number of pages on received documents.	OFF* ON	9-49	3/3

Calling Up the RX Settings Screen

1

Press the [RX SETTINGS] key in the Custom FAX Settings screen.




2

The RX Settings screen appears.


The RX Settings screen is made up of three screens (1/3, 2/3, and 3/3). Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[RX Settings Screen]



1/3 screen



2/3 screen



3/3 screen



The descriptions in the rest of this section assume that you are operating from the RX Settings screen.


Setting Whether to Use ECM Receiving to Automatically Compensate for Errors in Received Documents (ECM RX)

Your machine can use Error Correction Mode (ECM) to continuously check communications status to prevent errors from occurring.


MEMO

- The initial setting is "ON."
- Even if communications use ECM, errors can still occur depending on the condition of the telephone line. If problems occur in the line, communications may take longer than normal as the machine works to correct errors on the line.
- Communications are carried out in regular mode if the other party is not set to use ECM.

- 1 Press the [▼] or [▲] keys to display 1/3 screen, then press the [ECM RX] key.



- 2 Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to RX Settings screen 1/3.


Setting the Call Tone When in the Auto Receiving, Transfer, and Memory Lock Modes (INCOMING RING)

Set whether to sound the call tone when the machine is in Auto Receiving, Transfer, Memory Lock modes. You can also set the number of times that the call tone sounds (ring count).

MEMO


- The initial setting is "2 times."

1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [INCOMING RING] key.



2 Select the [ON] or the [OFF] key.


- **To set the Incoming ring to ON:**
Press the [ON] key.
- **To set the Incoming ring to OFF:**
Press the [OFF] key, then press the [OK] key.
The display returns to the RX Settings screen 1/3.



3 Press the Number keys or the [-] [+] keys to enter the ring count, then press the [OK] key.

MEMO

- The ring count must be from 1 to 99.
- You can also increase or decrease the entered values directly with the [-] [+] keys in the touch panel display.



The display returns to RX Settings screen 1/3.

1

2

3

4

5

6

7

8

9

10

11

Setting Memory Reception When Paper Runs Out (MEMORY RX)


Set whether to receive documents in the machine's memory if the documents cannot be printed immediately (if the machine runs out of paper, for example).

MEMO

- The initial setting is "ON."

1

Press the [▼] or [▲] keys to display the 2/3 screen, then press the [MEMORY RX] key.



2


Select the [ON] or the [OFF] key.

■ **To set Memory RX ON:**

Press the [ON] key.

■ **To set Memory RX OFF:**

Press the [OFF] key, then press the [OK] key.



The display returns to RX Settings screen 2/3.


Setting Whether to Print Information on Received Documents

(RX PAGE FOOTER)

Select whether to print the time received, reference number, and number of pages on received documents.


MEMO

- The initial setting is "ON."




1

Press the [▼] or [▲] keys to display the 3/3 screen, then press the [RX PAGE FOOTER] key.



2



Select the [ON] or [OFF] key, then press the [OK] key.



The display returns to RX Settings screen 3/3.

System Management Settings *(System Settings)*

The following items can be stored and set in the System Settings screen.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page	Screen number
RX RESTRICT This allows you to prevent your machine from receiving documents that are not stored to One-touch Speed Dialling or Coded Speed Dialling key destinations.	ON OFF*	9-52	1/3
TX START SPEED This allows you to change the transmission speed when a poor telephone line increases sending time.	14400 bps* 9600 bps 7200 bps 4800 bps 2400 bps	9-53	
RX START SPEED This enables you to change the receiving speed when a poor telephone line increases receiving time.	14400 bps* 9600 bps 7200 bps 4800 bps 2400 bps	9-54	
REMOTE CONTROL Set whether to enable the use of the Remote Control Feature.	ON OFF* (8 digits number)	9-55	2/3
RX PASSWORD This password is based on the ITU-T standard, and enables you to set a password for verification with the password sent with a received document. The password is used to verify received documents for which no ITU-T standard subaddress is set. Documents cannot be received if they have no password, or if their passwords do not match your machine's.	No setting* (up to 20 characters, including numerals, *, #, and spaces)	9-56	
 SW This allows you to use services from the remote maintenance centre. ( SWITCH PASSWORD) This restricts access to your machine.	ON OFF*	9-57	
R-KEY SETTING Sets the type of the PBX through which your machine is connected. (PSTN:) Your machine is connected to the outside line. (PBX:) Your machine is connected through a PBX. If set to PBX you can set the access method to PREFIX, HOOKING or EARTH CONNECTION.	PSTN PBX	9-58	3/3
M-KEY SETTING (UK only) Sets the access code when using an alternative long-distance service such as the 2300 Service of Mercury Communications Limited.	No setting*	9-59	

Calling Up the System Settings Screen

1

Press the [SYSTEM SETTINGS] key in the Custom FAX Settings screen.

Select a feature.

USER SETTINGS

TX SETTINGS

SYSTEM SETTINGS

PRINTER SETTINGS

STORE DESTINATIONS

RX SETTINGS

FILE SETTINGS

REPORT SETTINGS

PRINT LISTS

☐

DONE

FAX MONITOR

2

The System Settings screen appears.

The System Settings screen is made up of two screens (1/3, 2/3 and 3/3).

Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[System Settings Screen]

1/3 screen

Select a mode feature.

RX RESTRICT

▶OFF

TX START SPEED

▶14400bps

RX START SPEED

▶14400bps

1/3

▼

▲

DONE

FAX MONITOR

2/3 screen

Select a mode feature.

REMOTE CONTROL

▶OFF

RX PASSWORD

SW

▶OFF

2/3

▼

▲

DONE

FAX MONITOR

3/3 screen

Select a mode feature.

R-KEY SETTING

M-KEY SETTING

3/3

▼

▲

DONE

FAX MONITOR

(UK only)

The descriptions in the rest of this section assume that you are operating from the System Settings screen.

1

2

3

4

5

6

7

8

9

10

11

9-51


Setting Whether to Restrict Transmission Terminals (RX RESTRICT)

This feature allows you to prevent your machine from receiving originals that are not stored to One-touch Speed Dialling or Coded Speed Dialling key destinations.


MEMO

- The initial setting is "OFF."

- 1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [RX RESTRICT] key.



- 2 Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to System Settings screen 1/3.

Setting the Transmission Start Speed When the Line is Defective
(TX START SPEED)


You can set the transmission speed for documents. If you experience problems when sending documents, try a lower setting.

MEMO

- The initial setting is "14400 bps."


1

Press the [▼] or [▲] keys to display the 1/3 screen, then press the [TX START SPEED] key.



2

Select the TX start speed, then press the [OK] key.



The display returns to System Settings screen 1/3.

1

2

3

4

5

6

7

8

9

10

11

Setting the Reception Start Speed When the Line is Defective


(RX START SPEED)

You can set the reception speed for documents. If you experience problems when receiving documents, try a lower setting.


MEMO

- The initial setting is "14400 bps."

- 1 Press the [▼] or [▲] keys to display the 1/3 screen, then press the [RX START SPEED] key.



- 2 Select the RX start speed, then press the [OK] key.



The display returns to System Settings screen 1/3.


Setting Whether to Enable the Use of the Remote Control Feature
(REMOTE CONTROL)

This feature allows you to operate your machine from a remote facsimile. Here you can set whether to enable the use of the Remote Control Feature.


MEMO

- The initial setting is "OFF."

1 Press the [▼] or [▲] keys to display the 2/3 screen, then press the [REMOTE CONTROL] key.



2 Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to System Settings screen 2/3.

1

2

3

4

5

6

7

8

9

10


11

Setting the Receiving Password (RX PASSWORD)

This password is based on the ITU-T standard. Setting this password allows you to control which incoming documents your machine will receive. A document cannot be received if the password that accompanies it does not match the password you set in your machine, or if the document has no password.

1

Press the [▼] or [▲] keys to display 2/3 screen, then press the [RX PASSWORD] key.




2

Enter the RX password, then press the [OK] key.

MEMO

- The receiving password can have up to 20 digits, and can include numerals, *, #, and spaces.



The display returns to System Settings screen 2/3.

☞ SW Setting (☞ SW SETTING)


This feature allows you to use services from the Remote Maintenance Centre.

MEMO

- The initial setting is "OFF."


1

Press the [▼] or [▲] keys to display the 2/3 screen, then press the [☞ SW] key.



2

Select the [ON] key.




3

Enter the ☞ SWITCH PASSWORD, then press the [OK] key.

MEMO

- Enter a password of eight digits with the Number keys.
- The remote maintenance centre cannot access your machine without this password (For security reasons).
- You can also omit this password, but it is not recommended.



Press the [OK] key until the display returns to System Settings screen 2/3.

1

2

3

4

5

6

7

8

9

10

11

12

Selecting the R-key Setting (R-KEY SETTING)

If your machine is connected through a PBX (Private branch exchange), set the R-key setting to PBX and select the access method.


MEMO

- You can set the PBX type to PREFIX, HOOKING, or EARTH CONNECTION. If you select PREFIX, you can set a code of up to 20 digits that will access the outside line. Be sure to enter a pause (P) after the prefix number.

1

Press the [▼] or [▲] keys to display the 3/3 screen, then press the [R-KEY SETTING] key.


(UK only)



2

Select the [PSTN] or [PBX] key.


- If your machine is connected to the outside line:**
Press the [PSTN] key, then press the [OK] key.
The display returns to System Settings screen 3/3.
- If your machine is connected through a PBX:**
Press the [PBX] key.



3

Select the access method.

- If you select PREFIX:**
Press the [CODE] key, and go to the next step.
- If you select a HOOKING or EARTH CONNECTION:**
Press the [OK] key.
The display returns to the System Settings screen 3/3.




4

Enter the PREFIX code.

MEMO

- Be sure to enter a pause (P) after the prefix number. Without it, you cannot register.




Press the [OK] key until the display returns to System Settings screen 3/3.

Selecting the M-key Setting (M-KEY SETTING) (UK only)

This feature allows you to set the access code when using an alternative long-distance service such as the 2300 Service of Mercury Communications Limited.

- 1 Press the [▼] or [▲] keys to display the 3/3 screen, then press the [M-KEY SETTING] key.





- 2 Confirm that an access code of either 131P (Pause) or 132 is displayed.

MEMO

- IF 131P or 132 is not displayed, then enter either one of these codes with the number keys.
- If your access code is not 132, be sure to enter a pause (P) after the access number
- If entering a code is necessary and you make a mistake during entry, press the [BACK SPACE] key to delete the number, then reenter the number.

- **If your access code is 132:**
You don't have to enter the ID code.
Press the [OK] key.

- **If your access code is not 132:**
Enter the ID code, then press the [OK] key.



The display returns to System Settings screen 3/3.

File Settings (FILE SETTINGS)

This machine is provided with four files.

■ **Memory Box Store/Set (See p. 9-62.)**

You can create, change, and cancel memory boxes.

■ **Preset Polling Setting (See p. 9-84.)**

You can set your machine so that it performs polling receiving periodically.

■ **Transfer Setting (See p. 9-86.)**


You can set your machine to transfer received documents to other destinations.

■ **Memory Lock Setting (See p. 9-90.)**

You can set your machine to store received documents to memory without printing them.

Calling Up the File Settings Screen

- 1 Press the [FILE SETTINGS] key in the Custom FAX Settings screen.




- 2 The File Settings screen appears.
The File Settings screen is made up of two screens (1/2 and 2/2).


Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[File Settings Screen]

1/2 screen



2/2 screen



The descriptions in the rest of this section assume that you are operating from the File Settings screen.

Storing Polling, Confidential, Relay, Batch Sending, Bulletin Board, and General Memory Boxes (MEMORY BOX STORE/SET)

- 1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [MEMORY BOX STORE/SET] key.

- 2 Select the memory box number, then press the [STORE] key.

MEMO

- Memory box number 00 is reserved for the Polling Memory Box.

- 3 Select the desired memory box function.

Select the [CONFIDENTIAL], [RELAY], [BATCH SENDING], [BULLETIN BOARD], or [GENERAL] key, then press the [OK] key.

The descriptions of how to set the above memory boxes begin with step 3, which describes how to select the memory box functions.

The description of how to set the polling memory box begins with step 2, which describes how to select the memory box to be stored.

Setting the Polling Memory Box

Set the polling memory box as follows. (Memory box number 00 is reserved for the polling memory box.)
If a remote FAX dials your machine and requests polling reception, documents already scanned to the Polling Memory Box can be sent to the remote FAX.

You can set and store the following items for the polling memory box.

- MEMO
- The setting is permanently “00.”

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME This sets the memory box name. If you have not stored the box name, the default “Polling” is used.	Polling* (up to 24 alphanumeric characters)	9-63
Password This sets the password for the memory box. This password restricts the accessibility to change the polling memory box’s settings. If you do not enter the password set here, you cannot change stored settings, or scan documents.	a four-digit number	9-64
DELETE DOCUMENT This controls whether the machine deletes documents in the Polling Memory Box after they have been sent.	YES NO*	9-64

- 1 Select box number “00”, then press the [STORE] key.

Select the box to store.
(Up to 70 boxes)

00 POLLING RX: _____

01 RELAY: _____

02 BATCH SEND: _____

03 BULLETIN BOARD: _____

DELETE [Left Arrow] [Right Arrow] STORE DONE

FAX MONITOR

- 2 Enter the box name, then press the [OK] key.
- MEMO
- You can enter up to 24 characters for the memory box name in UPPER, LOWER, and OTHER modes.
 - For details on how to enter characters, see “Entering Characters on the Touch Panel Display,” on p. 2-5 in the *Reference Manual*.

00 Enter the name for the box. (up to 24 letters)

POLLING TX: [C]

BACK SPACE INPUT MODE (UPPER)

Q W E R T Y U I O P

A S D F G H J K L

Z X C V B N M -

SPACE LOWER CASE OK

FAX MONITOR

1 _____

2 _____

3 _____

4 _____

5 _____

6 _____

7 _____

8 _____

9 _____

10 _____

11 _____

3

Enter the password, then press the [OK] key.

MEMO

- Enter a password of up to four digits with the Number keys.

[00] Set password. C

[1234]

Press OK if no settings need to be made. OK

FAX MONITOR

4

Select the [ON] key to delete documents after they are sent, or the [OFF] key to leave them in the polling memory box. Then press the [OK] key.

[00] POLLING SETTINGS C

DELETE DOCUMENT ON OFF

OK

FAX MONITOR

5

Make sure the stored settings are correct, then press the [OK] key.

[00] Stored.

Function : Polling

Box name : POLLING TX

Password : 1234

DELETE DOCUMENT : OFF

OK

FAX MONITOR

6

Press the [DONE] key.

The display returns to File Settings screen 1/2.

Setting the Confidential Memory Box

Set the confidential memory box as follows.

The Confidential Memory Box is for receiving confidential documents. To send documents to your machine's Confidential Memory Box, the sender must specify the memory box's subaddress and RX password.


MEMO

- You must enter the password to print documents stored in the confidential memory box.

You can set and store the following items for the confidential memory box.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME This sets the memory box name. If you do not store a name, the default "CONFIDENTIAL" is used.	CONFIDENTIAL* (up to 24 letters)	9-65
Password This restricts access to operating and setting up the confidential memory box. Do not forget the password. Without entering the password you cannot print documents received in your memory.	a four-digit number	9-66
SUBADDRESS This is used to distinguish among the machine's memory boxes when receiving documents. Be sure to set this subaddress.	(up to 20 digits, including numbers, *, #, and spaces)	
RX PASSWORD This controls which documents the machine can receive into this memory box: documents not sent with this password are not accepted.	(up to 20 digits, including numbers, *, #, and spaces)	


- 1** Select the [CONFIDENTIAL] key, then press the [OK] key.



- 2** Enter the box name, then press the [OK] key.

MEMO

- You can enter up to 24 letters for the memory box name in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.



3

Enter the password, then press the [OK] key.

MEMO

- Enter a password of four digits with the Number keys.
- This password is used to protect confidential documents in this memory box.

4

Enter the subaddress and RX password, then press the [OK] key.

MEMO

- Enter up to 20 digits (including numerals, *, #, and spaces) for the subaddress and RX password.

5

Make sure the stored settings are correct, then press the [OK] key.

6

Press the [DONE] key.

The display returns to File Settings screen 1/2.

Setting the Relay Memory Box


Set the relay memory box as follows.

The relay memory box allows you to forward documents received by your machine to two or more other machines. It also allows you to send a set of documents at a specified time.

You can set and store the following items for the relay memory box.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME Sets the memory box name. If you do not store a name, the default "RELAY" is used.	"RELAY"* (up to 24 letters)	9-68
Password Restricts access to relay memory box settings. Do not forget this password, or you will not be able to change these settings.	a 4-digit number	
SUBADDRESS This is used to distinguish among the machine's memory boxes when receiving documents. Be sure to set this subaddress.	(up to 20 digits, including numbers, *, #, and spaces)	
RX PASSWORD Controls which documents the machine can receive: the machine will not accept documents that were not sent with this password.	(up to 20 digits, including numbers, *, #, and spaces)	
ORG. RELAY UNIT RESTRICTION Determines whether your machine will only relay documents sent from a particular FAX machine (original relay unit).	ON OFF*	9-69
ORIG. RELAY UNIT Sets the original relay unit. (DESTINATION) Registers the destinations that documents sent from the original relay unit will be relayed to. Be sure to set these destinations.	you can use One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling	
PRINT RX DOC. Determines whether to print received documents.	ON OFF*	
TX RELAY REPORT Determines whether the machine sends the relay transmission results to the machine that sent the document.	ON OFF*	
RELAY START TIME Sets the time at which transmission starts.	No initial setting 00:00 to 23:59	

- 1 Select the [RELAY] key, then press the [OK] key.



2

Enter the box name, then press the [OK] key.

MEMO

- You can enter up to 24 letters for the box name in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see “Entering Characters on the Touch Panel Display,” on p. 2-5 in the *Reference Manual*.

3

Set the password, then press the [OK] key.

MEMO

- Enter the password of four digits with the Number keys.
- You can also omit the password.

4

Enter the subaddress and RX password, then press the [OK] key.

MEMO

- Enter up to 20 digits (including numerals, *, #, and spaces) for the subaddress and RX password.
- To cancel, press the [C] key.
- If you make a mistake when entering the subaddress and RX password, delete the character with the [BACK SPACE] key, then enter the correct character.

5

Select the [ONE-TOUCH DIALLING], [CODED DIALLING], or [DIRECTORY] keys to specify the destination. Press the [▼] or [▲] keys to display the relay destination, select the item, then press the [OK] key.

MEMO

- For details on using One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling, see “Specifying a Destination,” on p. 3-20.)
- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the relay destination and select it. Then, press the [DELETE] key.

6

Set the relay items.

■ ORIG. RELAY UNIT RESTRICTION

To restrict original relay units:
Press the [ON] key. The display on the right appears.
Store the original relay unit numbers for verifying the other parties specified for relay transmission.
Select [ONE-TOUCH DIALLING], [CODED DIALLING], or [DIRECTORY] keys to specify the destination, then press the [OK] key.

MEMO

- For details on using One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling, see "Specifying a Destination," on p. 3-20.)
- If you make a mistake when specifying the original relay unit, press the [▼] or [▲] keys to display the relay destination and select it. Then, press the [DELETE] key.

To leave original relay units unrestricted:
Press the [OFF] key.

■ PRINT RX DOC.

To print received documents, press the [ON] key. When not printing received documents, press the [OFF] key.

■ TX RELAY REPORT

To send relay transmission results to the sender, press the [ON] key. When not sending the report, press the [OFF] key.

■ RELAY START TIME

To set the relay start time:
Press the [ON] key.




The display on the right appears. Set the time to start relay transmission with the Number keys, then press the [OK] key.

MEMO

- The time must be in the range of 00:00 to 23:59.

The display returns to the RELAY SETTING screen.

When not setting the relay start time:
Press the [OFF] key.



- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

7

Press the [OK] key.

[01] RELAY SETTINGS

ORIG. RELAY UNIT RESTRICTION

PRINT RX DOCUMENT

TX RELAY REPORT

RELAY START TIME --:--

8

Make sure the stored settings are correct, then press the [OK] key.

[01] Stored.

Function : RELAY

Box name : RELAY:

Password : 1234

Sub-address : 9876

RX PASSWORD : 5432

RELAY UNIT : 7

ORIG. RELAY : 7

PRINT RX DOCUMENT : ON

TX RELAY REPORT : ON

RELAY START TIME : OFF

9

Press the [DONE] key.

Select the box to store.
(Up to 70 boxes)

POLLING RX:

RELAY:

BATCH SEND:

BULLETIN BOARD:

The display returns to File Settings screen 1/2.

Setting the Batch Sending Memory Box

Set the batch sending memory box as follows.


The batch sending memory box allows you to send documents scanned into it to a specific destination at a specific time every day, just like a regular service.

You can set and store the following items for the batch sending memory box.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME Sets the memory box name. If you do not store a name, the default "BATCH SENDING" is used.	BATCH SENDING* (up to 24 letters)	9-71
Password Restricts access to the Batch Sending Memory Box. Do not forget set this password, or you will not be able to scan documents to the memory box or change its settings.	a four-digit number	9-72
DESTINATION Sets the destinations to send the documents to at the specified time. Be sure to set these destinations.	use One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling	
TX START TIME Sets the time when transmission starts. Be sure to set the start time.	No initial setting* 00:00 to 23:59	

1

Select the [BATCH SENDING] key, then press the [OK] key.




2

Enter the box name, then press the [OK] key.

MEMO

- You can enter up to 24 letters for the box name in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- If you don't want to enter a new box name, press the [OK] key without entering anything.



1

2

3

4

5

6

7

8

9

10

11

3

Enter the password, then press the [OK] key.

MEMO

- Enter a password of four digits with the Number keys.
- You can also omit the password.
- This password is used to protect the confidentiality of documents in this memory box.

4

Select the [ONE-TOUCH DIALLING], [CODED DIALLING], or [DIRECTORY] keys to specify the destination, then press the [OK] key.

MEMO

- For details on how to use One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling, see "Specifying a Destination," on p. 3-20.
- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the relay destination. Then, select the destination and press the [DELETE] key.

5

Enter the transmission start time with the Number keys, then press the [OK] key.

MEMO

- The time must be in the range of 00:00 to 23:59.

6

Make sure the stored settings are correct, then press the [OK] key.

7

Press the [DONE] key.

Select the box to store.
(Up to 70 boxes)

00	POLLING RX:
01	BATCH SENDING:
02	BATCH SENDING:
03	BULLETIN BOARD:

DELETE [Left Arrow] [Right Arrow] STORE DONE

FAX MONITOR

The display returns to File Settings screen 1/2.

Setting the Bulletin Board Memory Box

Set the bulletin board memory box as follows.


Documents scanned to the Bulletin Board Memory Box can be sent to another party's FAX if the other party specifies the memory box's subaddress and RX password.

You can set and store the following items for the bulletin board memory box.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME This sets the memory box name. If you do not store a box name, the default "BULLETIN BOARD" is used.	BULLETIN BOARD* (up to 24 letters)	9-74
Password This restricts access to the bulletin board memory box. Be sure to set this password, or you will not be able to scan documents to this memory box.	a four-digit number	
SUBADDRESS This is used to distinguish among the machine's memory boxes when receiving documents. Be sure to set this subaddress.	(up to 20 digits, including numbers, *, #, and spaces)	
RX PASSWORD This controls which documents the machine can receive: the machine will not accept documents that were not sent with this password.	(up to 20 digits, including numbers, *, #, and spaces)	
DELETE DOCUMENT This controls whether the machine deletes documents from the bulletin board memory box after they have been sent.	ON OFF*	9-75

1

Select the [BULLETIN BOARD] key, then press the [OK] key.




2

Enter the box name, then press the [OK] key.

MEMO

- You can enter up to 24 letters for the box name in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- If you don't want to set a new box name, press the [OK] key without entering anything.



3

Set a password, then press the [OK] key.

MEMO

- Enter a password of up to four digits with the Number keys.
- You can also omit the password.
- This password is used to protect the confidentiality of documents in this memory box.




4

Enter the subaddress and RX password, then press the [OK] key.

MEMO

- Enter up to 20 digits (including numerals, *, #, and spaces) for the subaddress and RX password.
- If you make a mistake when entering the subaddress and RX password, delete the character with the [BACK SPACE] key, then enter the correct character.



5 Select the [ON] key to delete documents from the memory box after they are sent, or select the [OFF] key to leave them in the memory box. Then press the [OK] key.

[01] BULLETIN BOARD SETTINGS C

DELETE DOCUMENT ON OFF

OK

FAX MONITOR

6 Make sure the stored settings are correct, then press the [OK] key.

[01] Stored.

Function : BULLETIN BOARD

Box name : BULLETIN BOARD

Password : 1234

Sub-address : 9876

RX PASSWORD : 5432

DELETE DOCUMENT : OFF

OK

FAX MONITOR

7 Press the [DONE] key.

Select the box to store.
(Up to 70 boxes)

00 POLLING RX:

01 BULLETIN BOARD:

02 BATCH SEND:

03 BULLETIN BOARD:

DELETE [Left Arrow] [Right Arrow] STORE DONE

FAX MONITOR

The display returns to File Settings screen 1/2.


Setting the General Memory Box

Set the General Memory Box as follows.

You can set a General Memory Box to suit your specific needs by setting and storing the following items.

Store/Set Item and Description	Initial Setting (*) and Setting Item	See Page
BOX NAME Sets the memory box name. If you do not store a name, the default "GENERAL" is used.	"GENERAL" (up to 24 letters)	9-77
Password Restricts access to the memory box.	a four-digit number	
SUBADDRESS Needs to be set only when communicating by the ITU-T standard.	(up to 20 digits, including numerals, *, #, and spaces)	
RX Controls whether the machine receives documents into a memory box.	ON OFF*	9-78
(RX PASSWORD) This controls which documents the machine will receive into this memory box: documents not sent with this password are not accepted.	(up to 20 digits)	9-78
(SELECT ORIGINAL UNIT) This sets whether the machine checks the stored original unit when receiving documents.	ON OFF*	9-79
(PRINT RX DOCUMENT) This sets whether the machine prints received documents.	ON OFF*	9-79
TX Controls whether the machine can send documents stored in a memory box.	ON OFF*	9-80
(TX DESTINATION) This selects the destination telephone number.	you can use One-touch Speed Dialling, Coded Speed Dialling, or Directory Dialling	9-80
(TX DOCUMENT) This selects the document to be transmitted.	See the description in the text.	9-80
(TX START TIME) This sets the time to start transmission. You can set up to five times (in 24-hour clock format) per day.	EVERYDAY SELECT DAYS OFF*	9-81
POLLING TX Turns Polling Transmission ON or OFF.	ON OFF*	9-82
(TX PASSWORD) This sets the password to be sent with documents that are sent by polling transmission from the memory box. Documents are not sent to the remote FAX unless that FAX's reception password matches this password.	(up to 20 digits can be entered)	9-82
(TX DOCUMENT) This selects the document to be transmitted.	See the description in the text.	9-82
(ERASE AFTER TX) This controls whether the machine deletes sent documents after polling transmission.	ON OFF*	9-83


- 1 Select the [GENERAL] key, then press the [OK] key.



- 2 Enter the box name, then press the [OK] key.

MEMO

- You can enter up to 24 letters for the box name in UPPER, LOWER, and OTHER modes.
- For details on how to enter characters, see "Entering Characters on the Touch Panel Display," on p. 2-5 in the *Reference Manual*.
- If you don't want to enter a new box name, press the [OK] key without entering anything.



- 3 Set the password, then press the [OK] key.

MEMO


- Enter a password of four digits with the Number keys.
- You can also omit the password.
- This password is used to protect the confidentiality of documents in this memory box.



- 4 Enter the subaddress, then press the [OK] key.

MEMO

- Enter up to 20 digits (including numbers, *, #, and spaces) for the subaddress.
- If you make a mistake when entering the subaddress, delete the character with the [BACK SPACE] key, then enter the correct character.



5

Set the items for general memory box settings.

Select the [ON] or the [OFF] key for each of the following items. If you don't want to set a particular item, select the [OFF] key, then press the [OK] key and proceed to step 7.

- **When [ON] is selected for RX:**
The display on the right appears.

■ RX password:

- To set the reception password:
Press the [RX PASSWORD] key.

The display on the right appears.

MEMO

- If you have not set the reception password, do not press the [RX PASSWORD] key.


Enter the reception password with the Number keys, then press the [OK] key.

MEMO



- You can enter up to 20 digits for the reception password.
- If you make a mistake when entering the reception password, press the [BACK SPACE] key to delete the password, then enter the correct password.

The display returns to the RX screen.

GENERAL MEMORY BOX screen



[RX] Screen



■ Select Orig. unit

- To select the original unit:
Press the [ON] key. The display on the right appears.

Specify the original units from the destinations stored in [ONE-TOUCH DIALLING], [CODED DIALLING], and [DIRECTORY].

MEMO

- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the original unit and select it. Then, press the [DELETE] key to delete the item.

The display returns to the RX screen.

- When not selecting the original unit:
Press the [OFF] key.

■ PRINT RX DOCUMENT




- To print reception documents:
Press the [ON] key. The display on the right appears.

Select printing of reception documents with the [AUTO] key or [MANUAL] key.

The display returns to the RX screen.

- When not printing reception documents:
Press the [OFF] key.

When you finish making reception settings, press the [OK] key.
The display returns to the screen for setting the General Memory Box.



1

2

3

4

5

6

7


8

9

10

11

- **When [ON] is selected for TX:**
The display on the right appears.




■ TX destination

- To set the transmission destination:
Press the [TX DESTINATION] key. The display on the right appears.

MEMO

- If you aren't setting the transmission destination, do not press the [TX DESTINATION] key.

Specify the desired transmission destinations from the destinations stored in [ONE-TOUCH DIALLING], [CODED DIALLING], and [DIRECTORY].



MEMO

- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the transmission destination and select it. Then, press the [DELETE] key to delete the item.

The display returns to the TX screen.

■ TX document

- To set the transmission document:
Press the [TX DOCUMENT] key. The display on the right appears.


MEMO

- If you aren't setting the transmission document, do not press the [TX DOCUMENT] key.

Select the [ON] key or the [OFF] key for each of the [SCAN DOCUMENT], [RECEIVED DOCUMENT], and [TX REPORT] keys.

[SCAN DOCUMENT] is for sending scanned documents, [RECEIVED DOCUMENT] is for sending received documents, and [TX REPORT] is for sending transmission reports. Press the [DONE] key.

The display returns to the TX screen.



■ TX START TIME

- To set the transmission start time:
Press the [TX START TIME] key. The display on the right appears.

MEMO

- If you aren't setting the transmission start time, do not press the [TX START TIME] key.
- To set for everyday transmission:
Press the [EVERYDAY] key, then press the [OK] key. The display on the right appears.

Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range 00:00 to 23:59.

The display returns to the TX screen.

- To set the day:
Press the [SELECT DAYS] key, then press the [OK] key. The display on the right appears.

Select the day from [SU] (Sunday) through [SA] (Saturday). Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO





- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the TX screen.

- To set TX START TIME OFF:
Press the [OFF] key, then press the [OK] key.

The display returns to the TX screen.

When you finish entering transmission settings, press the [DONE] key. The display returns to the GENERAL MEMORY BOX screen.



1

2

3

4

5

6

7


8

9

10

11

- **When you have selected [ON] for POLLING TX:**
The display on the right appears.




■ TX password

- To set the transmission password:
Press the [TX PASSWORD] key. The display on the right appears.

MEMO

- This is not required if the transmission password is not set.

Enter the password for polling transmission, then press the [OK] key.



MEMO

- You can enter up to 20 digits (including numbers, *, #, and spaces) for the transmission password.
- If you make a mistake when entering the transmission password, delete the password with the [BACK SPACE] key, then enter the correct password.

The display returns to the POLLING TX screen.

■ TX document

Press the [TX DOCUMENT] key.
The display on the right appears.


MEMO

- If you aren't setting the transmission original, do not press the [TX DOCUMENT] key.

Select the [ON] key or the [OFF] key for each of the [SCAN DOCUMENT] and [RECEIVED DOCUMENT] keys.
[SCAN DOCUMENT] is for sending scanned documents, and [RECEIVED DOCUMENT] is for sending received documents.

Press the [DONE] key.

The display returns to POLLING TX screen.



■ ERASE AFTER TX

To delete sent documents after polling transmission, press the [ON] key. When not deleting sent documents, press the [OFF] key.

1

2

6

When you finish making reception, transmission and polling transmission settings, press the [OK] key.

3

4

7

Make sure the stored settings are correct, then press the [OK] key.

5

6

7

8

Press the [DONE] key.

8

9


The display returns to File Settings screen 1/2.

10

11

Setting Periodical Polling Reception (PRESET POLLING SETTING)

- 1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [PRESET POLLING SETTING] key.




- 2 Select the [ON] or [OFF] key.

- **To turn Preset polling ON:**
Select the [ON] key, then press the [OK] key.
Proceed to step 3.
- **To turn Preset polling OFF:**
Select the [OFF] key, then press the [OK] key.
The display returns to File Settings screen 1/2.

MEMO

- The initial setting is "ON."



- 3 Enter the password, then press the [OK] key.

MEMO


- Enter the password of four digits with the Number keys.



- 4 Specify the units to be polled from the destinations stored in [ONE-TOUCH DIALLING], [CODED DIALLING], and [DIRECTORY] keys.

MEMO

- For details on how to use One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling, see "Specifying a Destination," on p. 3-20.
- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the unit to be polled. Then select the destination and press the [DELETE] key.




5

Enter the time to start polling reception with the Number keys, then press the [OK] key.

MEMO

- The time must be in the range of 00:00 to 23:59.



The display returns to File Settings screen 1/2.

1

2

3

4

5

6

7

8

9

10

11

Transferring Received Documents (TRANSFER SETTING)

You can set and store the following items for transfer.

Description	Initial Setting (*) and Setting Item
SPECIFY DESTINATION This specifies the transfer destination for received documents.	you can use One-touch Speed Dialling, Coded Speed Dialling or Directory Dialling
Password This sets the password for protecting the transfer settings. This password must then be entered to change or delete transfer settings.	a four-digit number
ORIGINAL UNIT RESTRICTION This selects whether to limit access when the incoming document is from a destination not stored as the original relay unit.	ON OFF*
TRANSFER STARTING TIME This sets up to five transfer starting times for each day of the week.	EVERYDAY SELECT DAYS OFF*
TRANSFER ENDING TIME This sets up to five transfer ending times for each day of the week.	EVERYDAY SELECT DAYS OFF*
PRINT RX. DOC. This selects whether to print documents received on your machine.	ON OFF*

NOTICE


- The transfer feature can be used only for documents received normally. Documents received to a memory box (see Chapter 8) cannot use this feature.
- The transfer feature also cannot be used for manually received documents.

MEMO

- You can select "SELECT DAYS" as the transfer ending time even when "EVERYDAY" is selected as the transfer starting time.
- You can select "SELECT DAYS" as the transfer starting time, and "EVERYDAY" as the transfer ending time.

1

Press the [▼] or [▲] keys to display the 1/2 screen, then press the [TRANSFER SETTING] key.



Select the [ON] or [OFF] key.

■ To set Transfer ON:


Select the [ON] key, then press the [OK] key.
Proceed to step 3.

■ To set Transfer OFF:

Select the [OFF] key, then press the [OK] key.
The display returns to File Settings screen 1/2.

MEMO

- The initial setting is "OFF."



3

Enter the password, then press the [OK] key.

MEMO

- Enter a password of four digits with the Number keys.




4

Select the desired transfer destinations from the destinations stored in [ONE-TOUCH DIALLING], [CODED DIALLING], or [DIRECTORY].

MEMO

- For details on how to use One-touch Speed Dialling, Coded Speed Dialling, and Directory Dialling, see "Specifying a Destination," on p. 3-20.
- If you make a mistake when specifying the destination, press the [▼] or [▲] keys to display the transfer destination. Then select the destination and press the [DELETE] key.



5

Set the items for transfer.

■ Select Original Unit

To restrict original transfer units:
Press the [ON] key. The display on the right appears.

Select [ONE-TOUCH DIALLING], [CODED DIALLING], or [DIRECTORY] to specify the transfer original unit, then press the [OK] key.

MEMO

- If you make a mistake when specifying the transfer original unit, press the [▼] or [▲] keys to display the transfer original unit and select it, then press the [DELETE] key.



The display returns to the TRANSFER SETTING screen.

When not restricting original transfer units:
Press the [OFF] key.

■ Print RX DOCUMENT

To print received documents, press the [ON] key. When not printing received documents, press the [OFF] key.

[TRANSFER SETTING Screen]



■ Transfer start time

- To set the transfer starting time:
Press the [TRANSFER START TIME] key. The display on the right appears.

MEMO

- If you aren't setting the transfer starting time, do not press the [TRANSFER START TIME] key.
- To set for everyday transfer:
Press the [EVERYDAY] key. The display on the right appears.

Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the [TRANSFER SETTING] screen.

- To set the day:
Press the [SELECT DAYS] key. The display on the right appears.

Select the day from [SU] (Sunday) through [SA] (Saturday). Then enter the times for [1] to [5] with the Number keys, and press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the [TRANSFER SETTING] screen.

- To set TRANSFER START TIME OFF:
Press the [OFF] key, then press the [OK] key.





The display returns to the TRANSFER SETTING screen.

■ Transfer ending time

- To set the transfer ending time:
Press the [TRANSFER ENDING TIME] key. The display on the right appears.

MEMO

- If you aren't setting the transfer ending time, do not press the [TRANSFER ENDING TIME] key.



- To set for everyday transfer:
Press the [EVERYDAY] key. The display on the right appears.

Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the TRANSFER SETTING screen.

- To set the day:
Press the [SELECT DAYS] key. The display on the right appears.

Select the day from [SU] (Sunday) to [SA] (Saturday). Then enter the times for [1] to [5] with the Number keys, and press the [OK] key.




MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the TRANSFER SETTING screen.

- To set TRANSFER ENDING TIME to OFF:
Press the [OFF] key, then press the [OK] key.

The display returns to the TRANSFER SETTING screen.



6

Press the [OK] key.

The display returns to File Settings screen 1/2.

Saving Received Documents to Memory (MEMORY LOCK SETTING)

You can set your machine to save received documents to memory without printing them by setting and storing the following items.


Store/Set Item and Description	Initial Setting (*) and Setting Item
Password This sets the password for protecting the memory reception settings. This password must then be entered to change or delete memory reception settings.	a four-digit number
PRINT RX REPORT This selects whether the machine will print reception reports.	ON* OFF
MEMORY LOCK START TIME This sets up to five memory reception start times for each day of the week.	EVERYDAY SELECT DAYS OFF*
MEMORY LOCK ENDING TIME This sets up to five memory reception ending times for each day of the week.	EVERYDAY SELECT DAYS OFF*

MEMO

- You can select "SELECT DAYS" as the memory reception ending time, even when "EVERYDAY" is selected as the memory reception start time.
- You can select "SELECT DAYS" as the memory reception starting time, and "EVERYDAY" as the memory reception ending time.

1

Press the [▼] or [▲] keys to display the 2/2 screen, then press the [MEMORY LOCK SETTING] key.



Select the [ON] or the [OFF] key.

■ To set Memory lock ON:


Press the [ON] key, then press the [OK] key.
Proceed to step 3.

■ To set Memory lock OFF:

Press the [OFF] key, then press the [OK] key.
The display returns to the File Settings screen.

MEMO

- The initial setting is "OFF."



3

Enter the password, then press the [OK] key.

MEMO

- Enter a password of four digits with the Number keys.

Set the password. [C]

[1234]

Press OK if no settings need to be made. [OK]

FAX MONITOR

1

2

4

Set the items for memory lock setting.

■ Print report

To print reception reports, press the [ON] key. When not printing reception reports, press the [OFF] key.

■ Memory lock start time

- To set the memory reception start time:
Press the [MEMORY LOCK START TIME] key. The display on the right appears.

MEMO

- If you aren't setting the memory reception start time, do not press the [MEMORY LOCK START TIME] key.

- To set for everyday memory lock:
Press the [EVERYDAY] key. The display on the right appears.

Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the MEMORY LOCK SETTING screen.

MEMORY LOCK SETTING [C]

PRINT REPORT [ON] [OFF]

MEMORY LOCK START TIME [OFF]

MEMORY LOCK END TIME [OFF]

[OK]

FAX MONITOR

3

4

MEMORY LOCK SETTING [C]

MEMORY LOCK START TIME [C]

EVERYDAY SELECT DAYS [OFF]

[OK]

FAX MONITOR

5

6

7

MEMORY LOCK SETTING [C]

EVERYDAY (00:00~23:59)

1 [23:00] 4 [--:--]

2 [--:--] 5 [--:--]

3 [--:--]

[OK]

FAX MONITOR

8

9

10

11

- To set the day:
Press the [SELECT DAYS] key. The display on the right appears.

Select the day from [SU] (Sunday) through [SA] (Saturday). Then enter the times for [1] to [5] with the Number keys, and press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the MEMORY LOCK SETTING screen.

- To set MEMORY LOCK START TIME to OFF:
Press the [OFF] key, then press the [OK] key.

The display returns to the MEMORY LOCK SETTING screen.

■ Memory lock end time

- To set the memory reception ending time:
Press the [MEMORY LOCK END TIME] key. The display on the right appears.

MEMO

- If you aren't setting the memory reception ending time, do not press the [MEMORY LOCK END TIME] key.
- To set for everyday memory lock:
Press the [EVERYDAY] key. The display on the right appears.

Enter the times for [1] to [5] with the Number keys, then press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the MEMORY LOCK SETTING screen.





- To set the day:
Press the [SELECT DAYS] key. The display on the right appears.

Select the data from [SU] (Sunday) through [SA] (Saturday). Then enter the times for [1] TO [5] with the Number keys, and press the [OK] key.

MEMO

- You can enter up to five times to be used in a day.
- The time must be in the range of 00:00 to 23:59.

The display returns to the MEMORY LOCK SETTING screen.



- To set MEMORY LOCK END TIME to OFF:
Press the [OFF] key, then press the [OK] key.

The display returns to the MEMORY LOCK SETTING screen.

5

Press the [OK] key in the MEMORY LOCK SETTING screen.

MEMORY LOCK SETTING

PRINT REPORT

MEMORY LOCK START TIME

MEMORY LOCK END TIME

FAX MONITOR

The display returns to File Settings screen 2/2.

1

2

3

4

5

6

7

8

9

10

11

Printer Settings (PRINTER SETTINGS)


You can set and store the following items in the Printer Settings screen.

Store/Set Item and Description	Initial Setting(*) and Setting Item	See Page	Screen No.
# OF RX COPIES Sets the number of copies the machine makes when printing received documents.	1 to 99 1*	9-96	1/2
SELECT CASSETE Controls how printing is performed when it has no paper matching the size of the received document.	(ON is enabled)	9-97	
(SW A) Sections of an image are printed on two sheets of paper that have the same width as the received image.	ON* OFF	9-97	
(SW B) Images are printed with a margin around them on paper that has the same width as the received image.	ON* OFF	9-97	
(SW C) Images are reduced and printed on paper that differs in width from the received images.	ON* OFF	9-97	
(SW D) Images are printed with a margin around them on paper that differs in width from the received images.	ON* OFF	9-97	
RX REDUCTION Controls whether the machine prints received documents at a reduced copy ratio.	ON* OFF	9-98	
(RX REDUCTION) This sets whether received documents are reduced using Fixed or Auto mode.	AUTO* FIX	9-99	
(SELECT REDUCE%) This selects the reduction ratio.	97% 95% 90% 75%	9-99	
(REDUCE DIREC.) This controls the direction in which the document is reduced.	XY Y*	9-99	
TWO-SIDED PRINT Controls whether the machine prints received documents on both sides of the paper.	ON OFF*	9-100	2/2
N ON 1 LOG Select whether the machine prints two or more received documents reduced on a single sheet of paper in the same paper series.	ON OFF*	9-101	

Calling Up the Printer Settings Screen

1

Press the [PRINTER SETTINGS] key in the Custom FAX Settings screen.



1

2

3

2

The Printer Settings screen appears.

The Printer Settings screen is made up of two screens (1/2 and 2/2).

Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[Printer Settings Screen]

1/2 screen

Select a mode feature.

OF RX COPIES
▶ 1

SELECT CASSETTE


RX REDUCTION
▶ ON

1/2

▼ ▲

DONE

FAX MONITOR



4

5

6

7

The descriptions in the rest of this section assume that you are operating from the Printer Settings screen.

8

9

10

11

Setting the Number of Received Documents to Print

(# OF RX COPIES)


Set the number of copies the machine makes when printing received documents.

MEMO

- The initial setting is "1."

1

Press the [▼] or [▲] keys to display the 1/2 screen, then press the [# OF RX COPIES] key.




2

Press the [+] [-] keys to set the number of copies to make, then press the [OK] key.

MEMO

- The number of copies must be from 1 to 99.
- You can increase or decrease the entered values directly with the [-] [+] keys in the touch panel display.
- You can also enter the number of copies directly with the Number keys.



3

The display returns to Printer Settings screen 1/2.


Setting Alternate Paper Cassettes (SELECT CASSETTE)

This controls how printing is performed when it has no paper matching the size of the received document.


MEMO

- For details on selecting paper drawers when printing received documents, see “Setting Whether or Not a Drawer is Subject to Auto Drawer Switching,” on p. 3-11 in the *Reference Manual*.
- The initial setting of all switches are “ON.”

1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [SELECT CASSETTE] key.



2 Select [ON] or [OFF] for each of the switches (A to D), then press the [OK] key.



- Switch A:
Sections of an image are printed on two sheets of paper that have the same width as the received image.
- Switch B:
Images are printed with a margin around them on paper that has the same width as the received image.
- Switch C:
Images are reduced and printed on paper that differs in width from the received images.
- Switch D:
Images are printed with a margin around them on paper that differs in width from the received images.

The display returns to Printer Settings screen 1/2.

1

2

3

4

5

6

7

8

9

10

11

Setting Whether to Print Received Documents at a Reduced Size (RX REDUCTION)


Reduces received documents to ensure that they fit on the recording paper.

MEMO

- The initial setting is "ON."

1


Press the [▼] or [▲] keys to display the 1/2 screen, then press the [RX REDUCTION] key.



2

Select the [ON] or the [OFF] key.

- **To set reception reduction to ON:**
Select the [ON] key, then press the [OPTIONAL SETTING] key.
Proceed to step 3.
- **To set reception reduction to OFF:**
Select the [OFF] key, then press the [OK] key.
The display returns to Printer Settings screen 1/2.



3

Set the image reduction settings.

■ **RX REDUCTION:**

[AUTO]:

The document is automatically reduced by a ratio larger than the value preset by REDUCE %.

[FIX RED.]:

The image is reduced by the copy ratio preset in REDUCE %.

■ **REDUCE %:**

Select the copy ratio, then press the [OK] key.

■ **REDUCE DIREC.:**



Select the [VER. HOR.] or [VER. ONLY] key.

[VER. HOR.]:

The image is reduced in the vertical and horizontal directions.

[VER. ONLY]:

The image is reduced in the vertical direction.



1

2

3

4

5

6

7

8

9

10

11

4

Press the [OK] key.

The display returns to the screen shown in step 2.

5

Press the [OK] key.

The display returns to Printer Setting screen 1/2.


Setting Whether to Print Received Documents on Both Sides of the Paper (TWO-SIDED PRINT)

This feature allows you to print received documents on both sides of the paper. Using this feature will save paper.

MEMO

- The initial setting is "OFF."

- 1 Press the [▼] or [▲] keys to display the 2/2 screen, then press the [TWO-SIDED PRINT] key.




- 2 Select the [ON] or the [OFF] key.

- **To print on both sides:**

Press the [ON] key, then press the [OK] key.

- **To print on one side only:**

Select the [OFF] key, then press the [OK] key.



The display returns to Printer Settings screen 2/2.

Setting Whether to Print Two or More Received Documents on Single Sheets of Paper (N ON 1 LOG)

This feature allows you to print two or more received documents on a single sheet of paper in the same paper series. This function operates under the following conditions:

- The same paper drawer must be used for printing a set of two or three consecutive pages from a received document.
- The paper in the selected paper drawer must be large enough for two or three pages to be printed on it.

Example:
If the A4 drawer was empty and the A3 drawer had paper, you could print two A4 documents onto a single sheet of A3-size paper.
If the A4 drawer had paper, A3 documents (landscape orientation) would be printed onto A4-size paper.

MEMO

- The initial setting is "ON."

1

2

3

4

5

6

7

8

9


10

11

1


Press the [▼] or [▲] keys to display 2/2 screen, then press the [N ON 1 LOG] key.

The same paper sheet is selected for two or three consecutive pages of the received document.



2

Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to Print Settings screen 2/2.


Printing Reports *(REPORT SETTINGS)*

You can set and store the following items in the Report Settings screen.

Store/Set Item and Description	Initial Setting(*) and Setting Item	See Page	Screen No.
TX REPORT This selects whether to print Transmission Reports. You can also set the machine to print Transmission Reports only when a transmission error occurs. (ERROR COPY PRINT) This controls whether to print the transmitted document on the report.	ON FOR ERROR ONLY* OFF ON* OFF	9-104 9-104	1/2
RX REPORT This sets whether to print Reception Reports. You can also set the machine to print Reception Reports only when a receiving error occurs.	ON FOR ERROR ONLY OFF*	9-105	
MEMORY BOX REPORT This selects whether to print Memory Box Reports when documents are received to memory box.	ON* OFF	9-106	
ACTIVITY REPORT This sets whether to print Activity Management Reports. (AUTO PRINT) This sets whether to print Activity Management Reports automatically after every 40 transactions. (TX/RX SEPARATE) This controls whether to print Transmission and Reception Reports separately. (DAILY REPORT TIME) This sets whether to print Activity Management Reports at a specified time. (PRINT TIME) This specifies the time to print Activity Management Reports.	ON* OFF ON* OFF ON OFF* ON OFF* 00:00 to 23:59	9-107	2/2

Calling Up the Report Settings Screen

- 1 Press the [REPORT SETTINGS] key in the Custom FAX Settings screen.




- 2 The Report Settings screen appears.
The Report Settings screen is made up of two screens (1/2 and 2/2).


Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[Report Settings Screen]

1/2 screen



2/2 screen



The descriptions in the rest of this section assume that you are operating from the Report Settings screen.


Setting Printing of TX Reports (TX REPORT)

This controls whether the machine prints TX Reports. You can also set the machine to print TX Reports only when a transmission error occurs.

MEMO


- The initial setting is "FOR ERROR ONLY."
- For an example of a Transmission report, see "Checking the Communications Status With Activity Management Reports," on p. 11-2.

- 1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [TX REPORT] key.




- 2 Select the [ON], [FOR ERROR ONLY], or [OFF] key.

- **To print TX Reports after each transmission:**
Select the [ON] key. Proceed to step 3.
- **To print TX Reports only when an error occurs:**
Select the [FOR ERROR ONLY] key. Proceed to step 3.
- **Not to print TX Reports:**
Select the [OFF] key, then press the [OK] key.
The display returns to the Report Settings screen 1/2.



- 3 Select whether to print a portion of the received document in the TX Report.

- **To include a portion of the document:**
Select the [ON] key for ERROR COPY PRINT, then press the [OK] key.
- **To omit the document:**
Select the [OFF] key for ERROR COPY PRINT, then press the [OK] key.



The display returns to Report Settings screen 1/2.


Setting Printing of RX Reports (RX REPORT)

This selects whether to print Reception Reports. You can also set the machine to print RX Reports only when a reception error occurs.


MEMO

- The initial setting is "NO."
- For an example of a Reception Report, see "Checking the Communications Status With Activity Management Reports," on p. 11-2.

1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [RX REPORT] key.



2 Select the [ON], [FOR ERROR ONLY], or [OFF] key, then press the [OK] key.



The display returns to Report Settings screen 1/2.

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

Setting Printing of Memory Box Reports (MEMORY BOX REPORT)


Set whether to print Memory Box Reports when documents are received to a memory box.

MEMO

- The initial setting is "ON."
- For an example of a Memory Box Report, see "Checking the Communications Status With Activity Management Reports," on p. 11-2.


1

Press the [▼] or [▲] keys to display the 2/2 screen, then press the [MEMORY BOX REPORT] key.



2

Select the [ON] or the [OFF] key, then press the [OK] key.



The display returns to Report Settings screen 1/2.

Setting Printing of Activity Reports (ACTIVITY REPORT)


Set whether to print Activity Reports.

MEMO

- The initial setting is "ON."
- For an example of an Activity Report, see "Checking the Communications Status With Activity Reports," on p. 11-2.

1

Press the [▼] or [▲] keys to display the 2/2 screen, then press the [ACTIVITY REPORT] key.



2

Select how to print Activity Reports.

■ To automatically print Activity reports:

Select the [ON] key for AUTO PRINT. To set to OFF, select the [OFF] key.

■ To print separate TX/RX reports:


Select the [ON] key for TX/RX SEPARATE. To set to OFF, select the [OFF] key.

■ To print Activity Reports at a specified time:

Press the [ON] key for DAILY REPORT TIME. The display on the right appears.

Enter the time to start printing the Activity Report with the Number keys, then press the [OK] key.


To set to OFF, press the [OFF] key.



MEMO

- The time must be in the range of 00:00 to 23:59.

The display returns to the Activity Report screen.



3

When you finish making settings, press the [OK] key.

The display returns to Report Setting screen 2/2.

Printing Lists (PRINT LIST)

The machine can print the following lists.

Print Item and Description	See Page	Screen number
1-TOUCH SPEED DIAL LIST 1 This prints a list of One-touch Speed Dialling destinations.	9-111	1/2
1-TOUCH SPEED DIAL LIST 2 This prints a detailed list of One-touch Speed Dialling destinations.	9-112	
CODED SPEED DIAL LIST 1 This prints a list of Coded Speed Dialling destinations.	9-112	
CODED SPEED DIAL LIST 2 This prints a detailed list of Coded Speed Dialling destinations.	9-112	1/2
GROUP DIAL LIST This prints a list of Group Dialling destinations.	9-113	
USER'S DATA LIST This prints all Custom FAX Settings.	9-113	

1

2

3

4

5

6

7

8

9


10

11

Calling Up the Print List Screen

1

Press the [PRINT LIST] key in the Custom FAX Settings screen.




2

The Print List screen appears.
The Print List screen is made up of two screens (1/2 and 2/2).



Press the [▼] or [▲] keys to display the desired screens and make the required settings.

[Print List Screen]

1/2 screen



2/2 screen




The descriptions in the rest of this section assume that you are operating from the Print List screen.

MEMO


- For examples of output lists, see "Printing Lists," on p. 11-7.

1-TOUCH SPEED DIAL LIST 1


1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [1-TOUCH SPEED DIAL LIST 1] key.



2 When the display on the right appears, select the [YES] or the [NO] key.
If you press the [NO] key, the display returns to the Print List screen 1/2.



If you press the [YES] key, the display on the right appears.
MEMO
● To cancel printing, press the [CANCEL] key.



The display returns to Print List screen 1/2.
MEMO
● For an example of a 1-Touch Speed Dial List 1, see p. 11-10.

1

2

3

4

5

6

7

8

9

10

11

1-TOUCH SPEED DIAL LIST 2

- 1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [1-TOUCH SPEED DIAL LIST 2] key.

From here, carry out the procedure for printing a list of One-touch Speed Dialling destinations, beginning with step 2.

MEMO

- For an example of a 1-Touch Speed Dial List 2, see p. 11-11.

Select a type of list to print.

1-TOUCH SPEED DIAL LIST 1	<input type="checkbox"/>
1-TOUCH SPEED DIAL LIST 2	<input checked="" type="checkbox"/>
CODED SPEED DIAL LIST 1	<input type="checkbox"/>

1/2

DONE

FAX MONITOR

CODED SPEED DIAL LIST 1

- 1 Press the [▼] or [▲] keys to display the 1/2 screen, then press the [CODED SPEED DIAL LIST 1] key.

From here, carry out the procedure for printing a list of One-touch Speed Dialling destinations, beginning with step 2.

MEMO

- For an example of a Coded Speed Dial List 1, see p. 11-12.

Select a type of list to print.

1-TOUCH SPEED DIAL LIST 1	<input type="checkbox"/>
1-TOUCH SPEED DIAL LIST 2	<input type="checkbox"/>
CODED SPEED DIAL LIST 1	<input checked="" type="checkbox"/>

1/2

DONE

FAX MONITOR

CODED SPEED DIAL LIST 2

- 1 Press the [▼] or [▲] keys to display the 2/2 screen, then press the [CODED SPEED DIAL LIST 2] key.

From here, carry out the procedure for printing a list of One-touch Speed Dialling destinations, beginning with step 2.

MEMO

- For an example of a Coded Speed Dial List 2, see p. 11-12.

Select a type of list to print.

CODED SPEED DIAL LIST 2	<input checked="" type="checkbox"/>
GROUP DIAL LIST	<input type="checkbox"/>
USER'S DATA LIST	<input type="checkbox"/>

2/2

DONE

FAX MONITOR

GROUP DIAL LIST


- 1

Press the [▼] or [▲] keys to display the 2/2 screen, then press the [GROUP DIAL LIST] key.

From here, carry out the procedure for printing a list of One-touch Speed Dialling destinations, beginning with step 2.

MEMO

 - For an example of a Group Dialling List, see p. 11-13.



1

2

3

USER'S DATA LIST


- 1

Press the [▼] or [▲] keys to display the 2/2 screen, then press the [USER'S DATA LIST] key.

From here, carry out the procedure for printing a list of One-touch Speed Dialling destinations, beginning with step 2.

MEMO

 - For an example of a User's Data List, see p. 11-14.



4

5

6

7


8

9

10

11

This chapter describes what to do if a self-diagnostic (error) message or service-call message appears in the touch panel display.



■ Troubleshooting	2
■ Service Call Message	6
■ Error Messages	7
■ Questions & Answers	8

Troubleshooting



Check the following items when trouble occurs or an error message appears while you're using the machine for FAX operations.

- **Trouble Sending Documents** (See p. 10-2.)
- **Trouble Receiving Documents** (See p. 10-4)
- **Other Problems** (See p. 10-5.)

Trouble Sending Documents

To cancel transmissions

Cancel transmission as follows:

- **During scanning:**
Press the  (STOP) key, or press [CANCEL] in the touch panel display.
- **After scanning has finished:**
 1. Press the [FAX MONITOR] key, and then the [TX DOCUMENT] key.
 2. Press the [▼] or [▲] keys to select the document to cancel, then press the [CANCEL] key.
- **During direct transmission:**
Press the  (STOP) key, or press [CANCEL] in the touch panel display.

Documents will not send even after dialling the destination

- **Make sure the telephone line type is set correctly.**
 - Make sure the telephone line type (touch-tone/rotary dial) is set correctly. (See "Selecting the Line Type," on p. 1-16.)
- **Make sure the telephone number is dialed correctly.**
 - Make sure you have the correct telephone number, and dial again.
 - If you're using One-touch Speed Dialling or Coded Speed Dialling, make sure the stored telephone number is correct.
- **Make sure the other party's FAX has not run out of recording paper, and that it's memory is not full.**
 - Call the other party, and ask them to check their machine for sufficient recording paper and free memory.

Memory immediately becomes full when sending documents

- **Make sure that Density is not set to "Auto," and Image Quality is not set to "Photo."**
 - Avoid sending too many documents such as photographs using the Memory Transmission Feature. Instead, dial directly. (See "Direct Sending," on p. 3-6.)
 - Select the [TX DOCUMENT] or [RX DOCUMENT] key in the FAX Monitor screen, and delete unwanted documents or documents that cannot be sent because of communication errors. (See "Setting Whether to Clear Failed Transmissions from Memory," on p. 9-41.)
 - Delete unwanted documents from the memory boxes. (See "Printing and Deleting Documents in the Memory Box," on p. 8-13.)

The other party receives FAX documents with vertical streaks

- **Make sure the platen glass is clean.**
 - Use your machine to make a copy of the document, and check for streaks. If streaks appear, clean the platen glass.

The other party receives faint FAX documents

- **Make sure Density is not set to “Auto,” and Image Quality is not set to “Photo.”**
 - Set exposure to “Dark” and Image Quality to “Photo,” and send the documents again.

The machine won't transmit using a subaddress

- **Make sure the other party is using the subaddress function.**
- **Make sure you've specified the correct subaddress and password.**
- **Make sure the other party's machine's memory is not full.**
- **If you're using One-touch Speed Dialling or Coded Speed Dialling, make sure the stored subaddress and password are correct.**
 - Check the settings stored to the One-touch Dialling and Coded Dialling buttons.

It always takes time for the other party to switch over to receiving, resulting in an error

- **Make sure you've inserted a pause in the telephone number.**
 - When sending to a machine that takes time to switch over for FAX receiving, insert a pause after the other party's telephone number.

1

2

3

4

5

6

7

8

9

10

11

Trouble Receiving Documents

The machine will not receive documents

- **Make sure the machine has sufficient memory.**
To increase available memory, select the [TX DOCUMENT] or [RX DOCUMENT] key in the FAX Monitor screen, and delete unwanted documents.
- **Make sure the transmission terminal is not restricted in your machine's System settings.**
If RX RESTRICTION in the System settings is set to "ON", documents can be received only from registered senders.
- **Make sure the reception password is not set in your machine's System settings.**
If RX PASSWORD in the System settings is set, documents can be received only from senders that use the correct password.

Auto Receiving does not work

- **Make sure the machine's receiving mode is not Memory Lock or Transfer.**
Check this in the Basic Features screen. Change to Auto Receiving mode in the Special Features mode.

Quality of printed originals is uneven

- **Make sure the platen glass of the other party's machine is clean.**
Make a few copies using your machine. If the copies are not streaked, the problem is in the other party's machine. Contact the other party and ask them to clean their machine's platen glass and send the document again.

The machine will not receive to a memory box

- **Make sure the other party is sending to a stored memory box.**

Other Problems

Transmissions are slow

- **Make sure that Density is not set to “Auto” and Image Quality is not set to “Photo.”**
If you are sending a document containing only text, set Image Quality to “Text.”
- **Make sure Transmission mode is not set to ECM Reception or ECM Transmission.**
If ECM is not necessary, cancel ECM Reception or ECM Transmission mode. (See p. 9-37, 9-46.)

Domestic transmissions are fine, but error code #018 occurs during overseas calls, preventing transmission

- **Make sure a pause is inserted in the telephone number.**
Insert a pause at the end of the telephone number and dial again, or change the long-distance setting.

1

2

3

4

5

6

7

8

9


10

11


Service Call Message

If a malfunction occurs and the machine will not operate normally, the service-call message on the right appears in the touch panel display.

If this message appears, follow the procedure described below.




Turn the power switch OFF, wait for at least 10 seconds, then back ON.



If the machine still does not operate normally, do the following, and then contact your service representative.

- Turn the power switch OFF.
- Unplug the power cable from the outlet.



Error Messages

Error Code and Message	Cause and Remedy
#001 Check your document.	<ul style="list-style-type: none"> Paper jam. Remove any jammed paper. (See Chapter 4, "Clearing Paper Jams," in the Reference Manual.)
#003 Document is too long.	<ul style="list-style-type: none"> Communications that take longer than a preset time (64 minutes) cause an error. Change the resolution to any setting other than ultra-fine, and send the document again.
#005 No answer.	<ul style="list-style-type: none"> The other party did not answer within 35 seconds. Dial again. The receiving machine is not a G3 FAX. Confirm this with the receiving party.
#011 No response from the remote unit.	<ul style="list-style-type: none"> The document you're sending was not placed correctly. Place it again, then re-send. Polling reception was not possible because no document was placed in the other party's FAX. Ask the other party to place the original.
#012 No recording paper in remote unit.	<ul style="list-style-type: none"> The document could not be sent because the receiving FAX machine is out of paper.
#018 Busy/No signal.	<ul style="list-style-type: none"> The receiving FAX did not answer, even after redialling, or the receiving machine was busy and so documents could not be sent because the FAX signal was not received within 35 seconds. Check the state of the receiving FAX, then send again.
#037 The memory is full.	<ul style="list-style-type: none"> Your machine's memory is full. To increase available memory, select the [TX DOCUMENT] or [RX DOCUMENT] key in the FAX Monitor screen, and delete unwanted documents.

1

2

3

4

5

6

7

8

9

10

11

Questions & Answers

Q: How do I increase the number of times my machine automatically redials?

A: You can set the number of redials as high as 15 by increasing the "Auto Redial" setting in the User mode. (See "Automatic Redialling When the Other Party is Busy," on p. 9-39.)

Q: What happens to documents that are sent to my machine while the power switch on the control panel is OFF?

A: These documents are automatically received, and print automatically when all documents have been received.

Q: What happens if a document arrives while my machine is copying?

A: You need not do anything special. While you are making copies, the document is automatically received and stored to the machine's memory, and will print automatically when you finish copying. You can change the order in which these documents print. (See "Setting the Printing Priority in Copy, FAX, and Printer Operations," on p. 3-17 in the *Reference Manual*.)

Q: I frequently send documents in Fine mode. How do I set my machine to always return to Fine mode after the power is turned ON or when communications have finished?

A: You can change the standard settings for resolution, image quality, and exposure in the Standard mode. (See "Changing the Standard Mode," on p. 9-15.)

Q: What happens to received FAX documents if a paper jam occurs while they are printing?

A: If documents are not printed correctly, they are held in memory. When the paper jam is cleared, printing resumes from the page where the paper jam occurred.

Q: What happens to documents in memory or One-touch Speed Dial settings if power is interrupted?

A: Documents remain in memory for as long as an hour if power is interrupted. Stored One-touch Speed Dialling or Coded Speed Dialling destinations also remain in memory. However, note that if power is interrupted while a document is being received, that document is not stored in memory.

Q: The machine goes into Sleep mode when it is not being used much. What happens to documents that arrive while the machine is in Sleep mode? Does the call tone sound?

A: The call tone sounds and documents are automatically received as usual while the machine is in Sleep mode.


Q: How can I save paper?

A: The 3121 series allows you to print received documents on both sides of the paper. (See "Setting Whether to Print Received Documents on Both Sides of the Paper," on p. 9-100.)

Q: Can I turn the power OFF even after setting timer transmission?

A: The power switch on the control panel can be turned OFF while you are not using your machine. When the preset time is reached, documents set for timer transmission are still sent from memory.

This chapter describes and shows examples of the Activity Management Reports and lists you can use to help track your machine's activity. This chapter also lists the machine's specifications, and provides indexes.



■ Activity Management Reports and Lists.....	2
■ Main Specifications	16
■ Index.....	17

Activity Management Reports and Lists

You can print Activity Management Reports and lists from your machine to check the status of its transmissions and receptions.

Checking the Communications Status with Activity Management Reports

Activity Management Reports allow you to check the results of your machine's transmissions and receptions. Various types of Activity Management Reports are available, including Transmission Reports and Failed Transmission Reports. You can also set the machine to print reports automatically after transmission and reception.

● Transmission Reports

The machine can print two types of Transmission Reports:

- TX Reports
These can be printed after each transmission.
- Failed TX Reports
These reports print out if the other party does not reply, or if an error prevents communications between your machine and the other party.

TX Report

'96 02/28 WED 16:39 ☎ 001

*** TX REPORT ***

TRANSMISSION OK

TX/RX NO 0002
CONNECTION TEL 32
SUB-ADDRESS
CONNECTION ID 32
ST. TIME 02/28 16:39
USAGE T 00'11
PGS. 1
RESULT OK

Error TX Report

'96 02/28 WED 16:57 ☎

001

```
*****  
***  ERROR TX REPORT  ***  
*****  
  
TX FUNCTION WAS NOT COMPLETED  
  
TX/RX NO          0004  
CONNECTION TEL     33  
SUB-ADDRESS  
CONNECTION ID  
ST. TIME          02/28 16:56  
USAGE T           00'00  
PGS.              0  
RESULT            NG  
                  0      STOP
```

1

2

3

4

5

6

7

8

9

10

11

- **Reports Output on Reception**

The machine can print two types of reports when it receives a FAX: Reception Reports and Memory Box Reception Reports.

- **MEMO**

- The initial setting is Reception Report "OFF" and Memory Box Reception Report "ON".

RX Report

11/11/96 MON 01:50	FAX 516 328 5841	OCÉ U.S.A.	001
***** *** RX REPORT *** *****			
RECEPTION OK			
TX/RX NO	5006		
CONNECTION TEL	25		
SUB-ADDRESS			
CONNECTION ID	OCÉ 7500		
ST. TIME	11/11 01:49		
USAGE T	01'31		
PGS.	1		
RESULT	OK		

Memory Box Reception Report

11/11/96 MON 02:01 FAX 516 328 5841

OCÉ U.S.A.

001

** MEMORY BOX REPORT **

MAILBOX #	#03
BOX NAME	GENERAL:
TX/RX NO	5008
CONNECTION TEL	25
SUB-ADDRESS	0123
CONNECTION ID	OCÉ 7500
ST. TIME	11/11 01:59
USAGE T	01'32
PGS.	1
RESULT	OK

1

2

3

4

5

6

7

8

9

10

11

● **Activity Management Report**

When the total number of transactions (receptions and transmissions) reaches 40, the machine automatically prints an Activity Management Report covering those last 40 transactions. You can also print Activity Management Reports whenever you like, or set the machine to Print Activity Management reports at a preset time every day.

Activity Report

11/11/96 MON 02:02 FAX 516 328 5841

OCÉ U.S.A.

001

*** ACTIVITY REPORT ***

ST. TIME	CONNECTION TEL/ID	SENDER'S NAME	NO.	MODE	PGS.	RESULT
*11/21 31:62	OCÉ U.S.A. 2101 1250		0001	TX	0	NG 00'00
*11/21 31:62	OCÉ-FE-PTE. LTD. 1 432 2060		0002	DEL SQ BDCST	0	NG 00'00
*11/21 31:62			5001	MANUAL RX	0	NG 00'00
*11/21 31:62			5002	MANUAL RX	0	NG 00'00
*11/21 31:62	OCÉ U.S.A. 2101 1250		0003	TX	0	NG 00'00
*11/21 31:62			5003	MANUAL RX	0	NG 00'00
*11/21 31:62			5004	MANUAL RX	0	NG 00'00
*11/11 01:45	OCÉ 7500 25 0123		5005	MEM. BOX RX ECM	1	OK 01'33
*11/11 01:49	OCÉ 7500 25		5006	AUTO RX ECM	1	OK 01'31
*11/11 01:55	OCÉ 7500 25		5007	AUTO RX ECM	1	OK 01'32
*11/11 01:59	OCÉ 7500 25 0123		5008	MEM. BOX RX ECM	1	OK 01'32

Printing Lists

The machine can print two types of lists: lists from the FAX Monitor screen or lists from the Print List screen.

- **Printing lists from the FAX Monitor screen**
Lists printed from the TX DOCUMENT, RX DOCUMENT, or TX/RX RESULT screen allow you to check the transmission status (ready to send or sending) or reception status of documents.

TX Reserve List

This list is printed from the FAX Monitor's Document screen

11/11/96 MON 02:02 FAX 516 328 5841

OCÉ U.S.A.

001

*** TX RESERVE LIST ***

TX/RX NO	MODE	CONNECTION TEL/ID	PGS.	SET TIME	ST. TIME	SENDER'S NAME
0011	TX	I 011OCÉ U.S.A.	1	11/21 31:62	12:00	OCÉ U.S.A.
0012	TX	I 021OCÉ-FE-PTE. LTD.	1	11/21 31:62		OCÉ U.S.A.
0013	TX	I 031OCÉ-AUSTRALIA	1	11/21 31:62		OCÉ U.S.A.
0014	DEL SQ BDCST	I 041NORTH AMERICA	1	11/21 31:62		OCÉ U.S.A.
0015	TX	I 011OCÉ U.S.A.	1	11/21 31:62		OCÉ U.S.A.
0016	TX	25	1	11/11 01:48		OCÉ U.S.A.

1

2

3

4

5

6

7

8

9

10

11

Document Memory List

This is a list of all documents in memory. This list is printed from the FAX Monitor's RX Document screen.

11/11/96 MON 01:23

FAX 516 328 5841

OCÉ U.S.A.

001

*** DOC. MEMORY LIST ***

TX

TX/RX NO	MODE	CONNECTION TEL/ID	PGS.	SET TIME	ST. TIME	SENDER'S NAME
0014	DEL SQ BDCST	[04]NORTH AMERICA	1	11/21 31:62	12:00	OCÉ U.S.A.
0012	TX	[02]OCÉ-FE-PTE. LTD.	1	11/21 31:62		OCÉ U.S.A.
0013	TX	[03]OCÉ-AUSTRALIA	1	11/21 31:62		OCÉ U.S.A.
0011	TX	[01]OCÉ U.S.A.	1	11/21 31:62		OCÉ U.S.A.
0015	TX	[01]OCÉ U.S.A.	1	11/21 31:62		OCÉ U.S.A.

RX

TX/RX NO	MODE	CONNECTION TEL/ID	PGS.	SET TIME	ST. TIME	SENDER'S NAME
----------	------	-------------------	------	----------	----------	---------------

Activity Report

This list is printed from the FAX Monitor's TX/RX RESULT screen.

You can print this report whenever you like. (See "Setting Printing of Activity Reports," on p. 9-107.)

11/11/96 MON 02:02 FAX 516 328 5841

OCÉ U.S.A.

001

*** ACTIVITY REPORT ***

ST. TIME	CONNECTION TEL/ID	SENDER'S NAME	NO.	MODE	PGS.	RESULT
*11/21 31:62	OCÉ U.S.A. 2101 1250		0001	TX	0 NG	00'00
*11/21 31:62	OCÉ-FE-PTE. LTD. 1 432 2060		0002	DEL SQ BDCST	0 NG	00'00
*11/21 31:62			5001	MANUAL RX	0 NG	00'00
*11/21 31:62			5002	MANUAL RX	0 NG	00'00
*11/21 31:62	OCÉ U.S.A. 2101 1250		0003	TX	0 NG	00'00
*11/21 31:62			5003	MANUAL RX	0 NG	00'00
*11/21 31:62			5004	MANUAL RX	0 NG	00'00
*11/11 01:45	OCÉ 7500 25 0123		5005	MEM. BOX RX ECM	1 OK	01'33
*11/11 01:49	OCÉ 7500 25		5006	AUTO RX ECM	1 OK	01'31
*11/11 01:55	OCÉ 7500 25		5007	AUTO RX ECM	1 OK	01'32
*11/11 01:59	OCÉ 7500 25 0123		5008	MEM. BOX RX ECM	1 OK	01'32

MEMO

- You can print Activity Management Reports separately for transmission or reception. (See p. 9-107.)

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

● **Printing lists from the Print List screen**

This list is printed from the Print List screen in the Custom FAX Settings Screen. You can print stored One-touch Speed Dialling or Coded Speed Dialling information, or all set Custom FAX Settings

One-touch Speed Dialling List 1

This list shows the One-touch Speed Dialling destinations stored in the machine.

11/11/96 MON 01:24 FAX 516 328 5841 OCÉ U.S.A. 001

*** 1-TOUCH SPD DIAL LIST 1 ***

NO.	CONNECTION TEL	CONNECTION ID	MODE	⌚
[01]	2101 1250	OCÉ U.S.A.	REGULAR TX	
[02]	1 432 2060	OCÉ-FE-PTE. LTD.	REGULAR TX	
[03]	516 488 6700	OCÉ-AUSTRALIA	REGULAR TX	
[04]	GROUP DIAL	NORTH AMERICA	REGULAR TX	12:00

One-touch Speed Dialling List 2

This list details all information relating to a particular One-touch Speed Dialling key.

11/11/96 MON 01:24		FAX 516 328 5841		OCÉ U.S.A.		001																																																																																																																									
<div>***** *** 1-TOUCH SPD DIAL LIST 2 *** *****</div> <table><tr><td>[01]</td><td>CONNECTION TEL</td><td>2101 1250</td><td colspan="5"></td></tr><tr><td></td><td>CONNECTION ID</td><td>OCÉ U.S.A.</td><td colspan="5"></td></tr><tr><td></td><td>TX SPEED</td><td>14400 bps(0)</td><td colspan="5"></td></tr><tr><td></td><td>MODE</td><td>REGULAR TX</td><td colspan="5"></td></tr><tr><td>[02]</td><td>CONNECTION TEL</td><td>1 432 2060</td><td colspan="5"></td></tr><tr><td></td><td>CONNECTION ID</td><td>OCÉ-FE-PTE. LTD.</td><td colspan="5"></td></tr><tr><td></td><td>TX SPEED</td><td>14400 bps(0)</td><td colspan="5"></td></tr><tr><td></td><td>MODE</td><td>REGULAR TX</td><td colspan="5"></td></tr><tr><td>[03]</td><td>CONNECTION TEL</td><td>516 488 6700</td><td colspan="5"></td></tr><tr><td></td><td>CONNECTION ID</td><td>OCÉ-AUSTRALIA</td><td colspan="5"></td></tr><tr><td></td><td>TX SPEED</td><td>14400 bps(0)</td><td colspan="5"></td></tr><tr><td></td><td>MODE</td><td>REGULAR TX</td><td colspan="5"></td></tr><tr><td>[04]</td><td>CONNECTION TEL</td><td>GROUP DIAL</td><td colspan="5"></td></tr><tr><td></td><td>CONNECTION ID</td><td>NORTH AMERICA</td><td colspan="5"></td></tr><tr><td></td><td>TX START TIME</td><td>1.12:00 2.15:00 3.18:00 4. 5.</td><td colspan="5"></td></tr></table>								[01]	CONNECTION TEL	2101 1250							CONNECTION ID	OCÉ U.S.A.							TX SPEED	14400 bps(0)							MODE	REGULAR TX						[02]	CONNECTION TEL	1 432 2060							CONNECTION ID	OCÉ-FE-PTE. LTD.							TX SPEED	14400 bps(0)							MODE	REGULAR TX						[03]	CONNECTION TEL	516 488 6700							CONNECTION ID	OCÉ-AUSTRALIA							TX SPEED	14400 bps(0)							MODE	REGULAR TX						[04]	CONNECTION TEL	GROUP DIAL							CONNECTION ID	NORTH AMERICA							TX START TIME	1.12:00 2.15:00 3.18:00 4. 5.					
[01]	CONNECTION TEL	2101 1250																																																																																																																													
	CONNECTION ID	OCÉ U.S.A.																																																																																																																													
	TX SPEED	14400 bps(0)																																																																																																																													
	MODE	REGULAR TX																																																																																																																													
[02]	CONNECTION TEL	1 432 2060																																																																																																																													
	CONNECTION ID	OCÉ-FE-PTE. LTD.																																																																																																																													
	TX SPEED	14400 bps(0)																																																																																																																													
	MODE	REGULAR TX																																																																																																																													
[03]	CONNECTION TEL	516 488 6700																																																																																																																													
	CONNECTION ID	OCÉ-AUSTRALIA																																																																																																																													
	TX SPEED	14400 bps(0)																																																																																																																													
	MODE	REGULAR TX																																																																																																																													
[04]	CONNECTION TEL	GROUP DIAL																																																																																																																													
	CONNECTION ID	NORTH AMERICA																																																																																																																													
	TX START TIME	1.12:00 2.15:00 3.18:00 4. 5.																																																																																																																													

1

2

3

4

5

6

7

8

9

10

11

Coded Speed Dial List 1

This list shows the Coded Speed Dialling destinations stored in the machine.

11/11/96 MON 01:25		FAX 516 328 5841		OCÉ U.S.A.		001	
***** *** CODED SPEED DIAL LIST 1 *** *****							
NO.	CONNECTION TEL			CONNECTION ID		MODE	⌚
[*000]	416 795 1111			OCÉ ITALIA		REGULAR TX	
[*001]	8 7448500			OCÉ U.K.		REGULAR TX	
[*002]	1 462 2060			OCÉ-CHINA		REGULAR TX	
[*003]	GROUP DIAL			EUROPA		REGULAR TX	12:00

Coded Speed Dial List 2

This list details all information relating to a particular Coded Speed Dialling key.

11/11/96 MON 01:25 FAX 516 328 5841

OCÉ U.S.A.

001

*** CODED SPEED DIAL LIST 2 ***

[*000]	CONNECTION TEL	416 795 1111			
	CONNECTION ID	OCÉ ITALIA			
	TX SPEED	14400 bps(0)			
	MODE	REGULAR TX			
[*001]	CONNECTION TEL	8 7448500			
	CONNECTION ID	OCÉ U.K.			
	TX SPEED	14400 bps(0)			
	MODE	REGULAR TX			
[*002]	CONNECTION TEL	1 462 2060			
	CONNECTION ID	OCÉ-CHINA			
	TX SPEED	14400 bps(0)			
	MODE	REGULAR TX			
[*003]	CONNECTION TEL	GROUP DIAL			
	CONNECTION ID	EUROPA			
	TX START TIME	1.12:00	2.	3.	4. 5.

Group Dialling List

This list shows the Group Dialling destinations stored in the machine.

11/11/96 MON 01:25		FAX 516 328 5841		OCÉ U.S.A.		001	
***** *** GROUP DIAL LIST *** *****							
[*003] EUROPA		[*000] 416 795 1111		OCÉ ITALIA			
		[*001] 8 7448500		OCÉ U.K.			
		[03] 516 488 6700		OCÉ-AUSTRALIA			
TX START TIME		1.12:00 2.		3.		4. 5.	
[04] NORTH AMERICA		[01] 2101 1250		OCÉ U.S.A.			
		[02] 1 432 2060		OCÉ-FE-PTE. LTD.			
TX START TIME		1.12:00 2.15:00		3.18:00 4.		5.	

1

2

3

4

5

6

7

8

9

10

11

User's Data List

This list shows Custom FAX Settings. The total number of pages in the report varies according to File.

● User's Data List (sheet 1)

11/11/96 MON 01:26 FAX 516 328 5841		OCÉ U.S.A.		001	
***** *** USER'S DATA LIST *** *****					
1.USER SETTINGS					
UNIT TELEPHONE #	516 328 5841				
UNIT NAME	OCÉ U.S.A.				
SENDER'S NAME	01: SALES DEPT 1				
	02: PLANNING DEPT				
	03: DESIGN DEPT				
TX TERMINAL ID	ON				
TTI POSITION	OUTSIDE IMAGE				
TELEPHONE # MARK	FAX				
DENSITY CONTROL	5				
VOLUME					
ALARM VOLUME	4				
MONITOR VOL.	4				
OFF-HOOK ALARM	ON				
DIAL TONE	ON				
TEL LINE TYPE	TOUCH TONE				
GENERAL1					
GENERAL2					
STANDARD KEY1 SETTING	DELAYED TX				
STANDARD KEY2 SETTING	DIRECTORY				
2.REPORT SETTINGS					
TX REPORT	OUTPUT YES				
TX CONFIRMATION REP.	OFF				
RX REPORT	OUTPUT YES				
MEMORY BOX REPORT	OUTPUT YES				
ACTIVITY REPORT					
AUTO PRINT	ON				
TX/RX SEPARATE	OFF				
DAILY REPORT TIME	OFF				
3.TX SETTINGS					
ECM TX	ON				
MID PAUSE	2 SEC				
AUTO REDIAL	ON				
REDIAL TIMES	2 TIMES				
REDIAL INTERVAL	2 MIN				
TX ERROR RESEND	ERROR & 1ST PAGE				
BATCH TX	ON				
ERASE FAILED TX	ON				
TIME OUT	ON				
STAMP DOC.	DIRECT&MEMORY TX				
4.RX SETTINGS					
ECM RX	ON				
INCOMING RING	OFF				
MANUAL/AUTO SWITCH	OFF				
MEMORY RX	ON				
RX PAGE FOOTER	OFF				
5.PRINTER SETTING					
NUMBER OF RX COPIES	1 COPIES				
SELECT CASSETTE					
SW A	ON				
SW B	ON				
SW C	ON				
SW D	ON				
RX REDUCTION	ON				
RX REDUCTION	AUTO				
REDUCE %	90%				
REDUCE DIREC.	VERTICAL ONLY				
TOW-SIDED PRINT	OFF				
N ON 1 LOG	OFF				

● User's Data List (sheet 2)

11/11/96 MON 01:26 FAX 516 328 5841		OCÉ U.S.A.		002	
6. FILE SETTINGS					
1. MEMORY BOX					
#01 CONFIDENTIAL		CONFIDENTIAL: JONES GM			
SUB-ADDRESS		1234567890			
RX		ON			
SELECT ORIG. UNIT		OFF			
PRINT RX DOC.		ON			
PRINT RX DOC.		MANUAL			
#02 BATCH SENDING		CANON SALES			
SUB-ADDRESS		ON			
TX		[01] [02] [03] [04]			
CONNECTION TEL/ID		NOT TRANSMIT			
RECEIVED DOCUMENT		TRANSMIT			
SCAN DOCUMENT		1. 12:00 2. 3. 4. 5.			
TX START TIME		[EVERYDAY]			
DIAL DIGITS REMAIN		95%			
2. PRESET POLLING OFF					
3. TRANSFER OFF					
4. MEMORY LOCK OFF					
7. SYSTEM SETTINGS					
RX RESTRICTION		OFF			
TX START SPEED		14400 bps			
RX START SPEED		14400 bps			
REMOTE CONTROL		OFF			
FIS SWITCH		ON			
PIN CODE ACCESS		OFF			

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	

Main Specifications

Name	: G3 FAX Board-C1	
Sending Sizes	A3 to A5	
Paper Sizes	: A3 to A5	
Transmission Times (for a CCITT No. 1 Chart)	: ECM-MMR	6 sec. (14400 bps) 9 sec. (9600 bps)
	G3MR mehtod:	12 sec. (14400 bps) 18 sec. (9600 bps) 13 sec. (14400 bps)
	G3MH method:	19 sec. (9600 bps)
Scanline Density (scan, transmission)	: Standard mode:	8 pels/mm × 3.85 line/mm
	Fine mode:	8 pels/mm × 7.7 line/mm
	Super-fine:	8 pels/mm × 15.4 line/mm
	Ultra-fine:	16 pels/mm × 15.4 line/mm
Communication System	: Half-duplex	
Telephone Line Used/Number of Lines	: Public Switched Telephone Network, facsimile network 1 line	
Auto Dial Functions	: One-touch Dialling	60 destinations
	Coded Dialling	140 destinations
Image Memory	: 1 MB (expansible up to 4 MB, 10 MB)	

Specifications are subject to change without notice for product improvement.

Index

A

▲▼	Facsimile Manual	p. 1-13
2 → 1-SIDED	Facsimile Manual	p. 4-7
2 ON 1 TX	Facsimile Manual	p. 4-23
3121 Cartridge	Reference Manual	p. 5-13
3121 Cassette Feeding Unit-L1	Reference Manual	p. 6-3
A/B-size	Facsimile Manual	p. 4-16
Activity Management Reports	Facsimile Manual	p. 11-2
Activity Reports	Facsimile Manual	p. 9-107
Adding a Destination	Facsimile Manual	p. 6-13
Adding Toner	Reference Manual	p. 5-9
ADDITIONAL FUNCTION key	Facsimile Manual	p. 1-10
Additional Function Screen	Facsimile Manual	p. 1-7
Additional Functions	Facsimile Manual	p. 9-2
ADF	Facsimile Manual	p. 3-11
Adjusting a Paper Drawer to Hold a Different Paper Size	Reference Manual	p. 5-7
Adjusting the Brightness of the Touch Panel Display	Reference Manual	p. 5-15
Adjusting the Standard Exposure	Reference Manual	p. 3-39
Adjustment/Cleaning	Reference Manual	p. 3-36
Alternative Telephone Network	Facsimile Manual	p. 7-12
AREA DESIG.	Facsimile Manual	p. 4-17
AUDIBLE TONES	Reference Manual	pp. 3-10, 9-10
AUTO CLEAR SETTING	Reference Manual	p. 3-7
AUTO CLEAR TIME	Reference Manual	p. 3-33
AUTO REDIAL	Facsimile Manual	p. 9-39
AUTO SLEEP TIME	Reference Manual	p. 3-32
AUTOMATIC EXPOSURE ADJUSTMENT	Reference Manual	p. 3-9
Automatic Receiving	Facsimile Manual	p. 5-6

B

BACK SPACE	Facsimile Manual	p. 1-21
Basic Features Screen	Facsimile Manual	p. 1-3
Batch Sending Memory Box	Facsimile Manual	p. 9-71
Batch TX	Facsimile Manual	p. 9-41
Blanking	Facsimile Manual	p. 4-14
Bulletin Board Memory Box	Facsimile Manual	p. 9-73

C

C	Facsimile Manual	p. 1-13
Calling up the Adjustment/Cleaning Screen	Reference Manual	p. 3-36
Calling up the Custom Common Settings Screen	Reference Manual	p. 3-4
Cancel	Facsimile Manual	p. 2-5, 6-6
Canceling Transmission	Facsimile Manual	pp. 2-5, p. 6-6
Changing One-touch Speed Dialing Destinations	Facsimile Manual	p. 9-19
Changing Receiving Modes	Facsimile Manual	p. 5-3
Changing Sender's Name	Facsimile Manual	p. 3-33
Changing the Destination	Facsimile Manual	p. 6-12
Changing the Standard Mode	Facsimile Manual	p. 9-15
Changing the Status of Transmitted Documents	Facsimile Manual	p. 6-5
Changing the Document Transmission Time	Facsimile Manual	p. 6-14
Checking and Printing Copy Totals	Reference Manual	p. 3-24
Checking Communication Results	Facsimile Manual	p. 6-22
Checking Details	Facsimile Manual	pp. 6-9, 6-19, 6-23
Checking Originals before Sending	Facsimile Manual	p. 4-21
Checking Received Documents	Facsimile Manual	p. 6-15

Checking Transmitted Document	Facsimile Manual	p. 6-5
CLEAR AREA	Facsimile Manual	p. 4-19
CLEAR Key	Facsimile Manual	p. 1-11
Clearing Designated Areas	Facsimile Manual	p. 4-19
Clearing Paper Jams	Reference Manual	Chap. 4
Clearing Paper Jams (ADF-F1)	Reference Manual	p. 6-8
Clearing Paper Jams (3121 Cassette Feeding Unit-L1)	Reference Manual	p. 6-3
Clearing Paper Jams (Main Unit)	Reference Manual	Chap. 4
Clearing Paper Jams (Multi-output Tray-B2)	Reference Manual	p. 6-22
Clearing Paper Jams (Multi-output Tray-C1)	Reference Manual	p. 6-17
Clearing Paper Jams (RDF-G1)	Reference Manual	p. 6-12
Coded Speed Dialing	Facsimile Manual	p. 3-24
Communication Results (TX/RX RESULT)	Facsimile Manual	p. 6-22
Consumables	Reference Manual	pp. 5-13, 6-36
Control Card	Facsimile Manual	p. 2-8
Control Panel	Facsimile Manual	p. 1-2
Control Panel Key Operations	Facsimile Manual	p. 1-8
Control Panel Power Switch	Facsimile Manual	p. 1-2
Copy Key	Facsimile Manual	p. 1-2
Copy Stock	Reference Manual	p. 5-13
COPY TOTALS	Reference Manual	p. 3-24
Correcting a Destination	Facsimile Manual	p. 6-13
Custom Common Settings	Reference Manual	p. 3-3
Custom Fax Settings	Facsimile Manual	p. 9-2
Custom Fax Settings Items	Facsimile Manual	p. 9-3
Custom Fax Settings Screen	Facsimile Manual	p. 9-2

D

DAILY TIMER SETTINGS	Reference Manual	p. 3-35
DATE/TIME	Reference Manual	p. 3-31
Delayed Transmission (DELAYED TX)	Facsimile Manual	p. 7-4
Deleting a Destination	Facsimile Manual	p. 6-13
Deleting Copy Totals	Reference Manual	p. 3-26
Deleting Group Dialing Destinations	Facsimile Manual	p. 9-34
Deleting Received Documents	Facsimile Manual	p. 6-16
Deleting the Dept. ID and the Password	Reference Manual	p. 3-22
DENSITY	Facsimile Manual	p. 3-31
Dept. ID	Facsimile Manual	p. 2-10
DEPT. ID MANAGEMENT	Reference Manual	p. 3-20
Destiny	Facsimile Manual	p. 3-27
Details Received Documents	Facsimile Manual	p. 6-16
Details Screen	Facsimile Manual	pp. 6-9, 6-19, 6-23
Dial Tone	Facsimile Manual	p. 9-10
Direct Sending	Facsimile Manual	p. 3-6
Directory Dialing	Facsimile Manual	p. 3-25
Display Indicating How to Clear the Jam	Reference Manual	p. 4-3
Document Editing Modes	Facsimile Manual	p. 4-2
Document Size	Facsimile Manual	p. 4-8
DOCUMENT SIZE	Facsimile Manual	p. 4-8
DOMESTIC	Facsimile Manual	p. 9-23
DONE	Facsimile Manual	p. 1-13
DRAWER ELIGIBILITY FOR APS/ADS	Reference Manual	p. 3-11
[DT]	Facsimile Manual	p. 3-21

E

ECM RX	Facsimile Manual	p. 9-46
ECM TX	Facsimile Manual	p. 9-37
Enlarging /reducing at a % ratio	Facsimile Manual	p. 4-12
Entering Alphabet Characters	Reference Manual	p. 2-5
Entering Characters on the Touch Panel Display	Reference Manual	p. 2-5
Entering Symbols	Reference Manual	p. 2-6
ERASE AFTER TX	Facsimile Manual	p. 9-83
ERASE FAILED TX	Facsimile Manual	p. 9-41
Error Codes and Messages	Facsimile Manual	p. 10-7
Error Messages	Facsimile Manual	p. 10-7
ERROR TX Report	Facsimile Manual	p. 11-3
EXPOSURE RECALIB.	Reference Manual	p. 3-39
Extension	Facsimile Manual	p. 7-9
External View	Reference Manual	p. 1-7

F

Fax Error Lamp	Facsimile Manual	p. 1-2
FAX Key	Facsimile Manual	p. 1-9
Fax Monitor	Facsimile Manual	p. 6-2
Fax Monitor Screen	Facsimile Manual	p. 1-5
Fax Status Lamp	Facsimile Manual	p. 1-2
FEEDER CLEANING	Reference Manual	p. 5-17
File Settings	Facsimile Manual	p. 9-60
File Settings Screen	Facsimile Manual	p. 9-61
Fine-adjusting Zoom	Reference Manual	p. 3-38
Flow of Fax Operations	Facsimile Manual	p. 2-2
Framing	Facsimile Manual	p. 4-14
Frequently Occurring Paper Jams	Reference Manual	p. 4-14

G

GROUP DIAL LIST	Facsimile Manual	p. 9-113
GROUP DIALING	Facsimile Manual	p. 9-27
Group Mode	Reference Manual	p. 6-25
GUIDE Key	Facsimile Manual	p. 1-10

H

Handling Precautions	Reference Manual	p. 1-5
Horizontal Placement	Facsimile Manual	p. 3-9
How Originals Feed Through RDF	Facsimile Manual	pp. 3-16, 3-17

1

2

3

4

5

6

7

8

9

10

11

I

IMAGE PROCESSING	Facsimile Manual	p. 4-14
IMAGE QUALITY	Facsimile Manual	p. 3-31
Inch-size	Facsimile Manual	p. 4-16
Incoming Output Indicator Function	Reference Manual	p. 6-27
INCOMING RING	Facsimile Manual	p. 9-47
INITIAL FUNC.	Reference Manual	p. 3-6
INITIALIZE CUSTOM COMMON SETTINGS	Reference Manual	p. 3-28
INSIDE of Image	Facsimile Manual	p. 9-9
Installation Precautions	Reference Manual	p. 1-2
Integrated Operation	Reference Manual	p. 2-8
Internal View	Reference Manual	p. 1-9
International Telephone Numbers	Facsimile Manual	p. 7-11
INTERRUPT Key	Facsimile Manual	p. 1-2

J

Job/Communications Status Display	Facsimile Manual	p. 1-3
---	------------------	--------

L

Line Type	Facsimile Manual	p. 1-16
Loading paper	Reference Manual	p. 5-2
Long Distance	Facsimile Manual	p. 9-23
Long Distance (1) (2) (3)	Facsimile Manual	p. 9-23

M

M-key Setting	Facsimile Manual	p. 9-59
Main Specifications	Facsimile Manual	p. 11-16
Maintenance	Reference Manual	Chap. 5
Manual Insert Stapling Function	Reference Manual	p. 6-25
Manual Staple Mode	Reference Manual	p. 6-25
Memory Box	Facsimile Manual	Chap. 8
Memory Box Operations	Facsimile Manual	p. 8-10
Memory Box Report	Facsimile Manual	p. 9-106
Memory Box Set	Facsimile Manual	p. 9-62
Memory Box Store	Facsimile Manual	p. 9-62
MEMORY LOCK SETTING	Facsimile Manual	p. 9-90
MEMORY RX	Facsimile Manual	p. 9-48
Memory Sending	Facsimile Manual	p. 3-3
Monitor Volume	Facsimile Manual	p. 9-11
Multi-output Tray-B2	Reference Manual	p. 6-22
Multi-output Tray-C1	Reference Manual	p. 6-17

N

[NEXT]	Facsimile Manual	p. 3-21
N on 1 log	Facsimile Manual	p. 9-101
Names and Functions of the Parts on the Control Panel	Facsimile Manual	p. 1-2
Number Keys	Facsimile Manual	p. 1-8
Number Keys Dialing	Facsimile Manual	p. 3-21
Number of Receiving Documents (# OF RX COPIES)	Facsimile Manual	p. 9-96
Number of Times to Redial	Facsimile Manual	p. 9-40

O

OK.....	Facsimile Manual	p. 1-13
On-hook.....	Facsimile Manual	p. 1-3
One-touch Speed Dialing	Facsimile Manual	p. 3-23, 9-19
One-touch Speed Dialing Keys	Facsimile Manual	p. 1-2
Option Key.....	Facsimile Manual	p. 1-2
Optional Settings for Coded Speed Dialing Functions.....	Facsimile Manual	p. 9-23
Optional Settings for One-touch Speed Dialing Functions	Facsimile Manual	p. 9-23
Options	Reference Manual	p. 5-14
Orientation and Order in which Received Documents are Printed.....	Facsimile Manual	p. 5-8
Original Cannot be Cleanly Scanned.....	Reference Manual	p. 5-21
ORIGINAL FRAME ERASE	Facsimile Manual	p. 4-15
Original Scanned by ADF/RDF is Dirty	Reference Manual	p. 5-17
Original Scanning Size.....	Facsimile Manual	p. 4-8
Other Problems.....	Facsimile Manual	p. 10-5
Output Designation for Trays Multi-output Tray-B2.....	Reference Manual	p. 6-26
Output Designation of Each Tray Multi-output Tray-C1.....	Reference Manual	p. 6-17
OUTSIDE of Image	Facsimile Manual	p. 9-9

P

Paper on which Received Documents are Printed.....	Facsimile Manual	p. 5-8
Parts and Their Functions.....	Reference Manual	p. 1-7
Password.....	Facsimile Manual	p. 2-10
PAUSE TIME.....	Facsimile Manual	p. 9-38
Placing Originals.....	Facsimile Manual	p. 3-8
Platen Glass.....	Facsimile Manual	p. 3-10
Polling RX	Facsimile Manual	p. 7-2
Power Indicator.....	Facsimile Manual	p. 1-2
Preset Polling Setting	Facsimile Manual	p. 9-84
Print Information on Received Document (RX PAGE FOOTER)	Facsimile Manual	p. 9-49
Print List.....	Facsimile Manual	p. 9-109
Print List Screen	Facsimile Manual	p. 9-110
Printer Settings	Facsimile Manual	p. 9-94
Printer Settings Screen.....	Facsimile Manual	p. 9-95
Printing a DOC. Memory List.....	Facsimile Manual	p. 6-18
Printing Activity Management Reports	Facsimile Manual	p. 6-24
PRINTING PRIORITY	Reference Manual	p. 3-17
Printing Received Documents	Facsimile Manual	p. 5-8
Push-phone line.....	Facsimile Manual	p. 1-17

Q

Questions & Answers.....	Facsimile Manual	p. 10-8
--------------------------	------------------	---------

R

R-key Setting	Facsimile Manual	p. 9-58
RDF.....	Facsimile Manual	p. 3-14
Receiving Modes	Facsimile Manual	p. 5-2
REDIAL	Facsimile Manual	p. 3-22
Redial Interval	Facsimile Manual	p. 9-40
Relay Memory Box	Facsimile Manual	pp. 8-6, 9-67
Remote Control Features	Facsimile Manual	pp. 7-6, 9-55
Removing Jammed Staples.....	Reference Manual	p. 6-33
Replacing the Stamp Cartridge.....	Reference Manual	p. 6-9, 6-13
Replacing the Staple Cartridge.....	Reference Manual	p. 6-30
Report Settings.....	Facsimile Manual	p. 9-102
Report Settings Screen	Facsimile Manual	p. 9-103
Resending Failed Transmissions.....	Facsimile Manual	p. 6-11
RESET Key	Facsimile Manual	p. 1-9

RESOLUTION	Facsimile Manual	p. 3-31
RESTRICT USE OF FAX WITH CONTROL CARD	Reference Manual	p. 3-19
Returning the Custom Common Settings to Their Default	Reference Manual	p. 3-28
ROLLER CLEANING	Reference Manual	p. 5-19
ROTARY PULSE	Facsimile Manual	p. 1-17
Rotary pulse line	Facsimile Manual	p. 1-15
Routine Cleaning	Reference Manual	p. 5-16
RX (Reception) START SPEED	Facsimile Manual	p. 9-54
RX DOCUMENT	Facsimile Manual	p. 6-15
RX Document Screen	Facsimile Manual	p. 6-2
RX PASSWORD (Receiving Password)	Facsimile Manual	p. 9-56
RX REDUCTION	Facsimile Manual	p. 9-98
RX Report	Facsimile Manual	p. 9-105
RX Restrict	Facsimile Manual	p. 9-52
RX Settings Screen	Facsimile Manual	p. 9-45

S

Safety Considerations	Reference Manual	p. 9
Scanning Mode	Facsimile Manual	p. 4-4
SELECT CASSETTE	Facsimile Manual	p. 9-97
Sending Designated Areas of Originals	Facsimile Manual	p. 4-14
Sending Documents	Facsimile Manual	p. 2-2
Sending Enlarged Documents	Facsimile Manual	p. 4-11
Sending Facing-page Originals	Facsimile Manual	p. 4-4
Sending Reduced Documents	Facsimile Manual	p. 4-11
Sending Size	Facsimile Manual	p. 4-23
Sending Speed	Facsimile Manual	p. 9-23
Sending Transmission Functions (TX SETTING)	Facsimile Manual	p. 9-35
Sending Two-sided Originals	Facsimile Manual	p. 4-4
Sequential Broadcast	Facsimile Manual	p. 3-27
Service Call Message	Facsimile Manual	p. 10-6
Set Directory General Contents	Facsimile Manual	p. 9-12
SET ENVELOPE CASSETTE	Reference Manual	p. 3-14
SET SYSTEM SETTING PASSWORD	Reference Manual	p. 3-18
Setting Automatic Exposure Adjustment	Reference Manual	p. 3-9
Setting Display of the Paper Size Selection Screen	Reference Manual	p. 3-15
Setting Entry Tone, Error Tone, Job Done Tone	Reference Manual	p. 3-10
Setting Multi-output Tray-C1 or Multi-output Tray-B2	Reference Manual	p. 3-16
Setting Reception Function	Facsimile Manual	p. 9-44
Setting Standard Keys 1 and 2	Facsimile Manual	p. 9-14
Setting the Bulletin Board Memory Box	Facsimile Manual	p. 9-73
Setting the Confidential Memory Box	Facsimile Manual	p. 9-65
Setting the Current Date and Time	Reference Manual	p. 3-31
Setting the Date and Time	Facsimile Manual	p. 1-22
Setting the Dept. ID for Managing the Number of Prints by Department	Reference Manual	p. 3-20
Setting the General Memory Box	Facsimile Manual	p. 9-76
Setting the Pause Time	Facsimile Manual	p. 9-38
Setting the Printing Priority in Copy, FAX and Printer Operations	Reference Manual	p. 3-17
Setting the Screen that appears after Auto Clear Elapses	Reference Manual	p. 3-7
Setting the Specifications of an Envelope to be Placed in a Cassette	Reference Manual	p. 3-14
Setting the System Settings Password	Reference Manual	p. 3-18
Setting the Time Taken for Display to Return to Basic Features Screen after Finishing Operations	Reference Manual	p. 3-33
Setting the Time That the Unit's Power Turns OFF on Different Days of the Week	Reference Manual	p. 3-35
Setting the Time to Initiate Auto Sleep after Finishing Operations	Reference Manual	p. 3-32
Setting to Store After Installing the Machine	Facsimile Manual	p. 1-15
Setting Whether or Not a Drawer is Subject to Auto Drawer Switching	Reference Manual	p. 3-11
Settings for Different-size Originals in RDF for Non-copy Functions	Reference Manual	p. 3-8
Settings in Custom Common Settings Screen when Power is Turned ON	Reference Manual	p. 3-6
Sort Function (Sort Mode)	Reference Manual	pp. 6-18, 6-23
Special Features	Facsimile Manual	p. 1-3

Special Features Screen.....	Facsimile Manual	p. 1-4
STACK BYPASS SIZE ENTRY.....	Reference Manual	p. 3-15
STAMP.....	Facsimile Manual	p. 3-18
STANDARD SETTING.....	Facsimile Manual	p. 9-15
Staple-sort Mode.....	Reference Manual	p. 6-23
Ⓢ (START) Key.....	Facsimile Manual	p. 1-11
Ⓢ (STOP) Key.....	Facsimile Manual	p. 1-12
STORE DEPT. ID/PASSWORD.....	Reference Manual	p. 3-20
Store Destination Screen.....	Facsimile Manual	p. 9-18
STORE SPECIAL CASSETTE.....	Reference Manual	p. 3-12
Storing Coded Speed Display Destinations.....	Facsimile Manual	p. 9-22
Storing Destination (STORE DESTINATION).....	Facsimile Manual	p. 9-17
Storing Group Dialing Destinations.....	Facsimile Manual	p. 9-27
Storing One-touch Speed Dialing Destinations.....	Facsimile Manual	p. 9-19
Storing Sender's Name.....	Facsimile Manual	p. 9-7
Storing the Company Name.....	Facsimile Manual	p. 1-20
Storing the Department Name.....	Facsimile Manual	p. 1-20
Storing the Dept. ID and the Password.....	Reference Manual	p. 3-20
Storing the User Telephone Number.....	Facsimile Manual	p. 1-18
Streaks Appear on Copy Sheet.....	Reference Manual	p. 5-19
Subaddress.....	Facsimile Manual	p. 8-16
Subaddress (PSWD/SUBADDRESS).....	Facsimile Manual	p. 8-16
Ⓢ SW Setting.....	Facsimile Manual	p. 9-57
System Configuration.....	Reference Manual	p. 6-2
SYSTEM DIFF SIZE ORIGINAL.....	Reference Manual	p. 3-8
System Management Settings.....	Facsimile Manual	p. 9-50
System Settings Password.....	Reference Manual	p. 3-8
System Settings Screen.....	Facsimile Manual	p. 9-51

T

TEST PRINT.....	Facsimile Manual	p. 4-21
Thin Sheet Original.....	Facsimile Manual	p. 3-19
TIME OUT.....	Facsimile Manual	p. 9-42
TIME UNTIL UNIT QUIETS DOWN.....	Reference Manual	p. 3-34
Timer Settings.....	Reference Manual	p. 3-29
TONE.....	Facsimile Manual	p. 3-21
Touch Panel Display.....	Facsimile Manual	pp. 1-2, 1-3
TOUCH TONE.....	Facsimile Manual	p. 1-17
Transfer Setting.....	Facsimile Manual	p. 9-86
Transmission Start Speed (TX Start Speed).....	Facsimile Manual	p. 9-53
Transmission Terminal ID (TX Terminal ID).....	Facsimile Manual	p. 9-8
Transmitted Document (TX Document).....	Facsimile Manual	p. 6-5
Tray Functions.....	Reference Manual	pp. 6-17, 6-26
Tray Sliding Function.....	Reference Manual	pp. 6-18, 6-26
Trouble Receiving Documents.....	Facsimile Manual	p. 10-4
Trouble Sending Documents.....	Facsimile Manual	p. 10-2
Turning the Power OFF.....	Reference Manual	p. 2-4
Turning the Power ON.....	Reference Manual	p. 2-2
Two-page Separation.....	Facsimile Manual	p. 4-5
Two-sided Print.....	Facsimile Manual	p. 9-99
TX Document Screen.....	Facsimile Manual	p. 6-2
TX Error Redial.....	Facsimile Manual	p. 9-39
TX Report.....	Facsimile Manual	p. 9-103
TX Reserve List.....	Facsimile Manual	p. 11-7
TX Settings Screen.....	Facsimile Manual	p. 9-36
TX START TIME.....	Facsimile Manual	p. 6-14
TX/RX Result Screen.....	Facsimile Manual	p. 6-2

U

UNIT NAME	Facsimile Manual	p. 1-20
User Settings	Facsimile Manual	p. 9-5
User Settings Screen	Facsimile Manual	p. 9-6
User's Data List	Facsimile Manual	pp. 9-112, 11-14
Using the Confidential Memory Box	Facsimile Manual	p. 8-5

V

Vertical Placement	Facsimile Manual	p. 3-9
VOLUME CONTROL	Facsimile Manual	p. 9-11

W

When Paper Jams Occur Frequently	Reference Manual	p. 5-17
--	------------------	---------

Z

ZOOM FINE ADJUSTMENT	Reference Manual	p. 3-38
Zoom Transmitting	Facsimile Manual	p. 4-11
ZOOM TX	Facsimile Manual	p. 4-11